

# Reference Manual

P/N 070214-001

# 2D JANUS™ PSK for C/C++

 **ntermec**

A **UNOVA** Company

Intermec® Corporation  
6001 36th Avenue West  
P.O. Box 4280  
Everett, WA 98203-9280

U.S. technical and service support: 1-800-755-5505  
U.S. media supplies ordering information: 1-800-227-9947

Canadian technical and service support: 1-800-688-7043  
Canadian media supplies ordering information: 1-800-268-6936

Outside U.S. and Canada: Contact your local Intermec service supplier.

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Intermec manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Information and specifications in this manual are subject to change without notice.

© 1999 by Intermec Corporation  
All Rights Reserved

The word Intermec, the Intermec logo, Data Collection Browser, dcBrowser, JANUS, IRL, Duratherm, MicroBar, Sabre, Trakker, Antares, TE2000, Virtual Wedge, and CrossBar are trademarks of Intermec Corporation.

Throughout this manual, trademarked names may be used. Rather than put a trademark (® or ™) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

# Contents

*Before You Begin* **xiii**  
    *Warranty Information* **xiii**  
    *Cautions* **xiii**  
    *About This Manual* **xiv**  
    *Other Intermec Manuals* **xvii**

## 1

---

### **Getting Started**

*What Your JANUS Reader Can Do* **1-3**  
*Virtual Wedge* **1-4**  
*Reader Services* **1-5**  
    *Function Libraries* **1-6**  
    *Software Interrupts* **1-7**  
*Installing the Programmer's Software Kit* **1-8**

## 2

---

### **C Language Support**

*Building Your Program Using Borland C/C++* **2-3**  
*Building Your Program Using Microsoft C/C++* **2-4**  
*Debugging a Program With Turbo Debugger* **2-5**  
*Status Code Macros* **2-6**  
*Runtime Requirements* **2-7**  
    *Protocol Handlers* **2-7**  
    *Reader Wedge* **2-8**  
    *Specific Functions With Runtime Requirements* **2-9**  
*Certified C Language Functions* **2-11**

**Intermec C Library Functions 2-13**

**C Library Functions Listed by Category 2-14**

*im\_appl\_break\_status* 2-16  
*im\_backlight\_off* 2-18  
*im\_backlight\_on* 2-19  
*im\_backlight\_toggle* 2-20  
*im\_cancel\_rx\_buffer* 2-21  
*im\_cancel\_tx\_buffer* 2-22  
*im\_clear\_abort\_callback* 2-23  
*im\_command* 2-24  
*im\_cursor\_to\_viewport* 2-26  
*im\_decrease\_contrast* 2-27  
*im\_get\_config\_info* 2-29  
*im\_get\_contrast* 2-31  
*im\_get\_control\_key* 2-32  
*im\_get\_display\_mode* 2-34  
*im\_get\_display\_type* 2-36  
*im\_get\_follow\_cursor* 2-37  
*im\_get\_input\_mode* 2-39  
*im\_get\_keyclick* 2-41  
*im\_get\_label\_symbology* 2-43  
*im\_get\_length* 2-45  
*im\_get\_postamble* 2-46  
*im\_get\_preamble* 2-47  
*im\_get\_reboot\_flag* 2-48  
*im\_get\_viewport\_lock* 2-51  
*im\_get\_warm\_boot* 2-53  
*im\_increase\_contrast* 2-55  
*im\_input\_status* 2-57  
*im\_irl\_a* 2-59  
*im\_irl\_k* 2-63  
*im\_irl\_n* 2-66  
*im\_irl\_v* 2-69  
*im\_irl\_y* 2-74  
*IM\_ISERROR* 2-79  
*IM\_ISGOOD* 2-80



|                                    |       |
|------------------------------------|-------|
| <i>IM_ISSUCCESS</i>                | 2-81  |
| <i>IM_ISWARN</i>                   | 2-82  |
| <i>im_link_comm</i>                | 2-83  |
| <i>im_message</i>                  | 2-85  |
| <i>im_number_pad_off</i>           | 2-86  |
| <i>im_number_pad_on</i>            | 2-87  |
| <i>im_parse_host_response</i>      | 2-89  |
| <i>im_power_status</i>             | 2-91  |
| <i>im_protocol_extended_status</i> | 2-94  |
| <i>im_ready_for_reboot</i>         | 2-97  |
| <i>im_receive_buffer</i>           | 2-98  |
| <i>im_receive_buffer_no_wait</i>   | 2-101 |
| <i>im_receive_buffer_noprot</i>    | 2-104 |
| <i>im_receive_byte</i>             | 2-107 |
| <i>im_receive_input</i>            | 2-109 |
| <i>im_rs_installed</i>             | 2-113 |
| <i>im_rx_check_status</i>          | 2-114 |
| <i>im_serial_protocol_control</i>  | 2-115 |
| <i>im_set_abort_callback</i>       | 2-118 |
| <i>im_set_contrast</i>             | 2-122 |
| <i>im_set_control_key</i>          | 2-124 |
| <i>im_set_display_mode</i>         | 2-125 |
| <i>im_set_follow_cursor</i>        | 2-128 |
| <i>im_set_input_mode</i>           | 2-129 |
| <i>im_set_keyclick</i>             | 2-131 |
| <i>im_set_viewport_lock</i>        | 2-132 |
| <i>im_set_warm_boot</i>            | 2-133 |
| <i>im_setup_trx</i>                | 2-134 |
| <i>im_sound</i>                    | 2-137 |
| <i>im_standard_trx</i>             | 2-139 |
| <i>im_standby_wait</i>             | 2-142 |
| <i>im_transmit_buffer</i>          | 2-143 |
| <i>im_transmit_buffer_no_wait</i>  | 2-145 |
| <i>im_transmit_buffer_noprot</i>   | 2-148 |
| <i>im_transmit_byte</i>            | 2-151 |
| <i>im_unlink_comm</i>              | 2-153 |

*im\_viewport\_end* 2-154  
*im\_viewport\_getxy* 2-155  
*im\_viewport\_home* 2-156  
*im\_viewport\_move* 2-157  
*im\_viewport\_page\_down* 2-159  
*im\_viewport\_page\_up* 2-160  
*im\_viewport\_setxy* 2-161  
*im\_viewport\_to\_cursor* 2-165

## 3

---

### **Software Interrupts**

*Using the Software Interrupts* 3-3

*Programming With Software Interrupts* 3-6

*Specific Software Interrupt Definitions* 3-6

*INT 14H, Function 17H* 3-7

*Receive Next Buffer* 3-7

*INT 14H, Function 50H* 3-8

*Transmit Buffer* 3-8

*INT 14H, Function 60H* 3-9

*Receive Buffer* 3-9

*INT 14H, Function 71H* 3-10

*Protocol Extended Status* 3-10

*INT 14H, Function 84H* 3-11

*Cancel RX Buffer* 3-11

*INT 14H, Function 85H* 3-12

*Cancel TX Buffer* 3-12

*INT 16H, Function B4H* 3-13

*Enable/Disable Expanded Keyboard Buffer* 3-13

*INT 16H, Function B5H* 3-14

*Insert String Into Expanded Keyboard Buffer* 3-14

*INT 16H, Function B6H* 3-15

*Flush Expanded Keyboard Buffer* 3-15

*INT 16H, Function B7H* 3-16

*Enable/Disable Ctrl-Alt-Del Warm Boot* 3-16



- INT 78H, Function 06H 3-17*
  - Restore UART Configurations 3-17*
- INT 79H, Function 00H 3-21*
  - LCD Display Contrast 3-21*
- INT 79H, Function 01H 3-22*
  - LCD Display Backlight 3-22*
- INT 79H, Function 02H 3-24*
  - LCD Display Size Mode Manager 3-24*
- INT 79H, Function 03H 3-26*
  - Viewport Move 3-26*
- INT 7CH, Function 64H 3-29*
  - Generate Sound 3-29*
- INT 7DH, Function 08H 3-30*
  - Reader Wedge Control 3-30*
- INT 7DH, Function 0AH 3-35*
  - Get 2D Decoder Firmware Version 3-35*
- INT 7DH, Function 0CH 3-36*
  - Open COM2 3-36*
- INT 7DH, Function 0DH 3-37*
  - Close COM2 3-37*
- INT 7EH, Function 01H 3-38*
  - Get Application Break Status 3-38*
- INT 7EH, Function 03H 3-40*
  - Get Keypad Scanner Version 3-40*
- INT 7EH, Function 04H 3-41*
  - Get Keypad Map Table ID and Status 3-41*
- INT 7EH, Function 05H 3-42*
  - Enable/Disable KSCPU Keyclick 3-42*
- INT 7EH, Function 06H 3-43*
  - Enable/Disable Numeric Keypad 3-43*
- INT 7EH, Function 08H 3-45*
  - Enable/Disable Ctrl Key 3-45*
- INT 7EH, Function 10H 3-46*
  - Enable Viewport 3-46*
- INT 7EH, Function 11H 3-47*
  - Disable Viewport 3-47*

# 4

---

## **Advanced Programming**

### **Reader Input Modes 4-3**

*Wedge Mode 4-3*

*Programmer Mode 4-4*

*Desktop Mode 4-4*

*Differences in Input Modes 4-4*

### **Receiving Serial Data 4-6**

*Reader Services Routines 4-6*

*Communications Routines 4-8*

### **Transmitting Serial Data 4-9**

### **Communications Port UART Modes 4-9**

### **Display "Color" 4-10**

### **Advanced Power Management 4-11**

*Power Management Software Layers 4-11*

*System BIOS Interface 4-12*

*Application Interface 4-12*

*The APM Power States 4-14*

*Ready 4-14*

*Standby 4-14*

*Suspend 4-15*

*Off 4-15*

*Power State Transitions 4-15*

*Power State Cooperation 4-16*

*IPM Interface Functionality 4-18*

*Normal Suspend 4-18*

*Normal Resume 4-18*

*Critical Suspend 4-19*

*Critical Resume 4-19*

*APM Interface Functionality 4-20*



**Special APM BIOS Calls 4-22***APM Installation Check 4-24**CPU Busy 4-25**CPU Idle 4-26**Enable/Disable Power Management 4-27**Get PM Event 4-28**Get Power Status 4-30**Interface Connect 4-31**Interface Disconnect 4-32**Protected Mode 16-Bit Interface Connect 4-33**Protected Mode 32-Bit Interface Connect 4-35**Restore System BIOS Power-On Defaults 4-37**Set Power State 4-38**Suspend System 4-39**System Standby 4-40***5**

---

**Using the PSK With DCM****Accessing a Database Server Through DCM 5-3****Defining a Database Transaction 5-4***Configuring DCM 5-5**Sending a Transaction to the Database 5-6***Checking the Return Status Codes 5-7***Return Codes Listed by Calling Parameter 5-9**Return Codes Listed in Numerical Order 5-12**Symbolic Return Codes 5-14***Using a Standby File 5-15***Standby File Structure 5-16***Sample Program 5-17**

# A

---

## Status Codes

*Status Code Bit Values* A-3

*Status Codes Listed Numerically* A-4

*Status Codes Listed by Subsystem* A-22

*Subsystem 0100 RS (Reader Services)* A-23

*Subsystem 0200 CM (Configuration Management)* A-24

*Subsystem 0300 SC (Scanner)* A-27

*Subsystem 0400 DC (Decodes)* A-28

*Subsystem 0500 RW (Reader Wedge)* A-30

*Subsystem 0600 CU (Communications)* A-32

*Subsystem 0800 PM (Power Management)* A-34

*Subsystem 0A00 TM (Timer)* A-35

*Subsystem 0B00 BP (Beep)* A-36

*Subsystem 0E00 IM (Intermec Library)* A-37

*Subsystem 0F00 LG (Event Logger)* A-38

*Subsystem 1000 KB (Keyboard Buffer)* A-39

*Subsystem 1100 SS (System Configuration)* A-40

*Subsystem 1200 KP (Keypad Services)* A-41

*Subsystem 1300 DP (Display)* A-42

*Subsystem 1A00 EX (DCM Support)* A-43

# B

---

## Sample Interrupt Programs

*Using the Sample Programs* B-3

*apmif.c* B-4

*appbreak.cpp* B-7

*backlite.cpp* B-9

*close.cpp* B-10

*contrast.cpp* B-11

*ctlkey.cpp* B-13

*exstat.cpp* B-15

*fifo.cpp* B-20

*jbeep.cpp* B-23

*jboot.cpp* B-24  
*keybuff.cpp* B-25  
*keyclick.cpp* B-27  
*keystat.cpp* B-29  
*numpad.cpp* B-31  
*open.cpp* B-33  
*phterm.cpp* B-34  
*pl220ver.cpp* B-40  
*vp\_cur.cpp* B-41



---

***Index***



## Before You Begin

---

This section introduces you to standard warranty provisions, safety precautions, warnings and cautions, document formatting conventions, and sources of additional product information.

---

### **Warranty Information**

To receive a copy of the standard warranty provision for this product, contact your local Intermec sales organization. In the U.S. call (800) 755-5505, and in Canada call (800) 688-7043. Otherwise, refer to the Worldwide Sales & Service list shipped with this manual for the address and telephone number of your Intermec sales organization.

---

### **Cautions**

The cautions in this manual use the following format.



#### **Caution**

*A caution alerts you to an operating procedure, practice, condition, or statement that must be strictly observed to prevent equipment damage or destruction, or corruption or loss of data.*

#### **Conseil**

*Une précaution vous alerte d'une procédure de fonctionnement, d'une méthode, d'un état ou d'un rapport qui doit être strictement respecté pour empêcher l'endommagement ou la destruction de l'équipement, ou l'altération ou la perte de données.*

---

## **About This Manual**

This manual is part of the JANUS Programmer's Software Kit manual set. It describes the special features and methods needed for programming the JANUS family of PC-compatible readers. If you plan to write programs in C or C++, the information in this manual is very valuable.

If you plan to write programs using Interactive Reader Language (IRL), refer to the *IRL Programming Reference Manual*, Part No. 048609, and your JANUS user's manual for programming guidelines.

## **Organization**

The *2D JANUS PSK for C/C++ Reference Manual* is divided into five chapters and two appendixes as described below:

| Chapter | What You Will Find   |
|---------|--|
| 1       | <i>Getting Started</i><br>This chapter describes the capabilities of and programming methods for the JANUS readers. It also explains how to install the Programmer's Software Kit Language Libraries disk that is provided with this manual. |
| 2       | <i>C Language Support</i><br>This chapter describes how to write C applications using the Programmer's Software Kit (PSK) library functions.   |
| 3       | <i>Software Interrupts</i><br>This chapter explains how to use software interrupts in your programs.   |
| 4       | <i>Advanced Programming</i><br>This chapter explains the various reader input modes and how to use the power management software functions.  |
| 5       | <i>Using the PSK With DCM</i><br>This chapter explains how to program the reader to access a remote database connected through Intermecc DCM software.   |

Chapter      What You Will Find

*Appendix A Status Codes*

This appendix lists status codes that are returned by the PSK functions.

*Appendix B Sample Interrupt Programs*

This appendix lists C language programs that demonstrate how to use software interrupts.

***Terms and Conventions***

- A *reader* is the JANUS 2010, 2020, or 2050 PC-compatible bar code reader.
- *Reader services* are the functional abilities that distinguish the JANUS readers from a normal PC. For example, the reader's ability to decode bar code data as if it came from a PC keyboard is a typical reader service.
- *Software interrupts* are the synchronous triggering of interrupts used for application program interfaces.
- *Library functions* are the Intermec-specific functions provided in the language libraries you use to invoke various reader services.
- *PSK* means the Programmer's Software Kit and refers to the language libraries and the associated manuals.
- The *Programmer's Software Kit Language Libraries* is the disk shipped with this manual. It contains sample programs and library functions for interfacing with the reader.
- The *keypad* is the custom JANUS keyboard. Throughout this manual, specific references to the JANUS keyboard use the term *keypad*.
- The *keyboard* buffer is the machine-level buffer that stores key presses and scanned labels. Throughout this manual, specific references to this buffer and its status flags use the term *keyboard*.

### *Keypad Input*

- Keys that you press on the keypad are emphasized in **bold**. For example, “press **Enter**” means you press the key labeled “Enter” on the reader keypad.
- All key names use first-letter capitalization. For example:  
**Ctrl** = Control key  
**Enter** = Enter key  
**F3** = F3 key
- When you are required to press and release a series of keys in order, the keys are listed in order with no connectors. For example, to enter the uppercase character A, press **Shift A**. To enter this character, you press and release the **Shift** key, and then press the key marked **A**.
- When you are required to press more than one key at the same time, the keys are connected by a dash in the text. For example, press **Ctrl-Alt-Del** to perform a warm boot on a standard PC. When the keys are connected by a dash, it is important that you press and hold the keys in the order they are listed in the text.

### *Commands*

- DOS commands are printed in Courier, exactly as you must type them. For example:

```
COPY INTERMEC.* E:\
```

- Code examples are printed in 8-point Courier. For example:


```
if(step != 0) level = step;    // use step value if provided  
if(level >= 31) level = 0;    // keep level within bounds
```

### *Other Conventions*

- *Italic type* identifies a syntax parameter where it is defined in text. Italic type is also used to indicate references to other manuals and to indicate important terminology.
- Hexadecimal numbers in text are followed by an uppercase H. For example, 03 hex is shown as 03H.
- Hexadecimal numbers in C language code segments begin with 0x. For example, AX\_REG = 0x5300.



*Before You Begin*



---

### ***Other Intermec Manuals***

You may need additional information when working with the PSK in a data collection system. Please visit our Web site at [www.intermec.com](http://www.intermec.com) to download many of our current manuals in PDF format. To order printed versions of the Intermec manuals, contact your local Intermec representative or distributor.



**1**


# ***Getting Started***



*This chapter briefly describes the programming methods and capabilities that apply to the JANUS family of readers and explains how to install the PSK.*

## What Your JANUS Reader Can Do

---



Your JANUS reader is a portable, programmable bar code reader and a 386-based computer in one. Each reader has the Intermec controlled BIOS and MS-DOS 6.2. The reader behaves and functions like a normal PC with 640K of memory, with these exceptions:

- The JANUS 2010 and 2020 are hand-held, with a small LCD display, custom keyboard, and either a port for a bar code input device or a built-in scanner.
- The JANUS 2050 is mounted to a vehicle, such as a forklift, and has a monochrome CGA display, custom keyboard, built-in RF, and a port for a bar code input device.
- The operating system and protocol support programs reduce the memory available for your application to about 450K.

You can run batch programs and copy, name, or move files in the same manner as you would with any normal PC. The only difference is that the JANUS reader has ROM and RAM drives and a PC card drive.

You can also run DOS-based programs on the reader the same as you can on a PC. When you do, the reader behaves like a PC, but has the advantage of accepting bar code input as if it came from the keypad. If you are an experienced PC programmer, you have already written programs that will run on the reader.

## ***Virtual Wedge***

---

The Virtual Wedge feature of the reader allows application programs to receive decoded bar codes from the keyboard buffer. The Virtual Wedge makes the reader functionally equivalent to a reader wedge connected to a PC. Bar code input is inserted into the PC keyboard buffer as if entered from the keypad. The Virtual Wedge also allows rapid porting of PC applications to the reader.

***Note:*** *If your PC application follows MS-DOS programming conventions, it should run correctly on the JANUS reader. Not all programming languages, especially database languages, follow these conventions. If your PC application does not follow MS-DOS programming conventions, your scanned input will be incorrect.*

Valid configuration commands and reader commands are not put into the keyboard buffer. Bar code configuration commands beginning with \$+ are tagged as configuration commands by the Virtual Wedge and sent to the configuration manager to reconfigure the reader. The command parser in the Virtual Wedge software recognizes and processes reader commands.

You can run applications that use the Virtual Wedge (instead of Intermec interrupt extensions or function libraries) on either the reader or on your PC.

## Reader Services

---

Reader services include several functions ranging in complexity from controlling the reader beeper to controlling the function of the power management software. With reader services, you can easily use bar code input from a wand or scanner by using the direct program interface to handle the functions of the reader keyboard, display, and beeper.

There are two methods for incorporating the reader services into your programs:

- Using function libraries
- Using software interrupts

You can use either one or a combination of both methods.

**Note:** Do **not** run programs that use **PSK library functions** on your PC. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.



### Caution

**Do not run programs that use Intermec-specific interrupt extensions on your PC. If you attempt to run these programs without the Simulator, they will cause your PC to lock up and possibly corrupt your system BIOS.**

### Conseil

**N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.**

---

## ***Function Libraries***

You can use a *supported language* and its associated function libraries to access reader services. The term *supported language* describes a language that has extensive Intermec-supplied library functions that control reader services. The supported language functions are stored in libraries contained in the Programmer's Software Kit Language Libraries found at [www.intermec.com](http://www.intermec.com).

At the time of printing, the list of supported languages includes:

- Borland C/C++
- Microsoft C/C++
- Microsoft Visual C/C++

When you write applications in one of the supported languages, link your program to the library for your chosen language by including the header files in your program, and then invoke the reader services using the language-specific reader service commands. The Intermec-specific functions are documented in Chapter 2, "C Language Support."



---

## Software Interrupts

The reader supports special software interrupts in addition to those available on a normal PC. If your programming language supports software interrupts, you can write applications that use the reader services. However, it is much easier to use the PSK library functions.

Interrupts are a very *low-level* method of controlling a computer. Programming with interrupts is more difficult than with a high-level language (such as C).

Some of the most popular languages have built-in commands for triggering software interrupts (Microsoft C and Borland C++ for example). Languages that do not have built-in interrupt commands sometimes allow you to access interrupts by embedding fragments of assembly language inside your program. There are other methods for triggering software interrupts, and you can generate software interrupts from almost any language.

For complete descriptions and examples of the software interrupts that govern reader services, see Chapter 3, "Software Interrupts," and Appendix B, "Sample Interrupt Programs."



### Caution

***Do not run programs that use Intermec-specific interrupt extensions on your PC. If you attempt to run these programs, they will cause your PC to lock up and possibly corrupt your system BIOS.***

### Conseil

***N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.***

## ***Installing the Programmer's Software Kit***

---

The files for the Programmer's Software Kit Language Libraries are distributed in several subdirectories, each corresponding to the supported language:

| Subdirectory Name | Language                         |
|-------------------|----------------------------------|
| INTERMEC\BORLANDC | Borland C/C++                    |
| INTERMEC\MICROSFT | Microsoft C/C++ and Visual C/C++ |

The exact contents of the PSK Language Libraries is listed in the README.TXT file. To use the library functions, install the correct files on your computer. You can also use the DOS copy command to copy only the specific files you are sure you will need.

**Note:** *If you have an existing Intermec directory, the installation process will update any files in the existing Intermec directory with the newer version files having the same name.*

To install the library files

1. Copy the PSK Language Libraries files from [www.intermec.com](http://www.intermec.com) to your computer.
2. Enter the following command:

```
INSTALL dirname drive
```

where:

*dirname* is either BORLANDC, or MICROSFT, depending on which programming language you need.

*drive* is the location where you want to install the utilities library. Drive C is the default drive.

2

## *C Language Support*



*This chapter describes how to compile and link applications in C using the Programmer's Software Kit (PSK) library functions. It also provides the syntax and parameters for each function.*

## ***Building Your Program Using Borland C/C++***

---

Use the following procedure to compile and link a C/C++ program that uses the Borland C/C++ library functions that you installed from the PSK web site at [www.intermec.com](http://www.intermec.com). You will use one make file and one example program:

|            |   |
|------------|---|
| XCDEMO.PRJ | Sample make file to create XCDEMO.EXE.                      |
| XDEMO.PRJ  | Sample make file to create XDEMO.EXE.                       |
| XCDEMO.C   | Sample reader program using <code>im_receive_input</code> . |
| XDEMO.C    | Sample reader program using IRL-like functions.             |

If you are building your own program, make sure that you set the following options. The sample programs already include these settings:

- The project must be set to create a DOS-executable file.
- The memory model must be set to the Large compilation model.

To build a sample program using Borland C/C++

1. Start the Borland Programmer's Platform from Microsoft Windows.
2. Open the project file XDEMO.PRJ or XCDEMO.PRJ from:

```
\INTERMEC\BORLANDC\SAMPLES
```

3. Open XDEMO.C or XCDEMO.C from:

```
\INTERMEC\BORLANDC\SAMPLES
```

4. From the Options menu, set the Directories to the directory containing your Borland C include files and your Borland C library files:

```
\BORLANDC\INCLUDE ; \INTERMEC\BORLANDC\INCLUDE
```

```
\BORLANDC\LIB ; \INTERMEC\BORLANDC\LIB
```

5. Compile and link the demo program.

## **Building Your Program Using Microsoft C/C++**

Use the following procedure to compile and link a C/C++ program that uses the Microsoft C/C++ library functions that you installed from the PSK web site at [www.intermec.com](http://www.intermec.com). You will use one make file and one example program:

XCDEMO.MAK Sample make file to create XCDEMO.EXE.  
XDEMO.MAK Sample make file to create XDEMO.EXE.  
XCDEMO.C Sample reader program using `im_receive_input`.  
XDEMO.CPP Sample reader program using IRL-like functions.

If you are building your own program, make sure that you set the following options. The sample programs already include these settings:

- The project must be set to create a DOS-executable file.
- The memory model must be set to the Large compilation model.

To build a sample program using Microsoft C/C++

1. Start the Microsoft Programmer's Workbench from Microsoft Windows.
2. Open XCDEMO.MAK or XDEMO.MAK from:  
`\INTERMEC\MICROSFT\SAMPLES`
3. Open XCDEMO.C or XDEMO.CPP from:  
`\INTERMEC\MICROSFT\SAMPLES`
4. Set OPTIONS | DIRECTORIES to the directory containing your Microsoft C include files and your Microsoft C library files. The sample project uses the following include files and library files:  
`\MICROSFT\INCLUDE ; \INTERMEC\MICROSFT\INCLUDE`  
`\MICROSFT\LIB ; \INTERMEC\MICROSFT\LIB`
5. Build the demo program from the Project menu.

## Debugging a Program With Turbo Debugger

Turbo Debugger is the application debugging environment supplied with Borland C/C++. Since Turbo Debugger requires a lot of memory and is easier to use on a large display, you will probably want to debug your programs using the remote debugging feature. Turbo Debugger runs on your PC while the program you want debugged runs on the reader.

To use remote debugging, you must connect the PC to your reader with a null modem cable and you must run TDREMOTE.EXE on the reader.

### To debug your program

1. Connect the PC to your reader with a null modem cable.
2. Copy the TDREMOTE.EXE program to a drive on the reader.
3. If your application uses reader services, make sure they are loaded on the reader. If you use the Intermec-supplied AUTOEXEC.BAT file, they are loaded automatically. Otherwise, start reader services on the reader by entering this command:

```
RSERVICE
```

4. On the reader, change to the drive with TDREMOTE.EXE and enter the command:

```
TDREMOTE -rpm -rsn
```

where:

*rpm* sets the reader's communications port  
*m* is 1, 2, or 4 for COM1, COM2, or COM4  
*rsn* sets the transmission baud rate as follows:

| JANUS Reader  | Port | Switch | Baud    |
|---------------|------|--------|---------|
| 2010 and 2050 | COM1 | -rs2   | 19,200  |
|               |      | -rs3   | 38,400  |
|               |      | -rs4   | 115,000 |
| 2020          | COM1 | -rs2   | 19,200  |
|               |      | -rs3   | 38,400  |
|               |      | -rs4   | 115,000 |

5. On the PC where Turbo Debugger will run, go to the directory where your program file is located and enter:

```
TD -rpm -rsn progname.exe
```

where:

*rpm* sets the PC communications port. Omit this for COM1.

*rsn* sets the transmission baud rate. This parameter must match the value you entered for *-rsn* on the reader.

*progname* is your executable program file.

6. Use Turbo Debugger as described in the user's guide supplied with Borland C/C++ to debug your application.

**Note:** Turbo Debugger uses the communications port of the reader for remote debugging. You need to avoid conflict with portions of your programs that use the reader's communications functions. Skip over the portions that use communications functions.

## Status Code Macros

---

When using any of the C library functions, you can check for a specific return value or you can use one of the PSK macros to determine the severity of the returned status codes. For portability with future Intermec products, we recommend that you use the macros.

The following macros are located in IMMSG.H:

**IM\_ISERROR(*status*)** This macro returns a nonzero number when *status* indicates an error (either fatal or nonfatal). Zero is returned if *status* indicates either success or warning.

**IM\_ISSUCCESS(*status*)** This macro returns a nonzero number when *status* indicates either success or warning. Zero is returned if *status* indicates an error (either fatal or nonfatal).

**IM\_ISGOOD(*status*)** This macro returns a nonzero number when *status* indicates success.

**IM\_ISWARN(*status*)** This macro returns a nonzero number when *status* indicates a warning.



The following example uses `IM_ISERROR` to test for an error, and then prints the error message on the reader display.

```
status = im_transmit_byte( com_port, outchar);
if ( IM_ISERROR(status))
im_message(status);
```

## Runtime Requirements

---

For some library functions to work properly, you must install and run specific software components at program execution time. For example, if the reader is using a communications port, you must load a protocol handler. Because protocol handlers use a lot of memory, they are not automatically loaded for you. Other functions require the Reader Wedge TSR program.

***Note:** Large C language programs can require more memory than is currently available in the reader. One possible solution is to use overlays. For more information, see your C language programmer's guide.*

---

### Protocol Handlers

You use the Intermec protocol handler (`PHIMEC.EXE`) when the reader is connected with other Intermec devices. `PHIMEC.EXE` works with User-Defined, Point-to-Point, Polling Mode D, and Multi-Drop protocols.

You use the PC standard protocol handler (`PHPCSTD.EXE`) when the reader is connected to devices that use PC standard protocol. `PHPCSTD.EXE` provides low-level communication abilities and protocol services at the DOS level for non-communication software. It also provides byte-by-byte transfer.

If your reader is a radio frequency (RF) unit, `RFPH.EXE` is automatically loaded. For more information on protocol handlers, refer to your JANUS user's manual.

To install a protocol handler on the reader

- From the DOS prompt, enter the following command:

```
handler n
```

where:

*handler* is either `PHIMEC` or `PHPCSTD`.

*n* is the number of the communications port.

When your application is finished, the protocol handler TSR continues to run and can prevent other applications from running due to lack of memory. You can unload the protocol handler TSR by adding the unload command as the last line of the batch file that launches your application.

To unload a protocol handler on the reader

- From the DOS prompt, enter the following command:

```
unload handler n
```

where:

*handler* is either PHIMEC or PHPCSTD.

*n* is the number of the communications port.

---

## ***Reader Wedge***

Some functions, such as `im_receive_input`, allow the reader to receive input from multiple sources and process the input depending on the source. You must load the Reader Wedge (RWTSR.EXE) TSR to use these functions.

When your application is finished, the Reader Wedge TSR continues to run in the background and take up memory. The Reader Wedge TSR can prevent other applications from running due to lack of memory. Make sure that your application unloads the Reader Wedge TSR as part of the exit routine or as part of a batch file.

**Note:** *PSK version 2.1 and above automatically loads RWTSR.EXE for C language applications. However, you get optimal memory management by loading and unloading RWTSR.EXE at the command line. The autoload feature uses about 6K additional memory.*

To load the Reader Wedge TSR on the reader

- From the DOS prompt, enter the following command:

```
RWTSR
```

To unload the Reader Wedge TSR on the reader

- From the DOS prompt, enter the following command:

```
RWTSR -D
```

---

## ***Specific Functions With Runtime Requirements***

The following table lists the PSK functions that have runtime requirements.

---

### ***Specific Runtime Requirements***

| <b>This Function</b>      | <b>Requires</b>   |
|---------------------------|---|
| im_cancel_rx_buffer       | Protocol Handler  |
| im_cancel_tx_buffer       | Protocol Handler  |
| im_clear_abort_callback   | Reader Wedge  |
| im_command                | Reader Wedge  |
| im_get_input_mode         | Reader Wedge  |
| im_get_label_symbology    | Reader Wedge  |
| im_get_length             | Reader Wedge  |
| im_input_status           | Reader Wedge  |
| im_irl_a                  | Reader Wedge  |
| im_irl_k                  | Reader Wedge  |
| im_irl_n                  | Reader Wedge  |
| im_irl_v                  | Reader Wedge<br>If the data is from a communications port, use a Protocol Handler and im_link_comm. |
| im_irl_y                  | Reader Wedge<br>Protocol Handler<br>Use im_link_comm.   |
| im_link_comm              | Reader Wedge<br>Protocol Handler  |
| im_parse_host_response    | Protocol Handler  |
| im_receive_buffer         | Protocol Handler<br>Do not use im_link_comm.  |
| im_receive_buffer_no_wait | Protocol Handler<br>Do not use im_link_comm.  |
| im_receive_buffer_noprot  | Protocol Handler<br>Do not use im_link_comm.  |
| im_receive_byte           | PHPCSTD.EXE<br>You must use PC standard protocol on the host.<br>Do not use im_link_comm.           |

---

*Specific Runtime Requirements (continued)*

| <b>This Function</b>                    | <b>Requires</b>  |
|---|--|
| <code>im_receive_input</code>           | Reader Wedge<br>Protocol Handler<br>Use <code>im_link_comm</code> if data is from a communications port. |
| <code>im_rx_check_status</code>         | Protocol Handler   |
| <code>im_serial_protocol_control</code> | Use <code>im_link_comm</code> .  |
| <code>im_set_abort_callback</code>      | Reader Wedge   |
| <code>im_set_display_mode</code>        | Reader Wedge   |
| <code>im_set_input_mode</code>          | Reader Wedge   |
| <code>im_setup_trx</code>               | Protocol Handler   |
| <code>im_standard_trx</code>            | Protocol Handler   |
| <code>im_standby_wait</code>            | Reader Wedge   |
| <code>im_transmit_buffer</code>         | Protocol Handler   |
| <code>im_transmit_buffer_no_wait</code> | Protocol Handler   |
| <code>im_transmit_buffer_noprot</code>  | Protocol Handler   |
| <code>im_transmit_byte</code>           | Protocol Handler<br>You must install PHPCSTD.  |
| <code>im_unlink_comm</code>             | Reader Wedge<br>Protocol Handler   |

## ***Certified C Language Functions***

---

Because of the large number of functions in the C language, not all functions are known to work correctly when used with the JANUS family of readers. Many of these have been tested, however, and are known to operate on the reader the same as on a PC. These tested functions are listed below.

---

### *Tested C Functions*

|                  |              |              |
|------------------|--------------|--------------|
| atol             | _dos_settime | fseek        |
| bdos             | dostounix    | _fstrlen     |
| _bios_keybrd     | enable       | fwrite       |
| bioskey          | exit         | geninterrupt |
| _bios_serialcom  | farcoreleft  | getch        |
| _chain_intr      | farfree      | getchar      |
| chdir            | farmalloc    | getche       |
| _chdrive         | feof         | getcwd       |
| _chmod           | fflush       | getdate      |
| _clock           | fgets        | _getcwd      |
| chsize           | filelength   | getdfree     |
| close            | fileno       | getdisk      |
| clrscn           | findfirst    | _getdrive    |
| corel            | findnext     | getenv       |
| cprintf          | fnmerge      | getpsp       |
| cputs            | fnsplit      | gets         |
| delay            | fopen        | gettext      |
| disable          | fprintf      | gettextinfo  |
| _dos_findnext    | fputc        | gettime      |
| _dos_getdate     | fputs        | getvect      |
| _dos_getdiskfree | FP_OFF       | gotoxy       |
| _dos_getfileattr | FP_SEG       | _harderr     |
| _dos_gettime     | fread        | _hardresume  |
| _dos_setdate     | free         | _hardretn    |

---

*Tested C Functions (continued)*

|           |                |          |
|-----------|----------------|----------|
| highvideo | qsort          | va_start |
| inport    | read           | vsprintf |
| inportb   | realloc        | wherex   |
| inpw      | remove         | wherey   |
| int86     | scanf          | window   |
| intdosx   | setcursortype  | write    |
| isalpha   | setdate        |          |
| isascii   | settime        |          |
| isctrl    | setvect        |          |
| isdigit   | sleep          |          |
| isprint   | sprintf        |          |
| isspace   | sscanf         |          |
| itoa      | strcat         |          |
| kbhit     | strchr         |          |
| keep      | strcmp         |          |
| lseek     | strcmpi        |          |
| malloc    | strcpy         |          |
| memccpy   | strcspn        |          |
| memcmp    | strlen         |          |
| memcpy    | strncmp        |          |
| memmove   | strncmpi       |          |
| memset    | strncpy        |          |
| min       | strnset        |          |
| MK_FP     | strpbrk        |          |
| open      | strrchr        |          |
| outp      | strstr         |          |
| outportb  | tell           |          |
| outpw     | textbackground |          |
| printf    | textcolor      |          |
| putch     | time           |          |
| puts      | toupper        |          |
| puttext   | va_end         |          |

## ***Intermec C Library Functions***

---

The following pages list the C library functions available in the Programmer's Software Kit (PSK), along with notes on syntax and examples of how the functions can be used. Each function is fully compatible with currently available Microsoft C/C++ and Borland C/C++ compilers.

**Note:** *Do not run programs that use **PSK library functions** on your PC. If you attempt to run these programs without the Simulator, you will receive an error message and the program will not run.*



### **Caution**

***Do not run programs that use Intermec-specific interrupt extensions on your PC. If you attempt to run these programs, they will cause your PC to lock up and possibly corrupt your system BIOS.***

### **Conseil**

***N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.***

## ***C Library Functions Listed by Category***

---

### ***Communications***

im\_cancel\_rx\_buffer, 2-21  
im\_cancel\_tx\_buffer, 2-22  
im\_get\_reboot\_flag, 2-48  
im\_link\_comm, 2-83  
im\_protocol\_extended\_status, 2-94  
im\_ready\_for\_reboot, 2-97  
im\_receive\_buffer, 2-98  
im\_receive\_buffer\_no\_wait, 2-101  
im\_receive\_buffer\_noprot, 2-104  
im\_receive\_byte, 2-107  
im\_receive\_input, 2-109  
im\_rx\_check\_status, 2-114  
im\_serial\_protocol\_control, 2-115  
im\_transmit\_buffer, 2-143  
im\_transmit\_buffer\_no\_wait, 2-145  
im\_transmit\_buffer\_noprot, 2-148  
im\_transmit\_byte, 2-151  
im\_unlink\_comm, 2-153

### ***DCM***

im\_parse\_host\_response, 2-89  
im\_setup\_trx, 2-134  
im\_standard\_trx, 2-139

### ***Display***

im\_backlight\_off, 2-18  
im\_backlight\_on, 2-19  
im\_backlight\_toggle, 2-20  
im\_decrease\_contrast, 2-27  
im\_get\_contrast, 2-31  
im\_get\_display\_mode, 2-34  
im\_get\_display\_type, 2-36  
im\_get\_follow\_cursor, 2-37  
im\_increase\_contrast, 2-55  
im\_set\_contrast, 2-122  
im\_set\_display\_mode, 2-125  
im\_set\_follow\_cursor, 2-128

### ***Input***

im\_get\_input\_mode, 2-39  
im\_get\_label\_symbology, 2-43  
im\_get\_length, 2-45  
im\_input\_status, 2-57  
im\_receive\_byte, 2-107  
im\_receive\_input, 2-109  
im\_set\_input\_mode, 2-129

### ***IRL***

im\_irl\_a, 2-59  
im\_irl\_k, 2-63  
im\_irl\_n, 2-66  
im\_irl\_v, 2-69  
im\_irl\_y, 2-74

### ***Keypad***

im\_get\_control\_key, 2-32  
im\_get\_keyclick, 2-41  
im\_get\_warm\_boot, 2-53  
im\_number\_pad\_off, 2-86  
im\_number\_pad\_on, 2-87  
im\_set\_control\_key, 2-124  
im\_set\_keyclick, 2-131  
im\_set\_warm\_boot, 2-133

### ***Macros***

IM\_ISERROR, 2-79  
IM\_ISGOOD, 2-80  
IM\_ISSUCCESS, 2-81  
IM\_ISWARN, 2-82

### ***Program Control***

im\_appl\_break\_status, 2-16  
im\_clear\_abort\_callback, 2-23  
im\_set\_abort\_callback, 2-118



### **Sound**

im\_sound, 2-137

### **System**

im\_command, 2-24  
im\_get\_postamble, 2-46  
im\_get\_preamble, 2-47  
im\_message, 2-85  
im\_power\_status, 2-91  
im\_rs\_installed, 2-113  
im\_standby\_wait, 2-142

### **Viewport**

im\_cursor\_to\_viewport, 2-26  
im\_get\_config\_info, 2-29  
im\_get\_follow\_cursor, 2-37  
im\_get\_viewport\_lock, 2-51  
im\_set\_follow\_cursor, 2-128  
im\_set\_viewport\_lock, 2-132  
im\_viewport\_end, 2-154  
im\_viewport\_getxy, 2-155  
im\_viewport\_home, 2-156  
im\_viewport\_move, 2-157  
im\_viewport\_page\_down, 2-159  
im\_viewport\_page\_up, 2-160  
im\_viewport\_setxy, 2-161  
im\_viewport\_to\_cursor, 2-165

**Note:** The following syntax descriptions refer to many named constant variables, such as *IM\_COM1*. These variables always appear in uppercase and are described in *IM20LIB.H*.

*im\_appl\_break\_status*

---

## ***im\_appl\_break\_status***

**Purpose:** This function checks whether the application break sequence has been pressed. All PSK functions are terminated when the application break sequence is keyed in.

Place calls to this function at strategic locations in your program to detect when a user wants to break out of a loop. Your program can determine what action to take when the break sequence is detected.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_appl_break_status
    (IM_APPBREAK_STATUS *brk);
```

**IN Parameters:** None.







**OUT Parameters:** The *brk* parameter returns a nonzero value if the break status bit is set and zero if it is not set.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The *brk* flag is reset each time the routine is called. Because this function is also called during the input routines provided in the library, you should check the return code from input functions for the hex value 8515H. This value indicates that the input function has terminated because the application break sequence was entered. In this case, *brk* is cleared by the input function's call to *im\_appl\_break\_status*.

For more information on the application break sequence, refer to your JANUS user's manual.

To enter an application break sequence

1. Press  to turn off the reader.
2. Press  -  -  at the same time.
3. Press . This sets the reader's application break bit.
4. Press  to turn on the reader.

---

**Example**

```
/****** im_appl_break_status *****/
#include <stdio.h>
#include <stdlib.h>
#include <conio.h>
#include "im20lib.h"

void main (void)
{
IM_STATUS          status;
IM_APPBREAK_STATUS brk;

    /* Pause for key stroke */
    while ( !kbhit() )
        ;
    /* To set the break bit: */
    /* Press the following sequence at this pause: */
    /* I/O key (Turn OFF the reader) */
    /* F3+2+Left Arrow (Press F3, 2, and left arrow at the same time) */
    /* 1 (Press the 1 (one) key to set application break bit) */
    /* I/O key (Turn the reader ON) */
    /* Enter key */

    /* Leave the break bit unset: Press any key. */

    /* Set brk to known value */
    brk = 99;

    /* Call Intermec function. Everytime the break bit is checked, it is cleared*/
    status = im_appl_break_status ( &brk);

    if (brk)
    {
        /* brk should return a -1 if bit is set */
        printf ("Break status ON\n");
        printf ("return status: %4X\n", status);
        printf ("break status: %d\n", brk);
    }
    else
    {
        /* brk should return a 0 if bit is not set */
        printf ("Break status OFF\n");
        printf ("return status: %4X\n", status);
        printf ("break status: %d\n", brk);
    }
}
```

**Note:** *Break* is reserved. So, do not name the application *Break.cpp*.

*im\_backlight\_off*

---

## ***im\_backlight\_off***

**Purpose:** This function turns the display backlight off. Turn off the backlight to prolong the reader's battery life.

**Syntax:** `#include <im20lib.h>`  
`void im_backlight_off(void);`

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1-second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** `im_backlight_on`, `im_backlight_toggle`

---

### ***Example***

```
/****** im_backlight_off *****/
#include <stdio.h>
#include "im20lib.h"

void main (void)
{
    im_backlight_off();
    printf("Backlight off\n");
}
```

---

## *im\_backlight\_on*

**Purpose:** This function turns the display backlight on to illuminate the reader display in dimly lit environments.

**Syntax:** `#include <im20lib.h>`  
`void im_backlight_on(void);`

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1-second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** `im_backlight_off`, `im_backlight_toggle`

---

### *Example*

```
/****** im_backlight_on *****/
#include <stdio.h>
#include "im20lib.h"

void main (void)
{
    im_backlight_on();
    printf("Backlight on\n");
}
```

*im\_backlight\_toggle*

---

## ***im\_backlight\_toggle***

**Purpose:** This function toggles the display backlight ON and OFF.

**Syntax:** `#include <im20lib.h>`  
`void im_backlight_toggle(void);`

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You can program the backlight to automatically turn off after a specified time to save battery power. The length of time depends on the backlight timeout configuration parameter. The configuration parameter is set in 1-second increments. The default is 10 seconds.

This function has no effect on the JANUS 2050.

**See Also:** `im_backlight_on`, `im_backlight_off`

---

### ***Example***

```
/****** im_backlight_toggle *****/
#include <stdio.h>
#include "im20lib.h"

void main (void)
{
    im_backlight_toggle();
    printf("Backlight switched on/off\n");
}
```

---

## *im\_cancel\_rx\_buffer*

**Purpose:** This function clears the receive buffer of the designated communications port.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_cancel_rx_buffer
    (IM_COM_PORT port_id);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

If there is no input pending to receive, this function returns 4602H (no client).

**Notes:** You must install a protocol handler to use this function.

**See Also:** im\_receive\_buffer\_no\_wait, im\_receive\_buffer\_noprot

---

### *Example*

See example for im\_receive\_buffer\_no\_wait.

*im\_cancel\_tx\_buffer*

---

## ***im\_cancel\_tx\_buffer***

**Purpose:** This function clears the contents of the transmit buffer for a designated communications port, stops transmission in progress, and resets the communications port.

Use this function with Polling Mode D to clear out the buffer. Other protocols clear the buffer automatically.

You can also use this function to clear a busy port.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_cancel_tx_buffer
    (IM_COM_PORT port_id);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this function.

**See Also:** *im\_transmit\_buffer\_no\_wait*, *im\_transmit\_buffer\_noprot*, *im\_transmit\_buffer*

---

### ***Example***

See example for *im\_transmit\_buffer\_no\_wait*.



---

## ***im\_clear\_abort\_callback***

- Purpose:** This function clears the notification (callback) mode of the Virtual Wedge.
- Syntax:**

```
#include <im20lib.h>
IM_STATUS im_clear_abort_callback(void);
```
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”
- Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.
- See Also:** *im\_set\_abort\_callback*

---

### ***Example***

See example for *im\_set\_abort\_callback*.

*im\_command*

---

## ***im\_command***

**Purpose:** This function modifies the reader's configuration. For example, you can use this function to set a specific communications port's baud rate.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_command
    (IM_UCHAR *command,
     IM_USHORT command_length);
```

**IN Parameters:** The *command* parameter is a reader command string. The command string may include more than one reader command. For example, the command string `%.1$+BV9` turns on the backlight and raises the beep volume.

Reader commands are listed in your JANUS user's manual.

The *command\_length* parameter is the length of the reader command string.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** For more information on using *im\_command*, see your JANUS user's manual.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

---

**Example**

```
/* ***** im_command ***** */
/* Also with: im_standby_wait */

#include <stdio.h>
#include <string.h>
#include "im20lib.h"

void main (void)
{
    /* Command string to set contrast */
    char *high_trast = "$+DJ7"; /* 7 (dark) */
    char *normal_trast = "$+DJ3";
    char *low_trast = "$+DJ0"; /* 0 (light)*/

    /* Set high contrast */
    printf("Set high contrast\n");
    im_command(high_trast, strlen(high_trast));

    /* Wait for two seconds */
    im_standby_wait(2000);

    /* Set low contrast */
    printf("Set low contrast\n");
    im_command(low_trast, strlen(low_trast));

    /* Wait for two seconds */
    im_standby_wait(2000);

    /* Set normal contrast */
    printf("Set normal contrast\n");
    im_command(normal_trast, strlen(normal_trast));
}
```

*im\_cursor\_to\_viewport*

---

## ***im\_cursor\_to\_viewport***

**Purpose:** This function moves the cursor to the center of the current viewport. Since the viewport can move around with or without the cursor, you can use this function to recenter the cursor.

**Syntax:**

```
#include <im20lib.h>
void im_cursor_to_viewport(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** `im_viewport_end`, `im_viewport_home`,  
`im_viewport_page_down`, `im_viewport_page_up`,  
`im_viewport_to_cursor`, `im_viewport_move`

---

### ***Example***

See example for `im_viewport_setxy`.

---

## ***im\_decrease\_contrast***

**Purpose:** This function decreases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast (0 to 31), where 0 is very light, and 31 is very dark.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_decrease_contrast(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The 0 to 31 scale fine tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table compares the two scales.

| This Value on<br>Scale 0 to 7 | Equates to This Value on<br>Scale 0 to 31 | Contrast<br>Level |
|-------------------------------|---|-------------------|
| 0                             | 10  | Very light        |
| 1                             | 12  |                   |
| 2                             | 14  |                   |
| 3                             | 16  |                   |
| 4                             | 18  |                   |
| 5                             | 20  |                   |
| 6                             | 22  | Very dark         |
| 7                             | 24  |                   |

This function has no effect on the JANUS 2050.

**See Also:** `im_increase_contrast`, `im_set_contrast`, `im_get_contrast`

## *im\_decrease\_contrast*

---

### **Example**

```
/****** im_decrease_contrast *****/
#include <stdio.h>
#include "im20lib.h"
#include "immsg.h"

void main (void)
{
    IM_STATUS status;

    status = im_decrease_contrast();

    /* If the most significant bit is set, there is an error */
    if (IM_ISERROR(status))
        printf("Dec Contrast error = %x\n", status);
}
```

---

## ***im\_get\_config\_info***

- Purpose:** This function retrieves the current reader configuration information string and its length.
- Syntax:**
- ```
#include "im20lib.h"
IM_STATUS im_get_config_info
    (IM_UCHAR *config_string,
     IM_USHORT *length);
```
- IN/OUT Parameters:** The *config\_string* parameter is the configuration information string. The first two characters specify the type of configuration information returned.
- For example, to get the beep duration setting, set *config\_string* to "BD." The function returns BD and the current configuration for beep duration.
- The *length* parameter is the length of the configuration information string.
- For a list of the configuration commands, see your JANUS user's manual.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** This function differs from *im\_command* in that you only pass the two-character command identifier. The *im\_command* function passes an entire command string.
- See Also:** *im\_command*

## *im\_get\_config\_info*

---

### **Example**

```
/****** im_get_config_info *****/
#include <stdio.h>
#include <string.h>
#include "im20lib.h"

void main(void)
{
    IM_STATUS status;
    IM_USHORT length;
    IM_UCHAR config_string[128];

    // Use im_get_config_info to get the Beeper Volume
    printf("\nim_get_config_info example: \n");

    // Set config request for Beeper Volume
    strcpy(config_string, "BV");

    status = im_get_config_info(config_string, &length);

    // Print the results
    printf("\nBeeper Volume: %s", config_string);
    printf("\nlength: %d", length);
    printf("\nstatus: %d", status);
}
```



---

## *im\_get\_contrast*

- Purpose:** This function gets the reader's LCD display contrast level. There are eight levels of contrast (0 to 7) from very light to very dark, which are the most frequently used contrast settings.
- Syntax:**
- ```
#include "im20lib.h"
IM_STATUS im_get_contrast
    (IM_UCHAR *display_contrast_level);
```
- IN Parameters:** None.
- OUT Parameters:** The *contrast* parameter is a number from 0 to 7 or is one of these constants:
- ```
IM_MIN_CONTRAST    0  Minimum contrast
IM_MAX_CONTRAST    1  Maximum contrast
```
- Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** The functions *im\_set\_contrast* and *im\_get\_contrast* use a scale of 0 to 7 that is related to the scale of 0 to 31 used by *im\_increase\_contrast* and *im\_decrease\_contrast*. The following table compares the two scales.

| This Value on<br>Scale 0 to 7 | Equates to This Value on<br>Scale 0 to 31 | Contrast<br>Level |
|-------------------------------|-------------------------------------------|-------------------|
| 0                             | 10                                        | Very light        |
| 1                             | 12                                        |                   |
| 2                             | 14                                        |                   |
| 3                             | 16                                        |                   |
| 4                             | 18                                        |                   |
| 5                             | 20                                        |                   |
| 6                             | 22                                        |                   |
| 7                             | 24                                        | Very dark         |

This function has no effect on the JANUS 2050.

- See Also:** *im\_set\_contrast*, *im\_decrease\_contrast*, *im\_increase\_contrast*

---

### *Example*

See example for *im\_set\_contrast*.

*im\_get\_control\_key*

---

## ***im\_get\_control\_key***

**Purpose:** You can enable or disable the **Ctrl** key. This procedure retrieves the current setting.

When you disable this keycode, none of the key combinations that use the **Ctrl** key will work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_control_key
    (IM_CONTROL *control_key);
```

**IN Parameters:** None.

**OUT Parameters:** The *control\_key* parameter is one of these constants:

|            |                             |
|------------|-----------------------------|
| IM_ENABLE  | <b>Ctrl</b> key is enabled  |
| IM_DISABLE | <b>Ctrl</b> key is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_set\_control\_key*

---

**Example**

```
/****** im_get_control_key ******/
/* Also with: im_set_control_key */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "im20lib.h"

void main (void)
{
IM_UCHAR   user_option;
IM_CONTROL old_controlkey;
IM_CONTROL new_controlkey;

    clrscr();                /* Clear screen */
    gotoxy(1,1);            /* Position message */

    /* Get the current status of control key */
    im_get_control_key(&old_controlkey);

    /* Display control key's status */
    if (old_controlkey == IM_ENABLE)
        printf("<CTRL> key enabled!");
    else
        printf("<CTRL> key disabled!");

    /* Get user's input option, 'y' for enabling control key */
    printf("\n\nEnabling <CTRL> key(y)?");
    user_option = getche();
    user_option = toupper(user_option);

    if (user_option == 'Y')
    {
        /* <CTRL> key enable */
        im_set_control_key(IM_ENABLE);
    }
    else
    {
        /* <CTRL> key disable */
        im_set_control_key(IM_DISABLE);
    }

    /* Get new <CTRL> key's status after setting */
    im_get_control_key(&new_controlkey);

    /* Display user's input setting */
    if (new_controlkey == IM_ENABLE)
        printf("\n<CTRL> key enabled!");
    else
        printf("\n<CTRL> key disabled!");

    printf("\nTest it>>\n");
}
```

*im\_get\_display\_mode*

---

## ***im\_get\_display\_mode***

**Purpose:** This function gets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_display_mode
    (IM_STD_SIZE_MODE *size_mode,
     IM_STD_VIDEO_MODE *video_mode,
     IM_SCROLL_MODE *scroll_mode,
     IM_CHARACTER_HEIGHT *char_ht);
```

**IN Parameters:** None.

**OUT Parameters:** The *size\_mode* parameter is required and is one of these constants:

|                    |                                   |
|--------------------|-----------------------------------|
| IM_SIZE_MODE_80X25 | 80 x 25 text mode                 |
| IM_SIZE_MODE_20X16 | 20 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_20X8  | 20 x 8 text mode (2010 and 2020)  |
| IM_SIZE_MODE_10X16 | 10 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_10X8  | 10 x 8 text mode (2010 and 2020)  |

If the *size\_mode* parameter is set to IM\_SIZE\_MODE\_80X25, the video mode, scroll mode, and character height values may have been customized. If any other *size\_mode* is set, the video mode, scroll mode, and character height use the default values.

The *video\_mode* parameter requires IM\_SIZE\_MODE\_80X25. The standard PC BIOS supports up to video mode 13H. The reader only supports up to video mode 6. You can also set video modes 0 through 3 with IC.EXE.

The *video\_mode* parameter is one of these constants:

|                     |                                         |
|---------------------|-----------------------------------------|
| IM_STD_VIDEO_MODE_0 | 40 x 25 (use for double-wide character) |
| IM_STD_VIDEO_MODE_1 | 40 x 25 (use for double-wide character) |
| IM_STD_VIDEO_MODE_2 | 80 x 25                                 |
| IM_STD_VIDEO_MODE_3 | 80 x 25                                 |
| IM_STD_VIDEO_MODE_4 | 300 x 200 2-color                       |
| IM_STD_VIDEO_MODE_5 | 300 x 200 monochrome                    |
| IM_STD_VIDEO_MODE_6 | 640 x 200 2-color (2050)                |

The *scroll\_mode* requires `IM_SIZE_MODE_80X25` and is one of these constants:

|                                  |                                            |
|----------------------------------|--------------------------------------------|
| <code>IM_LCD_SCROLL_AT_25</code> | Scroll at line 25                          |
| <code>IM_LCD_SCROLL_AT_16</code> | Scroll at line 16 (2010 and 2020)          |
| <code>IM_LCD_SCROLL_AT_13</code> | Scroll at line 13 (2050 and double height) |
| <code>IM_LCD_SCROLL_AT_8</code>  | Scroll at line 8 (2010 and 2020)           |

The *char\_ht* parameter requires `IM_SIZE_MODE_80X25` and is one of these constants:

|                                      |                                                                                                                                                              |
|--------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>IM_STANDARD_CHAR_HEIGHT</code> | Standard height characters. On a JANUS 2050, up to 25 lines of these characters fit on the screen. On other JANUS readers, up to 16 lines fit on the screen. |
| <code>IM_DOUBLE_CHAR_HEIGHT</code>   | Double height characters. On a JANUS 2050, up to 13 lines of these characters fit on the screen. On other JANUS readers, up to 8 lines fit on the screen.    |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `im_set_display_mode`

---

**Example**

See example for `im_viewport_setxy`.

*im\_get\_display\_type*

---

## ***im\_get\_display\_type***

**Purpose:** This function gets the hardware display type, either standard JANUS reader or JANUS 2050 (VMU).

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_display_type
    (IM_DISPLAY_TYPE *type);
```

**IN Parameters:** None.

**OUT Parameters:** The *type* parameter is one of these constants:

|              |                        |
|--------------|------------------------|
| IM_LCD_20X16 | Standard JANUS display |
| IM_CRT_80X25 | JANUS VMU display      |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_get\_display\_mode*, *im\_set\_display\_mode*

---

### ***Example***

```
/****** im_get_display_type *****/
#include <stdio.h>
#include <string.h>
#include "im20lib.h"

void main(void)
{
    IM_DISPLAY_TYPE type;
    IM_STATUS status;

    // Use im_get_display_type to get the Display Type
    printf("\nim_get_display_type example: \n");

    status = im_get_display_type(&type);

    // Print the results
    if(type == IM_LCD_20X16)
        // Standard JANUS Display
        printf("\nDisplay type is Standard JANUS display");
    else
        if(type == IM_CRT_80X25)
            // JANUS VMU Display
            printf("\nDisplay type is JANUS VMU display");
}
```

---

## ***im\_get\_follow\_cursor***

**Purpose:** When the display is in 80 x 25 mode, the viewport follows the cursor as it moves. The follow-the-cursor feature can be enabled or disabled. This function retrieves the current setting.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_follow_cursor
    (IM_CONTROL *follow_cursor);
```

**IN Parameters:** None.

**OUT Parameters:** The *follow\_cursor* parameter is one of these constants:

|            |                                    |
|------------|------------------------------------|
| IM_ENABLE  | Follow-the-cursor mode is enabled  |
| IM_DISABLE | Follow-the-cursor mode is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** *im\_set\_follow\_cursor*, *im\_cursor\_to\_viewport*, *im\_viewport\_to\_cursor*

## *im\_get\_follow\_cursor*

---

### **Example**

```
/****** im_get_follow_cursor *****/
/* Also with: im_set_follow_cursor */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "im20lib.h"

#define ESC_CHAR 0x1B

void main (void)
{
    IM_UCHAR    ch,
               user_option;
    IM_CONTROL  old_lock_cursor;
    IM_CONTROL  new_lock_cursor;

    clrscr();          /* Clear screen */
    gotoxy(1,1);      /* Position message */

    /* Get the current status of viewport follow cursor for restore later */
    im_get_follow_cursor(&old_lock_cursor);

    /* Get user's input option, 'y' for disable viewport follow cursor */
    printf("Enable viewport\nfollows cursor(y)?");
    user_option = getche();
    user_option = toupper(user_option);

    if (user_option == 'Y')
    {
        /* Enable viewport follow cursor */
        im_set_follow_cursor(IM_ENABLE);
    }
    else
    {
        /* Disable viewport follow cursor */
        im_set_follow_cursor(IM_DISABLE);
    }

    /* Get new viewport follow cursor status after setting */
    im_get_follow_cursor(&new_lock_cursor);

    /* Display user's input message */
    printf("\n\n'ESC' to quit!\nType keys to check\n");
    printf("viewport follow\n");

    if (new_lock_cursor == IM_ENABLE)
        printf("cursor ON !!!!!");
    else
        printf("cursor OFF !!!!!");

    /* Enter any characters to check viewport follow cursor until 'ESC' key. */
    while ( (ch = getche()) != ESC_CHAR )
        ;

    /* Restore original follow cursor setting */
    im_set_follow_cursor(old_lock_cursor);
}
```



---

## *im\_get\_input\_mode*

**Purpose:** This function reports the current mode of the input manager. The different modes affect how the reader interprets and stores input.

**Syntax:**

```
#include <im20lib.h>
IM_MODE im_get_input_mode (void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** The IM\_MODE returned is one of these constants:

|               |                 |
|---------------|-----------------|
| IM_WEDGE      | Wedge mode      |
| IM_PROGRAMMER | Programmer mode |
| IM_DESKTOP    | Desktop mode    |

**Notes:** There are three different reader input modes: Wedge, Programmer, and Desktop. These different modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label inputs go into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. Use Wedge mode when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader's power management capabilities. You will probably notice reduced battery life when the reader is in this mode compared to either Programmer or Desktop mode. For more information on power management, see Chapter 4, "Advanced Programming."

**Programmer Mode** Inputs are echoed to the screen. Reader commands are executed and saved. Use Programmer mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in Programmer mode.

*im\_get\_input\_mode*

**Desktop Mode** The application is responsible for retrieving and displaying input. Use Desktop mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes for the keyboard flags (**Shift**, **Ctrl**, **Alt**). See the structure `IM_KEYCODE` in `IM20LIB.H` for further details.

For more information about reader input modes, see Chapter 4, “Advanced Programming.”

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

**See Also:** `im_set_input_mode`

---

**Example**

See example for `im_receive_input`.

---

## ***im\_get\_keyclick***

**Purpose:** You can configure the reader to emit a click each time a key is pressed. This function returns the current setting (enabled or disabled) of the keyclick.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_keyclick
    (IM_CONTROL *keyclick);
```

**IN Parameters:** None.

**OUT Parameters:** The *keyclick* parameter is one of these constants:

|            |                      |
|------------|----------------------|
| IM_ENABLE  | Keyclick is enabled  |
| IM_DISABLE | Keyclick is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_set\_keyclick*

## *im\_get\_keyclick*

---

### **Example**

```
/****** im_get_keyclick *****/
/* Also with: im_set_keyclick */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "im20lib.h"

void main (void)
{
    IM_UCHAR    user_option;
    IM_CONTROL  old_keyclick;
    IM_CONTROL  new_keyclick;

    clrscr();                /* Clear screen */
    gotoxy(1,1);            /* Position message */

    /* Get the current status of keypad clicker */
    im_get_keyclick(&old_keyclick);

    /* Display keypad clicker's status */
    if (old_keyclick == IM_ENABLE)
        printf("Keypad clicker ON!");
    else
        printf("Keypad clicker OFF!");

    /* Get user's input option, 'y' for enabling keypad clicker */
    printf("\n\nEnabling keyclick(y)?");
    user_option = getche();
    user_option = toupper(user_option);

    if (user_option == 'Y')
    {
        /* Keypad clicker enable */
        im_set_keyclick(IM_ENABLE);
    }
    else
    {
        /* Keypad clicker disable */
        im_set_keyclick(IM_DISABLE);
    }

    /* Get new keypad clicker's status after setting */
    im_get_keyclick(&new_keyclick);

    /* Display user's input setting */
    if (new_keyclick == IM_ENABLE)
        printf("\nKeypad clicker ON!");
    else
        printf("\nKeypad clicker OFF!");

    printf("\nTest it>>\n");
}

```

---

## *im\_get\_label\_symbology*

**Purpose:** This function gets the symbology, such as Code 39, from the most recently scanned label. Call this function after receiving the data using `im_receive_input`.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_label_symbology
    (IM_DECTYPE *symbology);
```

**IN Parameters:** None.

**OUT Parameters:** The *symbology* parameter is one of these constants:

|                   |                        |
|-------------------|------------------------|
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_CODABAR        | Codebar bar code       |
| IM_CODE_11        | Code 11 bar code       |
| IM_CODE_16K       | Code 16K bar code      |
| IM_CODE_39        | Code 39 bar code       |
| IM_CODE_49        | Code 93 bar code       |
| IM_CODE_93        | Code 49 bar code       |
| IM_CODE_128       | Code 128 bar code      |
| IM_I_2_OF_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PDF_417        | PDF417 bar code        |
| IM_PLESSEY        | Plessey bar code       |
| IM_UPC            | Universal Product Code |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** `im_receive_input`

## *im\_get\_label\_symbology*

---

### **Example**

```
/****** im_get_label_symbology *****/
/* im_receive_input */
/* im_set_input_mode */

#include <stdio.h>
#include <conio.h>
#include "im20lib.h"
#include "immsg.h"

static char *bar_code[] = {
    "unknown",
    "Code 39",          /* See typedef enum { ... } IM_DECTYPE in im20lib.h*/
    "Code 93",
    "Code 49",
    "I 2 of 5",
    "Codabar",
    "UPC and EAN",
    "Code 128",
    "Code 16K",
    "Plessey/Anker",
    "Code 11",
    "MSI",
    "PDF417"
};

void main (void)
{
    IM_UCHAR   input[256];
    IM_ORIGIN  source;
    IM_DECTYPE symbol;

    window(1, 1, 20, 16);      /* Set the application text window */
    clrscr();                  /* Clear the screen */

    printf("Demo im_get_label_symbology\n'q' to quit\n");

    /* Set Reader Wedge into PROGRAMMER mode */
    im_set_input_mode(IM_PROGRAMMER);

    /* Input loop */
    do
    {
        source = IM_LABEL_SELECT | IM_KEYBOARD_SELECT;

        /* Request input from Reader Wedge */
        im_receive_input(source, IM_INFINITE_TIMEOUT, &source, input);

        /* Get most recently read label input
         * im_get_label_symbology only works with im_receive_input */
        im_get_label_symbology(&symbol);

        printf("\n%s\n", input);      /* Display input data */

        /* Display symbology */
        printf("\nSYMBOLGY: %d\n%s\n", symbol, bar_code[symbol]);
    } while (input[0] != 'q' && input[0] != 'Q'); /* 'q' to quit */

    /* Switch the Reader Wedge back to virtual wedge mode */
    im_set_input_mode(IM_WEDGE);
}

```

---

## *im\_get\_length*

**Purpose:** This function returns the length of the string received from the designated source by the most recent `im_receive_input` function.

**Syntax:**

```
#include "im20lib.h"
IM_USHORT im_get_length
    (IM_ORIGIN source);
```

**IN Parameters:** The *source* parameter is one of these constants:

|                    |                                             |
|--------------------|---------------------------------------------|
| IM_LABEL_SELECT    | Label selected                              |
| IM_KEYBOARD_SELECT | Keypad selected                             |
| IM_COM1_SELECT     | COM1 selected                               |
| IM_COM2_SELECT     | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)                     |

**OUT Parameters:** None.

**Return Value:** This function returns the length of the last input string read from the designated source.

**Notes:** All input using `im_receive_input` has a null termination character added to the end of the string so that it can be used as a normal C string. However, some data might contain embedded null characters. If so, this function supplies the true data length.

For this function, all COM input is considered to be from the same source. For example, if you call `im_receive_input` with `IM_COM1_SELECT` and again with `IM_COM4_SELECT`, then a call to `im_get_length` with a source of `IM_COM1_SELECT` returns the length of the message received from COM4 because that was the last message read from a communications port.

You must install the Reader Wedge to use this function. For information on loading `RWTSR.EXE`, see “Runtime Requirements” earlier in this chapter.

**See Also:** `im_receive_input`

---

### *Example*

See example for `im_receive_input`.

*im\_get\_postamble*

---

## ***im\_get\_postamble***

**Purpose:** This function retrieves the currently configured postamble string and its length.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_postamble
    (IM_UCHAR *post_string,
     IM_USHORT *length);
```

**IN Parameters:** None.

**OUT Parameters:** The *post\_string* parameter is the postamble string.

The *length* parameter is the length of the postamble string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You can set the postamble with IC.EXE, with the *im\_command* function and \$+AE command, or by scanning a postamble. Refer to your JANUS user's manual for more information on configuring a postamble.

**See Also:** *im\_get\_postamble*, *im\_get\_config\_info*

---

### ***Example***

```
/****** im_get_postamble *****/
#include <stdio.h>
#include <string.h>
#include "im20lib.h"

void main(void)
{
    IM_STATUS status;
    IM_USHORT length;
    IM_UCHAR post_string[128];

    // Use im_get_postamble to get the Postamble string
    printf("\nim_get_postamble example: \n");

    status = im_get_postamble(post_string, &length);

    // Print the results
    printf("\nPostamble: %s", post_string);
    printf("\nlength : %d", length);
    printf("\nstatus : %d\n", status);
}
```



---

## *im\_get\_preamble*

- Purpose:** This function retrieves the currently configured preamble string and its length.
- Syntax:**
- ```
#include "im20lib.h"
IM_STATUS im_get_preamble
    (IM_UCHAR *pre_string,
     IM_USHORT *length);
```
- IN Parameters:** None.
- OUT Parameters:** The *pre\_string* parameter is the preamble string.  
The *length* parameter is the length of the preamble string.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** You can set the preamble with IC.EXE, with the *im\_command* function and \$+AE command, or by scanning a preamble. Refer to your JANUS user's manual for more information on configuring a preamble.
- See Also:** *im\_get\_postamble*, *im\_get\_config\_info*

---

### *Example*

```
/****** im_get_preamble *****/
#include <stdio.h>
#include <string.h>
#include "im20lib.h"

void main(void)
{
    IM_STATUS status;
    IM_USHORT length;
    IM_UCHAR pre_string[128];

    // Use im_get_preamble to get the Preamble string
    printf("\nim_get_preamble example: \n");

    status = im_get_preamble(pre_string, &length);

    // Print the results
    printf("\nPreamble: %s", pre_string);
    printf("\nlength : %d", length);
    printf("\nstatus : %d", status);
}
```

*im\_get\_reboot\_flag*

---

## ***im\_get\_reboot\_flag***

**Purpose:** This function determines if the reader received a “Prepare For Reboot” command (..+%1) from a host for binary file transfer (BFT). Your application should periodically check if it has received a “Prepare for Reboot” command.

**Syntax:**

```
#include "im20lib.h"
IM_USHORT im_get_reboot_flag( )
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the following:

- 1 “Prepare for Reboot” (..+%1) has been received from the host.
- 0 “Prepare for Reboot” (..+%1) has not been received from the host.  
*or*  
“Cancel Reboot Preparation” (..+%0) has been received from the host.

**Notes:** When a host initiates a BFT, the JANUS reader must reboot with a server session open to establish a transfer session. The application should close any open files and perform cleanup tasks before rebooting.

Input functions such as `im_receive_input` terminate when the “Prepare for Reboot” command is received. The application should check the return status from input functions to determine if “Prepare for Reboot” terminated the input function.

**See Also:** `im_ready_for_reboot`

**Example**

```

/*****im_get_reboot_flag*****/
#include <conio.h>
#include <stdio.h>
#include "im20lib.h"
void main (void)
{
    char    inString[300];        // Buffer used by application
    char    comString[300];      // Buffer used by comm utilities
    int     done = 0;
    int     length;
    int     valid_source;
    IM_USHORT status;
    IM_USHORT reboot_flag;
    IM_ORIGIN source;
    IM_DECTYPE symbology;

    /* FUNCTION BODY */

    clrscr();
    im_set_input_mode(IM_PROGRAMMER);
    im_set_display_mode(IM_SIZE_MODE_20X16,
                       IM_STD_VIDEO_MODE_3,
                       IM_LCD_SCROLL_AT_16,
                       IM_STANDARD_CHAR_HEIGHT);
    im_link_comm(IM_COM1, comString, 300);
    while (!done) {
        valid_source = 1;        // assume source will be valid
        printf("\nEnter>>");
        printf("\nPress Q to quit>>");
        status = im_receive_input(IM_ALL_SELECT,
                                 IM_INFINITE_TIMEOUT,
                                 &source,
                                 inString);
        printf("\nStatus>%4x",status);
        if (source == IM_KEYBOARD_SELECT) {
            printf("\nFrom Keyboard");
        }
        else if (source == IM_LABEL_SELECT) {
            printf("\nFrom Label");
            im_get_label_symbology(&symbology);
            if (symbology == IM_CODE_39) {
                printf("\nCode 39");
            }
            else {
                printf("\nWrong code!");
            }
        }
        else if (source == IM_COM1_SELECT) {
            printf("\nFrom Serial");
        }
        else {
            printf("\nUnknown source");    // Source = Unknown if reboot
                                           // command or abort command
                                           // received
            valid_source = 0;
        }
        if (valid_source) {
            length = im_get_length(source);
            printf("\nRecvd>>%s",inString);
        }
    }
}

```

### *im\_get\_reboot\_flag*

```
        printf("\nLength>%d",length);
        if (inString[0] == 'Q' || inString[0] == 'q')
            done = 1;
    }
    else {
        reboot_flag = im_get_reboot_flag();
        if (reboot_flag) {
            printf("\nReboot flag is set");
            status = im_ready_for_reboot(IM_TRUE);
        }
        else {
            printf("\nReboot flag not set");
            status = im_ready_for_reboot(IM_FALSE);
        }
    }
}
im_unlink_comm(IM_COM1);
im_set_display_mode(IM_SIZE_MODE_80X25,
                    IM_STD_VIDEO_MODE_3,
                    IM_LCD_SCROLL_AT_16,
                    IM_STANDARD_CHAR_HEIGHT);
im_set_input_mode(IM_WEDGE);
}
```

---

## ***im\_get\_viewport\_lock***

**Purpose:** This function retrieves the current setting of the viewport lock. When the display is in 80 x 25 mode, you can use the viewport in virtual display mode unless the currently running application program restricts it. The application program may require the viewport to be locked or unlocked.

The viewport lock only affects the user's ability to move the viewport with the viewport control keys.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_viewport_lock
    (IM_CONTROL *viewport_lock);
```

**IN Parameters:** None.

**OUT Parameters:** The *viewport\_lock* parameter is one of these constants:

|            |                      |
|------------|----------------------|
| IM_ENABLE  | Viewport is locked   |
| IM_DISABLE | Viewport is unlocked |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The display must be in 80 x 25 mode (see *im\_set\_display\_mode*) to use this function.

This function has no effect on the JANUS 2050.

When the viewport is "locked," the viewport movement keys do not move the viewport. The viewport can still move if follow-the-cursor mode is enabled.

**See Also:** *im\_set\_viewport\_lock*, *im\_set\_display\_mode*, *im\_get\_display\_mode*, *im\_get\_follow\_cursor*, *im\_set\_follow\_cursor*

## *im\_get\_viewport\_lock*

---

### **Example**

```
/****** im_get_viewport_lock *****/
/* Also with: im_set_viewport_lock */

#include <stdio.h>
#include <conio.h>
#include <ctype.h>
#include <stdlib.h>
#include "im20lib.h"

#define ESC_CHAR 0x1B

void main (void)
{
    IM_UCHAR    ch,
               user_option;
    IM_CONTROL  current_viewport_lock;

    clrscr();                /* Clear screen */

    /* Get the current status of viewport lock for restore later */
    im_get_viewport_lock(&current_viewport_lock);

    /* Get user's input option, 'y' for disable viewport lock */
    printf("\nEnable viewport\nlock(y)?");
    user_option = toupper( getch());

    if (user_option == 'Y')
    {
        /* Enable viewport lock */
        im_set_viewport_lock(IM_ENABLE);
        printf("\n\n'ESC' to quit!\nType _f and arrow keys\n");
        printf("See viewport lock!");
    }
    else
    {
        /* Disable viewport lock */
        im_set_viewport_lock(IM_DISABLE);
        printf("\n\n'ESC' to quit!\nType _f and arrow keys\n");
        printf("See viewport unlock!");
    }

    /* Enter characters loop to check viewport movement until 'ESC' key. */
    while ( (ch = getch()) != ESC_CHAR )
        putchar(ch);

    /* Restore viewport lock */
    im_set_viewport_lock(current_viewport_lock);
}
```

---

## *im\_get\_warm\_boot*

**Purpose:** This function retrieves the current setting of the warm boot status flag. You can enable or disable the **Ctrl-Alt-Del** warm boot key sequence. When disabled, pressing the **Ctrl-Alt-Del** sequence does not reboot the reader.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_get_warm_boot
    (IM_CONTROL *warm_boot);
```

**IN Parameters:** None.

**OUT Parameters:** The *warm\_boot* parameter is one of these constants:

|            |   |
|------------|---|
| IM_ENABLE  | <b>Ctrl-Alt-Del</b> warm boot is enabled  |
| IM_DISABLE | <b>Ctrl-Alt-Del</b> warm boot is disabled |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_set\_warm\_boot*

## *im\_get\_warm\_boot*

---

### **Example**

```
/****** im_get_warm_boot ******/
/* Also with: im_set_warm_boot */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "im20lib.h"

void main (void)
{
    IM_UCHAR    user_option;
    IM_CONTROL  old_warmboot;
    IM_CONTROL  new_warmboot;

    clrscr();                /* Clear screen */
    gotoxy(1,1);            /* Position message */

    /* Get the current status of warn boot */
    im_get_warm_boot(&old_warmboot);

    /* Display warm boot's status */
    if (old_warmboot == IM_ENABLE)
        printf("Warm boot enabled!");
    else
        printf("Warn boot disabled!");

    /* Get user's input option, 'y' for enabling warm boot */
    printf("\n\nEnable warmboot(y)?");
    user_option = getche();
    user_option = toupper(user_option);

    if (user_option == 'Y')
    {
        /* Warm boot enable */
        im_set_warm_boot(IM_ENABLE);
    }
    else
    {
        /* Warm boot disable */
        im_set_warm_boot(IM_DISABLE);
    }

    /* Get new warm boot's status after setting */
    im_get_warm_boot(&new_warmboot);

    /* Display user's input setting */
    if (new_warmboot == IM_ENABLE)
        printf("\nwarm boot enabled!");
    else
        printf("\nWarm boot disabled!");

    printf("\nTest it>>\n");
    getch();
}
```



---

## ***im\_increase\_contrast***

- Purpose:** This function increases the LCD display contrast by one level. The display contrast is the lightness or darkness of the characters against the reader display. The reader display has 32 levels of contrast, where 0 is very light, and 31 is very dark.
- Syntax:**

```
#include <im20lib.h>
IM_STATUS im_increase_contrast(void);
```
- IN Parameters:** None.
- OUT Parameters:** None.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”
- Notes:** The 0 to 31 scale fine-tunes the contrast more precisely than using the keypad to adjust the contrast.

The functions `im_set_contrast` and `im_get_contrast` use a scale of 0 to 7 that is related to the scale of 0 to 31 used by `im_increase_contrast` and `im_decrease_contrast`. The following table compares the two scales.

| This Value on<br>Scale 0 to 7 | Equates to This Value on<br>Scale 0 to 31 | Contrast<br>Level |
|-------------------------------|---|-------------------|
| 0                             | 10  | Very light        |
| 1                             | 12  |                   |
| 2                             | 14  |                   |
| 3                             | 16  |                   |
| 4                             | 18  |                   |
| 5                             | 20  |                   |
| 6                             | 22  | Very dark         |
| 7                             | 24  |                   |

This function has no effect on the JANUS 2050.

- See Also:** `im_get_contrast`, `im_decrease_contrast`, `im_set_contrast`

## *im\_increase\_contrast*

---

### **Example**

```
/****** im_increase_contrast *****/
#include <stdio.h>
#include "im20lib.h"
#include "immsg.h"

void main (void)
{
    IM_STATUS status;
    status = im_increase_contrast();
    /* If the most significant bit is set, there is an error */
    if (IM_ISERROR(status))
        printf("Inc Contrast error = %x\n", status);
}
```

---

## *im\_input\_status*

**Purpose:** This function checks to see if any input buffers have data and returns the buffer identification.

**Syntax:**

```
#include <im20lib.h>
IM_ORIGIN im_input_status (void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** IM\_ORIGIN is one or more of these constants:

|                    |   |
|--------------------|---|
| IM_NO_SELECT       | No input buffer selected                    |
| IM_LABEL_SELECT    | Label selected                              |
| IM_KEYBOARD_SELECT | Keypad selected                             |
| IM_COM1_SELECT     | COM1 selected                               |
| IM_COM2_SELECT     | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)                     |
| IM_ALL_SELECT      | All input buffers are selected              |

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** im\_receive\_input

## *im\_input\_status*

---

### **Example**

```
/****** im_input_status *****/
/* Also with: im_receive_input */
/* im_get_length */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include "im20lib.h"
#include "immsg.h"

void main (void)
{
IM_UCHAR   input[300];
IM_MODE    original_mode;
IM_ORIGIN  source;
IM_STATUS  status;

    window(1, 1, 20, 16);      /* Set the application text window */
    clrscr();                  /* Clear the screen */

    printf("Demo im_input_status\n");

    /* Get the previous input mode for restoring input mode later */
    original_mode = im_get_input_mode();

    /* Set Reader Wedge mode to program interface */
    im_set_input_mode(IM_DESKTOP);

    /* Loop until some input */
    while ( (source = im_input_status()) == IM_NO_SELECT)
        ;

    /* See where the input comes from */
    if ( source == IM_COM1_SELECT)
        printf("COM1 input:");
    else
        printf("COM4 input:");

    /* Request input from source */
    status = im_receive_input(source, IM_INFINITE_TIMEOUT, &source, input);

    if ( IM_ISGOOD(status) )
        printf("\n%s\n", input);      /* Display input data */
    else /* input error */
    {
        printf("\n");
        im_message(status);
    }

    /* Restore original input mode */
    im_set_input_mode(original_mode);
}
```

---

## *im\_irl\_a*

**Purpose:** This function returns input from bar code labels or the keypad in the same manner as IRL ASCII input command A. This function returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command A, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_irl_a
    (IM_USHORT timeout,
     IM_LENGTH_SPEC test_table[],
     IM_UCHAR mask_string[],
     IM_UCHAR *instring,
     IM_USHORT *cmd_count,
     IM_DECTYPE *symbology);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *test\_table*. The *test\_table* parameter must be a matrix of the following form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

*im\_irl\_a*

The *a* position in the matrix is one of the following:

|              |                                    |
|--------------|------------------------------------|
| IM_NO_LENGTH | Accept data of any length          |
| IM_LENGTH    | Accept data with a specific length |
| IM_RANGE     | Accept data within a length range  |

If IM\_LENGTH is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If IM\_RANGE is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {IM\_NO\_LENGTH,0,0,0}.

The *mask\_string* parameter sets up a data mask that received data must match. *mask\_string* can accept a string of constants or wildcard characters. For example, use the string ### - #### to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

|                |                        |
|----------------|------------------------|
| #              | Numeric                |
| @              | Alpha                  |
| ?              | Alphanumeric printable |
| NULL (CHRS(0)) | No mask                |

**OUT Parameters:** The *instring* parameter is the input string. You must allocate at least 256 bytes for *instring*.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *symbology* parameter is one of these constants:

|                   |                        |
|-------------------|------------------------|
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_CODABAR        | Codabar bar code       |
| IM_CODE_11        | Code 11 bar code       |
| IM_CODE_16K       | Code 16K bar code      |
| IM_CODE_39        | Code 39 bar code       |
| IM_CODE_49        | Code 93 bar code       |
| IM_CODE_93        | Code 49 bar code       |
| IM_CODE_128       | Code 128 bar code      |
| IM_I_2_OF_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PDF_417        | PDF 417 bar code       |
| IM_PLESSEY        | Plessey bar code       |
| IM_UPC            | Universal Product code |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with `im_set_input_mode`.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `im_set_display_mode`.

**See Also:** `im_irl_k`, `im_irl_n`, `im_irl_v`, `im_irl_y`, `im_set_display_mode`, `im_set_input_mode`

## im\_irl\_a

---

### Example

```
/****** im_irl_a *****/
/* Also with: im_set_input_mode */
/* im_standby_wait */

#include <stdio.h>
#include <conio.h>
#include "im20lib.h"

IM_LENGTH_SPEC length_table[IM_LENGTH_SPEC_MAX] = {
    {IM_LENGTH, 0, 0, 2},
    {IM_RANGE, 7, 10, 0},
    {IM_LENGTH, 0, 0, 4},
    {IM_RANGE, 15, 17, 0},
    {IM_LENGTH, 0, 0, 6}
};

IM_UCHAR ssn_mask[] = "###-##-####";

void main (void)
{
    IM_UCHAR input[256];
    IM_USHORT cc;
    IM_DECTYPE symbol;

    window(1, 1, 20, 16); /* Set the application text window */
    clrscr(); /* Clear the screen */

    printf("Demo IRL A Bar Code\n");
    printf(" '9' = 1st char to quit\n");
    printf(" Example: '933-11-3333' \n");

    /* Set Reader Wedge into PROGRAMMER mode */
    im_set_input_mode(IM_PROGRAMMER);

    /* Input loop */
    do
    {
        /* Test wait for 5 seconds */
        printf("Start waiting for 5 seconds\n");
        im_standby_wait(5000);
        printf("Done waiting for 5 seconds\n");

        /* Display IRL A mask pattern */
        printf("IRL A test mask\n");
        printf(" = %s\n", ssn_mask);

        /* Request input from Reader Wedge */
        im_irl_a(IM_INFINITE_TIMEOUT, length_table,
                ssn_mask, input, &cc, &symbol);

        printf("\n%s\n", input);
    } while (input[0] != '9'); /* '9' to quit */

    /* Switch the Reader Wedge back to virtual wedge mode */
    im_set_input_mode(IM_WEDGE);
}
```



---

## *im\_irl\_k*

**Purpose:** This function receives input from the keypad in any format in the same manner as IRL ASCII input command K. This function returns the input data to the buffer, edits reader commands, and displays input data. For more information on IRL and command K, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_irl_k
    (IM_USHORT timeout,
     IM_LENGTH_SPEC test_table[],
     IM_UCHAR mask_string[],
     IM_UCHAR *instring,
     IM_USHORT *cmd_count);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *test\_table*. The *test\_table* parameter must be a matrix of the following form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

*im\_irl\_k*

The *a* position in the matrix is one of the following:

|              |                                   |
|--------------|-----------------------------------|
| IM_NO_LENGTH | Accept data of any length         |
| IM_LENGTH    | Accept data of a specific length  |
| IM_RANGE     | Accept data within a length range |

If IM\_LENGTH is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If IM\_RANGE is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {IM\_NO\_LENGTH,0,0,0}.

The *mask\_string* parameter sets up a data mask that received data must match. *mask\_string* can accept a string of constants or wildcard characters. For example, use the string ### - #### to accept only phone numbers.

You can use one or more of these wildcard characters to define the mask:

|                |                        |
|----------------|------------------------|
| #              | Numeric                |
| @              | Alpha                  |
| ?              | Alphanumeric printable |
| NULL (CHRS(0)) | No mask                |

**OUT Parameters:** The *instring* parameter is the input string. You must allocate at least 256 bytes for *instring*.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must set the reader to Programmer mode with *im\_set\_input\_mode*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using *im\_set\_display\_mode*.

**See Also:** im\_irl\_a, im\_irl\_n, im\_irl\_v, im\_irl\_y, im\_set\_display\_mode,  
im\_set\_input\_mode

---

### Example

```

/***** im_irl_k *****/
/* Also with: im_set_input_mode and im_standby_wait */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "im20lib.h"

IM_LENGTH_SPEC length_table[IM_LENGTH_SPEC_MAX] = {
    {IM_LENGTH, 0, 0, 2},
    {IM_RANGE, 7, 10, 0},
    {IM_LENGTH, 0, 0, 4},
    {IM_RANGE, 15, 17, 0},
    {IM_LENGTH, 0, 0, 6}
};

IM_UCHAR mix_mask[] = "?#@#";

void main (void)
{
    IM_UCHAR input[256];
    IM_USHORT cc;

    window(1, 1, 20, 16); /* Set the reader services text window */
    clrscr(); /* Clear the screen */
    printf("Demo IRL K Bar Code\n");
    printf(" 'Q' = 1st char to quit\n");
    printf("Example: 'Q1q2' \n");

    /* Set Reader Wedge into PROGRAMMER mode */
    im_set_input_mode(IM_PROGRAMMER);

    /* Input loop --Display IRL K mask pattern */
    do
    {
        printf("IRL K test mask:\n");
        printf(" = %s \n", mix_mask);
        printf("Example: 'A5a3' \n");

        /* Request input from Reader Wedge */
        im_irl_k(IM_INFINITE_TIMEOUT, length_table,
            mix_mask, input, &cc);

        printf("\n%s\n", input);

        /* Upper case first char of input for testing quit */
        input[0] = toupper(input[0]);
    } while (input[0] != 'Q'); /* 'Q' to quit */

    /* Switch the Reader Wedge back to virtual wedge mode */
    im_set_input_mode(IM_WEDGE);
}

```

*im\_irl\_n*

---

## ***im\_irl\_n***

**Purpose:** This function receives numeric input from the keypad or a label in the same manner as IRL numeric input command N. Nonnumeric data is ignored.

This function clears any data existing in the keypad or label buffers before the function was called, edits reader commands from input, and displays input data. For more information on IRL and command N, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_irl_n
    (IM_USHORT timeout,
     IM_LENGTH_SPEC test_table[],
     IM_UCHAR *instring,
     IM_USHORT *cmd_count,
     IM_DECTYPE *symbology);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

Data is returned only if its length matches one of the five lengths specified in the *test\_table*. The *test\_table* parameter must be a matrix of the following form:

```
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
{a, b, c, d},
```

The *a* position in the matrix is one of the following:

|              |                                   |
|--------------|-----------------------------------|
| IM_NO_LENGTH | Accept data of any length         |
| IM_LENGTH    | Accept data of a specific length  |
| IM_RANGE     | Accept data within a length range |

If IM\_LENGTH is specified in the *a* position, the actual length of the data string is placed in the *d* position (and *b* and *c* are not used).

If IM\_RANGE is specified in the *a* position, the data length must be within the range of *b* and *c* (and *d* is not used).

Set any unused table entries to {IM\_NO\_LENGTH,0,0,0}.

**OUT Parameters:** The *instring* parameter is the input string. You must allocate at least 256 bytes for *instring*.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *symbology* parameter is one of these constants:

|                   |                        |
|-------------------|------------------------|
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_CODABAR        | Codabar bar code       |
| IM_CODE_11        | Code 11 bar code       |
| IM_CODE_16K       | Code 16K bar code      |
| IM_CODE_39        | Code 39 bar code       |
| IM_CODE_49        | Code 93 bar code       |
| IM_CODE_93        | Code 49 bar code       |
| IM_CODE_128       | Code 128 bar code      |
| IM_I_2_OF_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PDF_417        | PDF 417 bar code       |
| IM_PLESSEY        | Plessey bar code       |
| IM_UPC            | Universal Product code |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must set the reader to Programmer mode with *im\_set\_input\_mode*.

## *im\_irl\_n*

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `im_set_display_mode`.

**See Also:** `im_irl_a`, `im_irl_k`, `im_irl_v`, `im_irl_y`, `im_set_input_mode`

---

### *Example*

```
/****** im_irl_n *****/
#include <stdio.h>
#include <conio.h>
#include "im20lib.h"

IM_LENGTH_SPEC length_table[IM_LENGTH_SPEC_MAX] = {
    {IM_LENGTH, 0, 0, 2},
    {IM_RANGE, 7, 10, 0},
    {IM_LENGTH, 0, 0, 4},
    {IM_RANGE, 15, 17, 0},
    {IM_LENGTH, 0, 0, 6}
};

void main (void)
{
    IM_UCHAR   input[256];
    IM_USHORT  cc;
    IM_DECTYPE symbol;

    window(1, 1, 20, 16);      /* Set the reader services text window */
    clrscr();                  /* Clear the screen */
    printf("Demo IRL N Bar Code\n");
    printf(" '9' to quit\n");

    /* Set Reader Wedge mode to program interface */
    im_set_input_mode(IM_PROGRAMMER);

    /* Input loop */
    do
    {
        /* Display IRL N test */
        printf("IRL N test\n");

        /* Request input from Reader Wedge */
        im_irl_n(IM_INFINITE_TIMEOUT, length_table,
                input, &cc, &symbol);

        printf("\n%s\n", input);
    } while (input[0] != '9');    /* '9' to quit */

    /* Switch the Reader Wedge back to virtual wedge mode */
    im_set_input_mode(IM_WEDGE);
}
```

---

## *im\_irl\_v*

**Purpose:** This function receives input from any specified source in any format, in the same manner as an IRL universal input command V. For more information on IRL and command V, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_irl_v
    (IM_USHORT timeout,
     IM_CONTROL edit,
     IM_LABEL_BEEP_CONTROL beep,
     IM_CONTROL display,
     IM_ORIGIN *source,
     IM_UCHAR *instring,
     IM_USHORT *cmd_count,
     IM_DECTYPE *symbology);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

The *edit* parameter determines whether the Reader Wedge parses reader commands. Use one of these constants:

|            |                                |
|------------|--------------------------------|
| IM_DISABLE | Disable reader command parsing |
| IM_ENABLE  | Enable reader command parsing  |

If *edit* is IM\_DISABLED, reader commands are treated as data.

## *im\_irl\_v*

The *beep* parameter determines whether the IRL V command beeps or not when data is entered.

If *beep* is set to IM\_APPLI\_BEEP, the Reader Wedge does not control the beep. Instead, you code the application to sound a beep when your program design requires one.

If *beep* is set to IM\_WEDGE\_BEEP, the reader always beeps when data is entered. The *beep* parameter is one of these constants:

|               |                               |
|---------------|-------------------------------|
| IM_APPLI_BEEP | Application controls the beep |
| IM_WEDGE_BEEP | Beeps occur automatically     |

The *display* parameter determines if the data is displayed as it is entered. The *display* parameter is one of these constants:

|            |                         |
|------------|-------------------------|
| IM_DISABLE | Disable display of data |
| IM_ENABLE  | Enable display of data  |

## **IN/OUT Parameters:**

The *source* parameter determines which input sources are allowed. When the IRL V command returns, *source* indicates where the data came from. When both keypad and label inputs are allowed, the *source* always returns keypad because it is possible for keyed and scanned data to be intermixed. Although intermixing is possible, it is not likely to occur.

If you have both the keypad and scanner enabled, and you want to know where the data came from, first check the symbology:

- If the symbology is IM\_UNKNOWN\_DECODE, then the data came from the keypad.
- If the symbology is one of the other values (such as IM\_CODE\_39), then some or all of the data came from the scanner.
- If only the scanner is enabled, then all of the data came from the scanner.



The *source* parameter is one of these constants:

|                    |   |
|--------------------|---|
| IM_NO_SELECT       | No source selected                          |
| IM_LABEL_SELECT    | Label selected                              |
| IM_KEYBOARD_SELECT | Keypad selected                             |
| IM_COM1_SELECT     | COM1 selected                               |
| IM_COM2_SELECT     | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)                     |
| IM_ALL_SELECT      | All sources are selected                    |

**OUT Parameters:** The *instring* parameter is the input string. You must allocate at least 256 bytes for *instring*.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

The *symbology* parameter is one of these constants:

|                   |                        |
|-------------------|------------------------|
| IM_UNKNOWN_DECODE | Unknown bar code       |
| IM_CODABAR        | Codabar bar code       |
| IM_CODE_11        | Code 11 bar code       |
| IM_CODE_16K       | Code 16K bar code      |
| IM_CODE_39        | Code 39 bar code       |
| IM_CODE_49        | Code 93 bar code       |
| IM_CODE_93        | Code 49 bar code       |
| IM_CODE_128       | Code 128 bar code      |
| IM_I_2_OF_5       | Interleaved 2 of 5     |
| IM_MSI            | MSI bar code           |
| IM_PDF_417        | PDF 417 bar code       |
| IM_PLESSEY        | Plessey bar code       |
| IM_UPC            | Universal Product code |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**Notes:** You must set the reader to Programmer mode with *im\_set\_input\_mode*.

To receive data from a communications port, you must install a protocol handler.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

*im\_irl\_v*

Data is automatically cleared from both the scanner and the keypad buffers but not from any communications port buffer.

Use the `im_link_comm` function to establish a link between the Reader Wedge function and a communications port, and use the `im_unlink_comm` function to remove the link.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using `im_set_display_mode`.

**See Also:**

`im_irl_a`, `im_irl_k`, `im_irl_n`, `im_irl_y`, `im_set_input_mode`

**Example**

```

/***** im_irl_v *****/
/* Also with: im_link_comm im_unlink_comm im_set_input_mode */
/* Note: Load PHIMEC.EXE protocol handler before using this program. */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "immsg.h"
#include "im20lib.h"

#define COM_BUFSIZE 300 /* allocate 300 bytes for comm buffer */

void main (void)
{
IM_UCHAR *com_buffer;
IM_UCHAR input[256];
IM_ORIGIN source;
IM_USHORT cc;
IM_DECTYPE symbol;

/* FUNCTION BODY */

window(1, 1, 20, 16); /* Set the reader services text window */
clrscr(); /* Clear the screen */
printf("Demo IRL V Bar code\n'C' to clear screen\n'Q' to quit\n");

/* Allocate a comm buffer */
com_buffer = (char *) malloc(COM_BUFSIZE);
/* Set Reader Wedge mode to program interface */
im_set_input_mode(IM_PROGRAMMER);
/* Link com_buffer to com1 */
im_link_comm(IM_COM1, com_buffer, COM_BUFSIZE);
/* im_irl_v input loop */
do
{
/* Display IRL V test */
printf("IRL V test\n");
/* Set up input source with labels, keypad, and com1 */
source = IM_LABEL_SELECT | IM_KEYBOARD_SELECT | IM_COM1_SELECT;
/* Request input from Reader Wedge */
im_irl_v(IM_INFINITE_TIMEOUT,
IM_ENABLE, IM_WEDGE_BEEP, IM_ENABLE,
&source, input, &cc, &symbol);
/* Display input data */
printf("\n%s\n", input);
/* Upper case first char of input for simplifying to test input */
input[0] = toupper(input[0]);
/* If the first char in string is 'C', then clear screen.*/
if (input[0] == 'C')
clrscr();
} while (input[0] != 'Q'); /* 'Q' for quit */
/* Unlink from comm port */
im_unlink_comm(IM_COM1);
/* Free allocated memory */
free(com_buffer);
/* Switch the Reader Wedge back to virtual wedge mode */
im_set_input_mode(IM_WEDGE);
im_set_beep_control(IM_WEDGE_BEEP);
}

```

*im\_irl\_y*

---

## ***im\_irl\_y***

**Purpose:** The *im\_irl\_y* function receives input from the designated communications port the same as IRL ASCII input command Y. This function receives a single block, not an entire file. This function always clears input from the host and edits reader commands from input. Unlike the other IRL instructions, the data is not automatically displayed. For more information on IRL and command Y, refer to the *IRL Programming Reference Manual*.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_irl_y
    (IM_USHORT timeout,
     IM_COM_PORT port_id,
     IM_UCHAR *eom_char,
     IM_PROTOCOL_CMD protocol,
     IM_UCHAR *instring,
     IM_USHORT *cmd_count);
```

**IN Parameters:** The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *eom\_char* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character.

The *protocol* parameter is one of these constants:

|                  |                                   |
|------------------|-----------------------------------|
| IM_NO_CHANGE     | Keep the current protocol         |
| IM_PROTOCOL_OFF  | Turn the protocol OFF             |
| IM_PROTOCOL_ON   | Turn the protocol ON              |
| IM_NEW_TERM_CHAR | Use the new termination character |

The *protocol* parameter affects how incoming messages are received:

- If IM\_NO\_CHANGE is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If IM\_PROTOCOL\_OFF is specified, the incoming data is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.
- If IM\_PROTOCOL\_ON is specified, the incoming message is terminated with the end of message character of the active protocol.
- If IM\_NEW\_TERM\_CHAR is specified, IM\_PROTOCOL\_OFF is assumed and the new end of message character specified in the parameter list is used.

**OUT Parameters:** The *instring* parameter is the input string. You must allocate at least 256 bytes for *instring*.

The *cmd\_count* returned is 0 unless an abort command is passed in the string.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The receive buffers are cleared whenever the protocol is turned ON or OFF. To change the termination character (or to not change the setting at all), use IM\_NEW\_TERM\_CHAR or IM\_NO\_CHANGE instead of toggling the protocol.

Data does not display correctly on the screen if the display is in the 80 x 25 mode after the cursor has scrolled off the bottom of the display. Set the display to one of the other modes using *im\_set\_display\_mode*.

## *im\_irl\_y*

Set the reader to Programmer mode using `im_set_input_mode` to use this function.

You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** `im_irl_a`, `im_irl_k`, `im_irl_n`, `im_irl_v`, `im_set_display_mode`,  
`im_set_input_mode`

---

### **Example**

```
/****** im_irl_y *****/
/* Also with: im_link_comm */
/* im_unlink_comm */
/* im_set_input_mode */

/* Note: Load JANUS's PHIMEC protocol before using this sample program. */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include "immsg.h"
#include "im20lib.h"

#define COM_BUFSIZE 300 /* Allocate 300 bytes for comm buffer */

static IM_UCHAR eom_ctrl_a = 1; /* Control-A for EOM char */
static IM_UCHAR eom_ctrl_y = 25; /* Control-Y for EOM char */
static IM_UCHAR eom_ctrl_z = 26; /* Control-Z for EOM char */
static IM_UCHAR eom_cr = '\r'; /* Carriage Return for EOM char */
static IM_UCHAR eom_null = '\0'; /* Null char for EOM char */

void main (void)
{
IM_UCHAR *com_buffer;
IM_UCHAR input[256];
IM_USHORT cc;
IM_STATUS status;

window(1, 1, 20, 16); /* Set the application text window */
clrscr(); /* Clear the screen */

printf("Demo IRL Y Bar Code\n'Q' to quit\n'C' to clear screen\n");

/* Allocate a comm buffer */
com_buffer = (char *) malloc(COM_BUFSIZE);
```

```

/* Link com_buffer to com1 */
im_link_comm(IM_COM1, com_buffer, COM_BUFSIZE);

/* Set Reader Wedge mode to program interface */
im_set_input_mode(IM_PROGRAMMER);

/* Using JANUS's protocol by passing IM_PROTOCOL_ON */
printf("\nUsing JANUS's protocol\n");
status = im_irl_y(IM_INFINITE_TIMEOUT, IM_COM1, &eom_null,
                 IM_PROTOCOL_ON, input, &cc);

/* Display input data */
printf("\nstatus: %x\n%s", status, input);

/*****
/* The following im_irl_y() calls demonstrates that the various types */
/* of EOM chars are used for EOM purpose. If you just use one type EOM */
/* char, then you delete the unwanted im_irl_y() call. */
*****/

/* Not using JANUS's protocol by passing IM_PROTOCOL_OFF and new EOM */
/* char control-y */
printf("\nCTRL-Y for EOM\n");
status = im_irl_y(IM_INFINITE_TIMEOUT, IM_COM1, &eom_ctrl_y,
                 IM_PROTOCOL_OFF, input, &cc);

/* Display input data */
printf("\nstatus: %x\n%s", status, input);

/* Using IM_NEW_TERM_CHAR and changing EOM char to control-z */
printf("\nCTRL-Z for EOM\n");
status = im_irl_y(IM_INFINITE_TIMEOUT, IM_COM1, &eom_ctrl_z,
                 IM_NEW_TERM_CHAR, input, &cc);

/* Display input data */
printf("\nstatus: %x\n%s", status, input);

/* Using IM_PROTOCOL_OFF and changing EOM char to control-a */
printf("\nCTRL-A for EOM\n");
status = im_irl_y(IM_INFINITE_TIMEOUT, IM_COM1, &eom_ctrl_a,
                 IM_PROTOCOL_OFF, input, &cc);

/* Display input data */
printf("\nstatus: %x\n%s", status, input);

/* Using JANUS's protocol for input again */
printf("\nUsing JANUS's protocol\n");
status = im_irl_y(IM_INFINITE_TIMEOUT, IM_COM1, &eom_null,
                 IM_PROTOCOL_ON, input, &cc);

/* im_irl_y input loop */
do
{
    /* Using JANUS's protocol, If using Pt-to-Pt protocol, EOM is CR */
    printf("\nCR is EOM of Pt-to-Pt\n");
    status = im_irl_y(IM_INFINITE_TIMEOUT, IM_COM1, &eom_null,
                    IM_NO_CHANGE, input, &cc);

    /* Display input data */
    printf("\nstatus: %x\n%s", status, input);
    /* Test input Y with protocol and timeout */

    /* Upper case first char of input for simplifying to test input */
    input[0] = toupper(input[0]);

```

*im\_irl\_y*

```
    /*If the first char in string is 'C', then clear screen.*/  
    if (input[0] == 'C')  
        clrscr();  
  
} while (input[0] != 'Q'); /* 'Q' to stop */  
  
/* Unlink com_buffer from com1 */  
im_unlink_comm(IM_COM1);  
  
/* Free allocated memory */  
free(com_buffer);  
  
/* Switch the Reader Wedge back to virtual wedge mode */  
im_set_input_mode(IM_WEDGE);  
}
```



---

## IM\_ISERROR

**Purpose:** This macro determines if the return status code from another PSK function is an error (either fatal or nonfatal).

**Syntax:** `#include <im20lib.h>`  
`IM_ISERROR(status);`

**IN Parameters:** The *status* parameter is any PSK function that returns a status code.

**OUT Parameters:** None.

**Return Value:** 0 Indicates success or warning  
nonzero Indicates an error (either fatal or nonfatal)

**See Also:** “Status Code Macros” earlier in this chapter.  
IM\_ISGOOD, IM\_ISSUCCESS, IM\_ISWARN

---

### Example

```
/****** IM_ISERROR *****/
#include "im20lib.h"
#include <stdio.h>
printf("IM_ISERROR example:")

status = im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME)
if IM_ISERROR(status)
    printf("Beep error!");
else
    printf("Beep success or warning!");
```

*IM\_ISGOOD*

---

## ***IM\_ISGOOD***

**Purpose:** This macro determines if the return status code from another PSK function is success.

**Syntax:** `#include <im20lib.h>`  
`IM_ISGOOD(status);`

**IN Parameters:** The *status* parameter is any PSK function that returns a status code.

**OUT Parameters:** None.

**Return Value:** 0 Indicates a warning or an error (either fatal or nonfatal)  
nonzero Indicates success

**See Also:** “Status Code Macros” earlier in this chapter.  
IM\_ISERROR, IM\_ISSUCCESS, IM\_ISWARN

---

### ***Example***

```
/****** IM_ISGOOD *****/
#include "im20lib.h"
#include <stdio.h>
printf("IM_ISGOOD example:")

status = im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME)
if IM_ISGOOD(status)
    printf("Beep successful!");
else
    printf("Beep warning or error!");
```

---

## IM\_ISSUCCESS

- Purpose:** This macro determines if the return status code from another PSK function is either success or warning.
- Syntax:** `#include <im20lib.h>`  
`IM_ISSUCCESS(status);`
- IN Parameters:** The *status* parameter is any PSK function that returns a status code.
- OUT Parameters:** None.
- Return Value:** 0 Indicates an error (either fatal or nonfatal)  
nonzero Indicates success or warning
- See Also:** “Status Code Macros” earlier in this chapter.  
IM\_ISERROR, IM\_ISGOOD, IM\_ISWARN

---

### Example

```
/****** IM_ISSUCCESS *****/
#include "im20lib.h"
#include <stdio.h>
printf("IM_ISSUCCESS example:")

status = im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME)
if IM_ISSUCCESS(status)
    printf("Beep success or warning!");
else
    printf("Beep error!");
```

*IM\_ISWARN*

---

## ***IM\_ISWARN***

**Purpose:** This macro determines if the return status code from another PSK function is a warning.

**Syntax:** `#include <im20lib.h>`  
`IM_ISWARN(status);`

**IN Parameters:** The *status* parameter is any PSK function that returns a status code.

**OUT Parameters:** None.

**Return Value:** 0 Indicates success or an error (either fatal or nonfatal)  
nonzero Indicates a warning

**See Also:** “Status Code Macros” earlier in this chapter.  
IM\_ISERROR, IM\_ISGOOD, IM\_ISSUCCESS

---

### ***Example***

```
/****** IM_ISWARN *****/
#include "im20lib.h"
#include <stdio.h>
printf("IM_ISWARN example:")


status = im_sound(IM_LOW_PITCH, IM_BEEP_DURATION, IM_NORMAL_VOLUME)
if IM_ISWARN(status)
    printf("Beep warning!");
else
    printf("Beep success or error!");
```

# im\_link\_comm

**Purpose:** This function establishes a link between the Reader Wedge function and a designated communications port. The following figure lists the different modes and the functions to use when linked or unlinked.

*Note: Programmer mode and desktop mode differ in how they handle keypad inputs. When the reader is in Programmer mode, the Enter key terminates keypad input. When the reader is in Desktop mode, keypad entry terminates when you press each key.*

## Linking Specific Modes and Functions



AIT-24

## *im\_link\_comm*

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_link_comm
    (IM_COM_PORT port_id,
     void *buffer,
     IM_USHORT buffer_size);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *buffer* parameter is a pointer to a memory area used by the Reader Wedge. Your application should not use this buffer.

The *buffer\_size* parameter is the number of bytes to allocate for the buffer array. The suggested size is 300 bytes.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** Use this function if you want to receive data with the Reader Wedge input function *im\_irl\_y* or to use the communications port with *im\_receive\_input* and *im\_irl\_v*.

This function needs to be called only once.

You must unlink at the end of your application.

You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** *im\_unlink\_comm*, *im\_receive\_input*, *im\_irl\_v*, *im\_irl\_y*, *im\_serial\_protocol\_control*

---

### *Example*

See example for *im\_receive\_input*.

---

## *fim\_message*

- Purpose:** This function displays the error message associated with a specific status code returned by an Intermec function. These status codes are listed in Appendix A.
- Use this function to display additional information about status codes during application development.
- Syntax:**
- ```
#include "im20lib.h"
void im_message(IM_STATUS status_code);
```
- IN Parameters:** The `status_code` parameter is a standard status code returned from various PSK functions.
- OUT Parameters:** None.
- Return Value:** None.
- Notes:** The status message is displayed at the current cursor location without any formatting.

---

### *Example*

See example for `im_set_contrast`.

*im\_number\_pad\_off*

---

## ***im\_number\_pad\_off***

**Purpose:** This function disables the number pad feature. When the number pad is disabled, the numeric keys function the same as the 1 through + keys above the “QWERTY” keys on a normal PC keyboard.

When the number pad is disabled, you cannot type characters from the extended ASCII character set or use the number pad to move the cursor. For more information, refer to your JANUS user’s manual.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_number_pad_off (void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”

**See Also:** `im_number_pad_on`

---

### ***Example***

See example for `Im_number_pad_on`.



---

## *im\_number\_pad\_on*

**Purpose:** This function enables the reader's number pad. When enabled, the number pad functions the same way as the 10-key number pad on a standard PC keyboard. The numeric keys then provide cursor movement and editing keys, numbers, and access to the extended ASCII character set.

When you enable the number pad, you also turn the **Num Lock** key off or on. When **Num Lock** is on, the number pad keys produce only numbers or extended ASCII characters with the same scan codes as the numeric keypad on a PC. The numeric keys always generate the same ASCII characters for numbers, but the scan codes depend on the status of the number pad and the **Num Lock** setting.

When **Num Lock** is off, the number pad keys move the cursor (**Home**) or edit text (**Del**). Refer to your JANUS user's manual for more information on the number pad.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_number_pad_on
    (IM_NUMBER_LOCK numlock);
```

**IN Parameters:** The *numlock* parameter indicates whether the **Num Lock** key is ON or OFF. Use one of these constants:

IM\_NUMLOCK\_ON    Enable the number pad with Num Lock ON  
IM\_NUMLOCK\_OFF   Enable the number pad with Num Lock OFF

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_number\_pad\_off*

## *im\_number\_pad\_on*

---

### **Example**

```
/****** im_number_pad_on ******/
/*Also with: im_number_pad_off */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include "im20lib.h"

void main (void)
{
int inchar;

    /* Numlock control */
    printf("\nTurn numlock ON/OFF\n");
    printf("Enter numbers.\n");
    printf("'Q' to quit\n");

    /* Number Lock On */
    /* IM_NUMLOCK_ON : Enables numeric pad with NUMLOCK ON */
    printf ("Numpad enable NL ON\n");
    inchar = '\0';

    im_number_pad_on( IM_NUMLOCK_ON);

    while (inchar != 'Q')
    {
        inchar = toupper( getche());
    }

    /* IM_NUMLOCK_OFF : Enables numeric pad with NUMLOCK off */
    printf ("\nNumpad enable NL OFF\n");
    printf("Try to enter numbers.\n");
    printf("'Q' or '3' to quit\n");
    inchar = '\0';

    im_number_pad_on( IM_NUMLOCK_OFF);

    while (inchar != 'Q')
    {
        inchar = toupper( getche());
    }
}
```

---

## *im\_parse\_host\_response*

**Purpose:** This function parses the host response for a DCM transaction. For a detailed discussion of programming database transactions, see Chapter 5, “Using the PSK With DCM.”

**Syntax:**

```
#include <im20lib.h>
IM_USHORT im_parse_host_response
    (IM_USHORT max_ret_length;
     IM_UCHAR *ret_string;
     IM_DCMSTRN ret_array[];
     IM_UCHAR oper_type);
```

**IN Parameters:** The *max\_ret\_length* parameter sets the maximum length for the return string buffer.

The *\*ret\_string* parameter is a pointer to the return string buffer. The buffer contains the database server’s transaction message unless a timeout occurs.

If the reader receives IM\_DCM\_TIMEOUT, then the communication error status is placed in the first two bytes of the return buffer.

The return string buffer must be large enough to hold a complete packet from the controller.

**OUT Parameters:** The *ret\_array[]* parameter is the array containing pointers to the variables that hold the data returned from the database. The received field data is parsed and then placed into the variables.

The *\*oper\_type* parameter is a pointer to the operation type and is one of these constants:

|               |   |                                  |
|---------------|---|----------------------------------|
| IM_DB_READ    | R | Read records from the database   |
| IM_DB_INSERT  | W | Write records to the database    |
| IM_DB_UPDATE  | U | Update records in the database   |
| IM_DB_DELETE  | D | Delete records from the database |
| IM_DB_UNKNOWN | X | Unknown                          |

*im\_parse\_host\_response*

**Return Value:** This function returns one of the status codes from the following table. For more information on these return codes, see Chapter 5, "Using the PSK With DCM."

|                    |      |                                      |
|--------------------|------|--------------------------------------|
| IM_DCM_ACK_RCD     | 1A01 | Transaction successful, ACK received |
| IM_DCM_MSG_RCD     | 1A10 | Data received                        |
| IM_DCM_NAK_RCD     | 5A02 | Transaction failed, NAK received     |
| IM_DCM_TRUNCATED   | 5A11 | Received data was truncated          |
| IM_DCM_EXCESSFIELD | 5A12 | Too many fields                      |
| IM_DCM_TIMEOUT     | 9A04 | Receive timeout                      |
| IM_DCM_HEAD_ERR    | 9A05 | Packet header error                  |

**Notes:** See Chapter 5, "Using the PSK With DCM."

**See Also:** `im_setup_trx`, `im_standard_trx`

---

**Example**

See the sample program in Chapter 5, "Using the PSK With DCM."

---

## *im\_power\_status*

**Purpose:** This function returns the line status, battery status, backup status, and percentage of remaining battery life.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_power_status
    (IM_LINE_STATUS *line_status,
     IM_BATTERY_STATUS battery_status,
     IM_BACKUP_STATUS *backup_status,
     IM_UCHAR fuel_gauge);
```

**IN Parameters:** None.

**OUT Parameters:** The *line\_status* parameter returns one of these constants:

|                         |                           |
|-------------------------|---------------------------|
| IM_Acline_NOT_CONNECTED | AC line is not connected  |
| IM_Acline_CONNECTED     | AC line is connected      |
| IM_UNKNOWN_Acline       | AC line status is unknown |

The *battery\_status* parameter returns one of these constants:

|                 |                              |
|-----------------|------------------------------|
| IM_HIGH_BAT     | Battery charge is high       |
| IM_LOW_BAT      | Battery charge is low        |
| IM_CRITICAL_BAT | Battery charge is critical   |
| IM_CHARGING_BAT | Battery is charging now      |
| IM_UNKNOWN_BAT  | Battery condition is unknown |

The *backup\_status* parameter returns one of these constants:

|               |                       |
|---------------|-----------------------|
| IM_BACKUP_OK  | Backup battery is OK  |
| IM_BACKUP_LOW | Backup battery is low |

The *fuel\_gauge* parameter returns one of these constants:

|          |                                       |
|----------|---------------------------------------|
| 0 to 100 | % of full charge in increments of 10% |
| 255      | Unknown                               |

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

## *im\_power\_status*

---

### **Example**

```
/****** im_power_status *****/
#include <stdio.h>
#include <stdlib.h>
#include "im20lib.h"

IM_LINE_STATUS    ac_line;
IM_BATTERY_STATUS battery;
IM_BACKUP_STATUS  backup;
IM_UCHAR          fuel;
IM_STATUS         status;

void main (void)
{
    /* Call Intermec function */
    status = im_power_status( &ac_line, &battery, &backup, &fuel);
    printf ("Status: %4X\n", status);

    printf ("Line status:\n ");
    switch (ac_line)
    {
        case IM_Acline_NOT_CONNECTED:
            printf ("Not connected\n");
            break;

        case IM_Acline_CONNECTED:
            printf ("Connected\n");
            break;

        case IM_UNKNOWN_Acline:
            printf ("Unknown\n");
            break;

        default:
            printf ("Invalid return value\n");
            break;
    } /* End switch */

    printf ("Battery status:\n ");
    switch (battery)
    {
        case IM_HIGH_BAT:
            printf ("Charge high\n");
            break;

        case IM_LOW_BAT:
            printf ("Charge low\n");
            break;

        case IM_CRITICAL_BAT:
            printf ("Charge critical\n");
            break;

        case IM_CHARGING_BAT:
            printf ("Charging battery\n");
            break;

        case IM_UNKNOWN_BAT:
            printf ("Unknown\n");
            break;
    }
}
```

```
        default:
            printf ("Invalid return value\n");
            break;
    } /* end switch */

printf ("Backup status:\n ");
switch (backup)
{
    case IM_BACKUP_OK:
        printf ("Backup battery OK\n");
        break;

    case IM_BACKUP_LOW:
        printf ("Backup battery low\n");
        break;

    default:
        printf ("Invalid return value\n");
        break;
} /* end switch */

if (fuel <= 100)
    printf ("Fuel gauge:\n %u percent\n", fuel);
else if (fuel == 255)
    printf ("Fuel gauge unknown\n");
else
    printf ("Invalid return value\n");
}
```

*im\_protocol\_extended\_status*

---

## ***im\_protocol\_extended\_status***

**Purpose:** This function gets the protocol extended status from the designated communications port. You allocate the protocol status buffer or RF status buffer, and then *im\_protocol\_extended\_status* returns the status and setup in hexadecimal values.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_protocol_extended_status
    (IM_COM_PORT port_id,
     IM_COMM_STATUS_BUFFER_s far
     *status_buffer);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *status\_buffer* parameter is a far pointer to the status buffer structure *IM\_COMM\_STATUS\_BUFFER\_s*.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_receive\_buffer\_no\_wait*, *im\_transmit\_buffer\_no\_wait*

---

### ***Example***

```
/****** im_protocol_extended_status *****/
#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <string.h>
#include <im20lib.h>

void main (void)
{
    IM_STATUS status;
    IM_COMM_STATUS_BUFFER_s status_buffer;

    /* First format string for extended protocol status */
    IM_UCHAR *format_str1 =
        "Strut Ver = %d\nHd Ver = %s\nBaud = %lu\nParity=%XH\nStop=%XH\nData=%XH\n"
        "Modem=%XH\nPort stat = %XH\nActive prot = %d\n"
```



```

        "Lrc enabled = %XH\nInterchar dely= %d\nTurnarnd dely=%d\n"
        "Receive tmeout= %d\nTransmit tmeout= %d\n";

/* Second format string for extended protocol status */
IM_UCHAR *format_str2 =
    "Pol char = %XH\nPol length= %d\nSel char = %XH\nSel length= %d\n"
    "Res char = %XH\nRes length= %d\nReq char = %XH\nReq length= %d\n"
    "Aff char = %XH\nAff length= %d\nNeg char = %XH\nNeg length= %d\n"
    "Som char = %XH\nSom length= %d\n";

/* Third format string for extended protocol status */
IM_UCHAR *format_str3 =
    "Tx eom len = %XH\nTx eom char 1 = %XH\n"
    "Tx eom char 2 = %XH\nRx eom len = %XH\nRx eom char 1 = %XH\n"
    "Rx eom char 2 = %XH\nFlow ctrl = %XH\nMulti drp addr = %XH\n"
    "Multi drp addr = %XH\nMulti drp enbled = %XH\n"
    "EOF len = %XH\nEOF char = %XH\nRecv clt buff= %d\n"
    "Xmit clt buff= %d\nProt mode = %d\n";

/* Call Intermec routine */
status_buffer.status_structure_version = STATUS_STRUCT_VERSION;

status = im_protocol_extended_status(IM_COM1, &status_buffer);

clrscr();
gotoxy(1, 1);      /* to upper left screen */

/* Print first page of status info */
printf("Extd Status,Page 1of3\n");
printf(format_str1,
        status_buffer.status_structure_version,
        status_buffer.handler_ver,

        status_buffer.specific.serial.baud_rate,
        status_buffer.specific.serial.parity,
        status_buffer.specific.serial.stop_bits,
        status_buffer.specific.serial.data_bits,
        status_buffer.specific.serial.modem_status,
        status_buffer.specific.serial.port_status,
        status_buffer.specific.serial.active_prot,
        status_buffer.specific.serial.lrc_enabled,
        status_buffer.specific.serial.interchar_delay,
        status_buffer.specific.serial.turnaround_delay,
        status_buffer.specific.serial.receive_timeout,
        status_buffer.specific.serial.transmit_timeout);

/* Pause between screens */
printf("Any key to cont'\n");
getch();

clrscr();
gotoxy(1, 1);
printf ("Extd Status,Page 2of3\n");

/* Print second page of status info */
printf (format_str2,

        status_buffer.specific.serial.pol_char,
        status_buffer.specific.serial.pol_length,
        status_buffer.specific.serial.sel_char,
        status_buffer.specific.serial.sel_length,
        status_buffer.specific.serial.res_char,

```

### *im\_protocol\_extended\_status*

```
        status_buffer.specific.serial.res_length,
        status_buffer.specific.serial.req_char,
        status_buffer.specific.serial.req_length,
        status_buffer.specific.serial.aff_char,
        status_buffer.specific.serial.aff_length,
        status_buffer.specific.serial.neg_char,
        status_buffer.specific.serial.neg_length,
        status_buffer.specific.serial.som_char,
        status_buffer.specific.serial.som_length);

/* Pause between screens */
printf ("Any key to cont'\n");
getch();

clrscr();
gotoxy(1, 1);
printf ("Extd Status,Page 3of3\n");

/* Print third page of status info */
printf (format_str3,
        status_buffer.specific.serial.txcom_len,
        status_buffer.specific.serial.txcom_char_1,
        status_buffer.specific.serial.txcom_char_2,
        status_buffer.specific.serial.rxcom_len,
        status_buffer.specific.serial.rxcom_char_1,
        status_buffer.specific.serial.rxcom_char_2,
        status_buffer.specific.serial.flow_ctrl,
        status_buffer.specific.serial.multi_drop_addr,
        status_buffer.specific.serial.multi_drop_enabled,
        status_buffer.specific.serial.eof_length,
        status_buffer.specific.serial.eof_char,
        status_buffer.specific.serial.have_rcv_client_buffer,
        status_buffer.specific.serial.have_xmit_client_buffer,
        status_buffer.specific.serial.protocol_mode);

/* Function call return status */
printf ("Extd Prot Stat=%XH\n", status);
}
```

---

## ***im\_ready\_for\_reboot***

- Purpose:** This function indicates to the host whether the JANUS reader is ready for a reboot in response to having received a “Prepare for Reboot” command.
- Syntax:**

```
#include "im20lib.h"
IM_STATUS im_ready_for_reboot(IM_BOOL reboot_flag)
```
- IN Parameters:** The *reboot\_flag* parameter can be one of the following symbolic constants:
- IM\_TRUE     JANUS reader is ready for reboot. The string “..+%1” will be sent to the host.
  - IM\_FALSE    JANUS reader is not ready for reboot. The string “..+%0” will be sent to the host.
- OUT Parameters:** None.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, “Status Codes.”
- Notes:** To reboot, the JANUS reader must receive one of the reboot commands from the host: ..%\$0 to reboot without an open session, or ..%\$1 to reboot with an open session.
- The *im\_ready\_for\_reboot* function with a *reboot\_flag* of IM\_TRUE **must** be called before the JANUS reader will respond to either reboot command. This prevents the JANUS reader from being rebooted before it is ready.
- See Also:** *im\_get\_reboot\_flag*

---

### ***Example***

See example for *im\_get\_reboot\_flag*

*im\_receive\_buffer*

---

## ***im\_receive\_buffer***

**Purpose:** This function receives the contents of a data buffer from a designated communications port.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_receive_buffer
    (IM_COM_PORT port_id,
     IM_USHORT user_length,
     IM_UCHAR far *data_buffer,
     IM_USHORT timeout,
     IM_USHORT far *comm_length);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *user\_length* parameter is the maximum number of bytes to receive and must be at least 256 bytes.

The *data\_buffer* parameter is a far pointer to the data array where you want to place the received data. This buffer must hold at least 256 bytes.

The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If you select IM\_INFINITE\_TIMEOUT, the function will not return until the end of message character has been received.

**OUT Parameters:** The *comm\_length* is the actual number of bytes received upon completion of the call.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function does not return until an end of message, a buffer is full, a timeout, or an error occurs.

You must install a protocol handler to use this function.

**See Also:** `im_receive_buffer_no_wait`, `im_receive_buffer_noprot`, `im_cancel_rx_buffer`, `im_rx_check_status`

---

### Example

```

/***** im_receive_buffer *****/
/* Also with: im_cancel_rx_buffer */
/*
/* Note: Must have reader services and comm protocol handler installed to */
/* enable send/receive buffer functions. */
/* Run these TSR's at DOS prompt before running these tests: */
/* rservice */
/* phimec 1 ( 1 is COM1) */
/*
/* Assume that the receive data is stored in file 'RC.DAT' at current */
/* working directory and uses the first byte of receiving string to */
/* terminate receive buffer loop. Default is 'Q' or 'q' character */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <string.h>
#include <ctype.h>
#include "im20lib.h"

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/
static IM_UCHAR filename[] = "RC.DAT"; /* Store receive data filename*/
static IM_UCHAR eor_char = 'Q'; /* Default end of receive char */

void main (void)
{
IM_USHORT actual_length;
IM_UCHAR data_buffer[300];
IM_UCHAR eor_byte;
FILE *out_fptr;
IM_STATUS status;

/* Call im_cancel_Rx_buffer to initialize the communications port and its buffer */
status = im_cancel_rx_buffer(com_port);
printf("Cancel Rx status: %xH\n", status);

/* Assume that the received data is stored in file 'RC.DAT' */
out_fptr = fopen(filename, "w+t"); /* Open in Translate mode*/

printf("Type End of receive\nchar?");
eor_byte = toupper( getche()); /* Get End of Receive char */
if (isascii(eor_byte))

```

### *im\_receive\_buffer*

```
    eor_char = eor_byte;

    printf ("Enter characters\n");
    printf ("to be received\n");
    printf ("from host\n");
    printf ("CRLF to End of Line\n");    /* Each line end with a CR & LF */

do
{
    actual_length = 0;

    /* Call Intermec receive buffer function with 50000 msec timeout */
    status = im_receive_buffer(com_port, sizeof(data_buffer) - 1,
                               data_buffer, 50000, &actual_length);

    if (actual_length > 0)
    {
        /* Append CR & LF before write it into files */
        data_buffer[actual_length++] = '\x0D';
        data_buffer[actual_length++] = '\x0A';
        data_buffer[actual_length] = '\0';

        /* Write results to file */
        fwrite(data_buffer, actual_length, sizeof(char), out_fptr);

        printf("%s", data_buffer);    /* Write data to on screen */
        eor_byte = toupper(data_buffer[0]);
    }
    else
    {
        eor_byte = '\0';
        printf("Rx Status: %xH\n", status);
    }
} while (eor_byte != eor_char);    /* Loop until EOR char 'q' */

/* Close file and exit */
fclose(out_fptr);
printf("Receive Done\n");
}
```

---

## ***im\_receive\_buffer\_no\_wait***

**Purpose:** This function receives data from the designated communications port and places the data into a user-defined record. It differs from `im_receive_buffer` in that the programmer must set up the data record and monitor the transfer status until transmission is complete. This function runs in the background after it is initiated; no checks are made.

Use this function when receiving multiple buffer transmissions in conjunction with `im_rx_check_status`.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_receive_buffer_no_wait
    (IM_COM_PORT port_id,
     IM_COM_DATA_BUFFER far *data_struct);
```

**IN Parameters:** The `port_id` parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The `data_struct` parameter is a far pointer to the data array for the received data. This buffer must hold at least 256 bytes.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must build and maintain a `data_struct` of the type `IM_COM_DATA_BUFFER` as described in `IM20LIB.H`.

You must periodically check the `protocol_xfer_status` element in the `IM_COM_DATA_BUFFER` record to see if all the data has been received. When `protocol_xfer_status` is no longer code 8602H (communications port in use), all data is received.

You must install a protocol handler to use this function.

## *im\_receive\_buffer\_no\_wait*

This function differs from `im_receive_buffer_noprot` in that program execution continues after `im_receive_buffer_no_wait` is called. When `im_receive_buffer_noprot` returns from a function call, the data has been read, the timeout has expired, or an error was encountered.

**See Also:** `im_receive_buffer_noprot`, `im_cancel_rx_buffer`, `im_rx_check_status`

---

### **Example**

```
***** im_receive_buffer_no_wait *****
/* Also with: im_rx_check_status */
/* im_cancel_rx_buffer */
/* Note: Must have reader services and comm protocol handler installed to */
/* enable send/receive buffer functions. */
/* Run these TSR's at DOS prompt before running these tests: */
/* rservice */
/* phimec 1 ( 1 is COM1) */

#include <stdio.h>
#include <conio.h>
#include <string.h>
#include <ctype.h>
#include <stdlib.h>
#include "im20lib.h"
#include "immsg.h"

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/
static IM_UCHAR eor_char = 'Q'; /* Default end of receive char */

void main (void)
{
IM_COM_DATA_BUFFER com_buff_struct; /*Data buffer structure for receive/transmit */
IM_STATUS status;
IM_UCHAR eor_byte;
IM_UCHAR data_buff[300];
int index = 0;

printf("Type End of receive\nchar?");
eor_byte = getche(); /* Get End of Receive char */
eor_byte = toupper( eor_byte);

if ( isascii(eor_byte))
eor_char = eor_byte;

printf ("Enter characters\n");
printf ("to be received\n");
printf ("from host\n");
printf ("CRLF to End of Line\n"); /* Each line end with a CR & LF */

/* Get the receive environment ready */
status = im_cancel_rx_buffer(com_port);
printf ("RX Init =%XH\n", status);

/* Set up com_buff structure for init Receive Buffer No Wait */
com_buff_struct.command = IM_CU_RECEIVE;
com_buff_struct.comm_length = 0;
```



```

com_buff_struct.user_length = sizeof(data_buff);
com_buff_struct.data_ptr   = data_buff;
com_buff_struct.protocol_mode = IM_NO_PROTOCOL;
com_buff_struct.eom_char   = 0x0d;          /* CR for terminating char */
com_buff_struct.protocol_xfer_status = IM_COMM_INUSE;

/* Call Intermec function */
status = im_receive_buffer_no_wait(com_port, (IM_COM_DATA_BUFFER far *)
                                   &com_buff_struct);

/* Uses im_rx_check_status to get the rest coming data */
do /* loop until first character in buffer is a 'Q' */
{
  /* Check for receive errors: Print the error status */
  if ( IM_ISSUCCESS(status) )
  {
    ++index;          /* Indicator of the receiving buffer */

    /* Let the receive data coming complete */
    while (com_buff_struct.protocol_xfer_status == IM_COMM_INUSE)
      ; /* End of While loop, Wait the coming data settled */

    printf ("Line %d Done\n", index);

    /* Put a null byte in received string for display */
    data_buff[com_buff_struct.comm_length] = '\0';

    /* If 1st byte in string is equal to eor_char, then quit the receive*/
    eor_byte = toupper(data_buff[0]);

    /* Display received string to screen */
    printf("%s\n", data_buff);

    /*
    *****
    * Update buffer for next block before calling check status to
    * get protocol handler to reset status.
    *****
    */
    com_buff_struct.command           = IM_CU_RECV_AGAIN;
    com_buff_struct.comm_length       = 0;
    com_buff_struct.protocol_xfer_status = IM_COMM_INUSE;

    /* Call intermec function to see next block data */
    status = im_rx_check_status(com_port);
  }
  else
  {
    eor_byte = '\0';
    printf("Rx Error = %XH\n", status);
  }
}

printf("ch: %xH, by: %xH\n", eor_char, eor_byte);

} while ( eor_byte != eor_char); /* Loop until reaching eor_char */

printf ("Receive Done\n");
}

```

*im\_receive\_buffer\_noprot*

---

## ***im\_receive\_buffer\_noprot***

**Purpose:** This function receives a text string from the designated port without using the active protocol. Only the PHIMEC.EXE protocol handler supports this function, which is often used to receive a host initialization string before beginning transmission.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_receive_buffer_noprot
    (IM_COM_PORT port_id,
     IM_USHORT user_length,
     IM_UCHAR far *data_buffer,
     IM_USHORT timeout,
     IM_UCHAR eom_char,
     IM_USHORT far *comm_length);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *user\_length* parameter is the maximum number of characters you can receive and must be at least 256 bytes.

The *data\_buffer* parameter is a far pointer to the data array where you want to place the received data. This buffer must hold at least 256 bytes.

The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

The *eom\_char* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any character.

**OUT Parameters:** The *comm\_length* parameter returns the actual number of bytes received.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install the PHIMEC.EXE protocol handler to use this function.

The difference between this function and *im\_receive\_buffer\_no\_wait* is that when *im\_receive\_buffer\_noprot* returns from the function call, the data has been read, the timeout has expired, or an error was encountered. When you call *im\_receive\_buffer\_no\_wait*, program execution continues without checking for received data or errors.

**See Also:** *im\_receive\_buffer\_no\_wait*, *im\_cancel\_rx\_buffer*, *im\_rx\_check\_status*

---

### Example

```

***** im_receive_buffer_no_protocol *****
/* Also with: im_cancel_rx_buffer */
/*
/* Note: Must have reader services and comm protocol handler installed to */
/* enable send/receive buffer functions. */
/* Run these TSR's at DOS prompt before running these tests: */
/* rservice */
/* phimec 1 ( 1 is COM1) */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <ctype.h>
#include <string.h>
#include "im20lib.h"
#include "immsg.h"

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/
static IM_UCHAR eor_char = 'Q'; /* Default end of receive char */

void main (void)
{
IM_STATUS status;
IM_UCHAR eor_byte; /* Uses 1st byte of receive to determine quit Rx*/
IM_UCHAR eom_char; /* End of message char */
IM_USHORT actual_length;
IM_UCHAR data_buffer[300];

/* Get the receive environment ready */
status = im_cancel_rx_buffer(com_port);

```

### *im\_receive\_buffer\_noprot*

```
printf("Rx Cancel: %xH\n", status);
printf("Type End of receive\nchar?");
eor_byte = toupper( getche());          /* Get End of Receive char */
if (isascii(eor_byte))
    eor_char = eor_byte;

printf ("Enter characters\n");
printf ("to be received\n");
printf ("from host\n");
printf ("CRLF to End of Line\n");      /* Each line end with a CR & LF */

/* Uses Carriage Return for End of Message character */
eom_char = 0x0d;                        /*CR */

do
{
    /* Call the Intermec function */
    status = im_receive_buffer_noprot(com_port, sizeof(data_buffer),
                                     (char far *)data_buffer, 50000,
                                     eom_char, &actual_length);

    if (actual_length > 0)
    {
        /* append CR & LF before write it into files */
        data_buffer[actual_length++] = '\x0D';
        data_buffer[actual_length++] = '\x0A';
        data_buffer[actual_length] = '\0';

        printf("%s", data_buffer);      /* Write data to on screen */
        eor_byte = toupper(data_buffer[0]);
    }
    else
    {
        eor_byte = '\0';
        printf("Rx Status: %xH\n", status);
    }

} while (eor_byte != eor_char);        /* Loop until reaching End of Receive*/

/* Show Exit receive no protocol message */
printf("Rx No Protocol Done\n");
}
```

---

## *im\_receive\_byte*

**Purpose:** This function receives one byte of data through the designated communications port. This function is identical to MS-DOS INT 14H service 02H.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_receive_byte
    (IM_COM_PORT port_id,
     IM_UCHAR *receive_byte);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

**OUT Parameters:** The *receive\_byte* parameter is a pointer to the byte received from the communications port.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

If you are using PHIMEC.EXE and want to receive a single byte, use *im\_receive\_buffer* with a buffer length of one instead of the *im\_receive\_byte* procedure.

This procedure will not work if linked.

**See Also:** *im\_transmit\_byte*

---

### *Example*

```
/****** im_receive_byte *****/
/* Uses Borland _bio_serialcom or Microsoft _bios_serialcom to init the */
/* com port for single byte receive. */
/* Operations. It sets up for 9600,E,7,1 on serial port */
/* To Terminate reception of bytes: */
/* To end the reception of bytes from the host, type <ESC> on JANUS */
/* and then type a Ctrl Z on the host */
/* Note: Phimec protocol handler must NOT be installed to run this routine */
/* Phpcstd protocol handler must be installed to run this routine */
```

## *im\_receive\_byte*

```
#include <stdio.h>
#include <dos.h>
#include <conio.h>
#include <stdlib.h>
#include <bios.h>
#include <string.h>
#include "im20lib.h"
#include "immsg.h"

/* Byte oriented defines */
#define COM1 0
#define SETTINGS (_COM_9600 | _COM_CHR7 | _COM_STOP1 | _COM_EVENPARITY )

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/

void main (void)
{
    IM_UCHAR inchar;
    IM_STATUS status;

    printf("\nChoose a protocol:\n");
    printf("1) PC Standard\n");
    printf("2) No protocol\n");

    if (getche() == '2') /* Call bios to initialize com port */
    {
        /* Communications port init */
        _bios_serialcom(_COM_INIT, COM1, SETTINGS);
    }

    printf ("\nChars received\n");
    printf ("<ESC> to quit\n");
    printf ("PC function\n");
    printf ("Ctrl Z to finish at\n");
    printf ("host\n");

    /* Phimec protocol handler must NOT be installed ...*/
    while (1)
    {
        /* Call Intermec function */
        status = im_receive_byte(com_port, &inchar);

        if ( IM_ISERROR(status))
        {
            printf("st: %xH\n", status);
            im_message(status);
        }
        else
            putchar (inchar);

        /* If User press <ESC> key, then stop program */
        if ( kbhit() && getch() == '\x1B')
            break;
    }
}
```

---

## *im\_receive\_input*

**Purpose:** This function gets input from the source and places it into the received buffer. You can use the `im_get_length` function after this function to get the input length.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_receive_input
    (IM_ORIGIN allowed,
     IM_UINT timeout,
     IM_ORIGIN *source,
     IM_CHAR *received);
```

**IN Parameters:** The *allowed* parameter defines the available input source and is one or more of these constants:

|                    |                                             |
|--------------------|---------------------------------------------|
| IM_LABEL_SELECT    | Label selected                              |
| IM_KEYBOARD_SELECT | Keypad selected                             |
| IM_COM1_SELECT     | COM1 selected                               |
| IM_COM2_SELECT     | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)                     |
| IM_ALL_SELECT      | All sources are selected                    |

The *timeout* parameter is the receive timeout period. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If `IM_INFINITE_TIMEOUT` is selected, the function will not return until the end of message character has been received.

## *im\_receive\_input*

**OUT Parameters:** The *source* parameter specifies the actual input source and is one of these constants:

|                    |                                             |
|--------------------|---------------------------------------------|
| IM_NO_SELECT       | No selection made                           |
| IM_LABEL_SELECT    | Label selected                              |
| IM_KEYBOARD_SELECT | Keypad selected                             |
| IM_COM1_SELECT     | COM1 selected                               |
| IM_COM2_SELECT     | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT     | COM4 selected (RF only)                     |

The *received* parameter is the variable where the data is placed.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** If input from more than one source is received before this function is called, the first available input is returned in this order: label, keypad, COM1, COM2, and COM4.

If you are using a communications port, you must install a protocol handler and call *im\_link\_comm*.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** *im\_get\_length*, *im\_get\_label\_symbology*, *im\_link\_comm*

---

### **Example**

```
/****** im_receive_input *****/
/* Also with: im_get_length */
/* im_link_comm */
/* im_unlink_comm */
/* im_get_input_mode */
/* im_set_input_mode */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include "im20lib.h"
#include "immsg.h"

#define COM_BUFSIZE 300 /* Allocate 300 bytes comm buffer */

void main (void)
{
IM_UCHAR input[300];
```



```

IM_USHORT length;
IM_MODE original_mode;
IM_UCHAR *com_buffer;
IM_ORIGIN in_source;
IM_ORIGIN source;
IM_STATUS status;

window(1, 1, 20, 16); /* Set the application text window */
clrscr(); /* Clear the screen */

printf("Demo im_receive_input\n'Q' to quit\n'C' to clear screen\n");

/* Allocate a comm buffer */
com_buffer = (char *) malloc(COM_BUFSIZE);

/* Get the previous input mode for restoring input mode later */
original_mode = im_get_input_mode();

/* Set Reader Wedge mode to program interface */
im_set_input_mode(IM_PROGRAMMER);

/* Link com_buffer to com1 */
im_link_comm(IM_COM1, com_buffer, COM_BUFSIZE);

/* Input loop */
do
{
    /* Set up input source */
    source = IM_LABEL_SELECT | IM_KEYBOARD_SELECT | IM_COM1_SELECT;

    /* Request input from label, keypad or com1 */
    status = im_receive_input(source, IM_INFINITE_TIMEOUT, &source, input);
    length = im_get_length(source);

    if (IM_ISGOOD(status))
    {
        /* Show the input source */
        if (source == IM_LABEL_SELECT)
            printf("\nLabel input:\n");
        else if (source == IM_KEYBOARD_SELECT)
            printf("\nKeybd input:\n");
        else if (source == IM_COM1_SELECT)
            printf("\nCom1 input:\n");
        /* Display input data */
        printf("%s\nInput length: %d\n", input, length);
    }
    else if (status == IM_APPLICATION_BREAK)
    {
        printf("application break detected");
    }
    else /* input error */
        printf("input error\n");

    /* Upper case first char of input for simplifying to test input */
    input[0] = toupper(input[0]);

    /*If the first char in string is 'C', then clear screen.*/
    if (input[0] == 'C')
        clrscr();
} while (input[0] != 'Q'); /* First number in string is 'Q', then stop */

```

### *im\_receive\_input*

```
/* Unlink com_buffer from com1 */  
im_unlink_comm(IM_COM1);  
  
/* Free allocated memory */  
free(com_buffer);  
  
/* Restore original input mode */  
im_set_input_mode(original_mode);  
}
```

---

## ***im\_rs\_installed***

**Purpose:** This function determines whether or not the reader services (RSERVICE.EXE) program is installed.

**Syntax:** `#include <im20lib.h>`  
`IM_STATUS im_rs_installed (void);`

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** None.

---

### ***Example***

```
/* ***** im_rs_installed ***** */
/* Also with: im_message */

#include <stdio.h>
#include "im20lib.h"

void main (void)
{
    printf("Check for reader\nservice installation\n");
    im_message( im_rs_installed() );
}
```

*im\_rx\_check\_status*

---

## ***im\_rx\_check\_status***

**Purpose:** This function directs the active protocol handler to check the communications port buffer status variable to determine if the application program has accepted the previous data. Use this function with the `im_receive_buffer_no_wait` function to receive input from multiple buffers.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_rx_check_status
    (IM_COM_PORT port_id);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this function.

**See Also:** `im_receive_buffer_no_wait`

---

### ***Example***

See example for `im_receive_buffer_no_wait`.

---

## *im\_serial\_protocol\_control*

**Purpose:** This function controls the protocol mode for a designated communications port and determines whether the receive mode is with or without protocol according to the input parameter. Any change clears the input buffer and resets the reader command parser.

Use this function to set the protocol when connected to a communications port. The return value indicates a success if the port is currently linked to the Virtual Wedge. If the port is not currently linked to the Virtual Wedge, the function returns an error.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_serial_protocol_control
    (IM_COM_PORT port_id,
     IM_PROTOCOL_CMD protocol,
     IM_UCHAR eom_char);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *protocol* parameter affects how incoming messages are received and is one of these constants:

|                  |                                   |
|------------------|-----------------------------------|
| IM_NO_CHANGE     | Keep the current protocol         |
| IM_PROTOCOL_OFF  | Turn the protocol OFF             |
| IM_PROTOCOL_ON   | Turn the protocol ON              |
| IM_NEW_TERM_CHAR | Use the new termination character |

The *protocol* parameter affects all incoming messages as follows:

- If `IM_NO_CHANGE` is specified, the protocol and end of message settings remain the same as the last time the function was called.
- If `IM_PROTOCOL_OFF` is specified, the incoming data is terminated with the specified end of message character. If the end of message character is null, the function terminates upon receiving the first character.

## *im\_serial\_protocol\_control*

- If IM\_PROTOCOL\_ON is specified, the incoming message is terminated with the end of message character of the active protocol.
- If IM\_NEW\_TERM\_CHAR is specified, IM\_PROTOCOL\_OFF is assumed and the new end of message character specified in the parameter list is used.

The *eom\_char* parameter is the end of message character needed to terminate input from the communications port. The character is normally a carriage return, but you can set it to any other character. An EOM character is required when using IM\_PROTOCOL\_OFF and IM\_NEW\_TERM\_CHAR for *protocol*.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** Requires *im\_link\_comm*.

The receive buffers are cleared whenever the protocol is turned ON or OFF. To change the termination character (or to not change the setting at all), use IM\_NEW\_TERM\_CHAR or IM\_NO\_CHANGE instead of toggling the protocol.

**See Also:** *im\_link\_comm*

---

### *Example*

```
***** im_serial_protocol_control *****  
/* Also with: im_set_input_mode */  
/* im_link_comm */  
/* im_unlink_comm */  
  
#include <stdio.h>  
#include <conio.h>  
#include <dos.h>  
#include <stdlib.h>  
#include <ctype.h>  
#include "immsg.h"  
#include "im20lib.h"  
  
#define COM_BUF_SIZE 300 /* Allocate 300 bytes for comm buffer */  
  
void main (void)  
{  
IM_UCHAR *com_buffer;  
IM_UCHAR input[256];
```

```

IM_ORIGIN  source;
IM_STATUS  status;
IM_CHAR    *msg_ptr;
int        sw_flag,
          order_flag;

window(1, 1, 20, 16);      /* Set the reader services text window */
clrscr();                  /* Clear the screen */
printf("Demo IM_SERIAL_PROTOCOL_CONTROL\n'Q' to quit\n");

/* Allocate a comm buffer */
com_buffer = (char *) malloc(COM_BUFSIZE);

/* Set Reader Wedge into PROGRAMMER mode */
im_set_input_mode(IM_PROGRAMMER);

/* Link com_buffer to com1 */
im_link_comm(IM_COM1, com_buffer, COM_BUFSIZE);

order_flag = 0;           /* Set flag to start from CR & LF */

/* Demo Input loop */
do
{
    sw_flag = order_flag % 3;
    switch (sw_flag)
    {
        case 0: /*Turn on protocol handle with EOM char CR & LF. */
            status = im_serial_protocol_control(IM_COM1, IM_PROTOCOL_ON, 0x0D);
            msg_ptr = "CR & LF";
            break;

        case 1: /* Turn off protocol handle with EOM char Ctrl-Z */
            status = im_serial_protocol_control(IM_COM1, IM_PROTOCOL_OFF, 0x1A);
            msg_ptr = "Ctrl-Z";
            break;

        case 2: /* Turn off protocol handle with EOM char Ctrl-Y */
            status = im_serial_protocol_control(IM_COM1, IM_PROTOCOL_OFF, 0x19);
            msg_ptr = "Ctrl-Y";
            break;
    }
    printf("\nEOM: %s, P-status: %x\n", msg_ptr, status);
    im_receive_input(IM_COM1, IM_INFINITE_TIMEOUT, &source, input);

    if ( source == IM_COM1_SELECT)
    {
        printf("%s\n", input);
    }
    else
        printf("error\n");
    order_flag++;
    input[0] = toupper(input[0]);
} while (input[0] != 'Q');

/* Unlink com_buffer from com1 */
im_unlink_comm(IM_COM1);
/* Free allocated memory */
free(com_buffer);

im_set_input_mode(IM_WEDGE);
}

```

*im\_set\_abort\_callback*

---

## ***im\_set\_abort\_callback***

**Purpose:** This function sets up the callback address for notification of an exit program reader command. It determines which function is activated when /\$ is received. For example, use this function when you are running a program and want to exit without using a warm boot.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_set_abort_callback
    (IM_ORIGIN source,
     void *notify_routine);
```

**IN Parameters:** The *source* parameter is one of these constants:

|                 |                                             |
|-----------------|---------------------------------------------|
| IM_LABEL_SELECT | No source selected                          |
| IM_COM1_SELECT  | COM1 selected                               |
| IM_COM2_SELECT  | COM2, scanner port selected (2010 and 2050) |
| IM_COM4_SELECT  | COM4 selected (RF only)                     |
| IM_ALL_SELECT   | All sources are selected                    |

The *notify\_routine* parameter is a pointer to the callback routine.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** IRL uses the /\$ as an exit command when received from a host or scanned from a label. This *im\_set\_abort\_callback* function allows you to specify a routine that is called whenever the /\$ is detected from the host or from the scanner. You can also use this capability from within a PSK application. The /\$ is called the IRL exit command, but the application can use it for actions other than exiting the program.

The callback is called by the Reader Wedge as soon as the /\$ is detected. The /\$ must be the only two characters in the string. Nothing occurs if the /\$ is in the middle of other characters. It is recommended that your callback routine be short (such as setting a flag or performing some other action).



Scan in the exit IRL program command to activate the abort callback. When the abort callback routine is called, the processor services an interrupt. The routine must reenables interrupts before doing any other interrupt-driven function such as writing to the screen.

If you use *im\_set\_abort\_callback* to set up a callback, you must use *im\_clear\_abort\_callback* before exiting your program. Otherwise, the Reader Wedge continues to call the callback each time the /\$ is detected. Since the callback is no longer at the address that the Reader Wedge calls, the result is unpredictable.

The notification *source* parameter replaces the previously set *source*. Only one callback routine can be submitted. On callback, the abort function's first parameter contains the origin of the abort program command. The second parameter is left for further expansion.

This command does not work in Wedge mode.

For this routine to work correctly, you must use the keyword *\_loads* to set the data segment in the callback routine.

Since the abort routine is called as an interrupt, all other interrupts are disabled until the system returns from the abort function or until an interrupt is explicitly enabled.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** *im\_clear\_abort\_callback*

## *im\_set\_abort\_callback*

---

### **Example**

```

/***** im_set_abort_callback *****/
/* Also with: im_clear_abort_callback */
/* im_set_input_mode */
/* im_standby_wait */
/* im_irlv */
/*
/* Note: When using Microsoft "C" compiler, Inside Abort_Callback routines */
/* avoid to call any run-time routines referring to __iob variable */
/* Since microsoft put __iob into another segment. */
/* Borlandc "C" compiler doesn't have this problem. */

#include <stdio.h>
#include <conio.h>
#include <dos.h>
#include "im20lib.h"
#include "immsg.h"

/* INTERNAL FUNCTIONS (EXPORTED) */
void _loadds Abort_Callback(unsigned short arg1, unsigned short arg2);

/* STATIC FUNCTIONS (KNOWN ONLY BY THIS FILE) */
static int abort_flag;

void main (void)
{
    IM_UCHAR input[256];
    IM_ORIGIN source;
    IM_USHORT cc;
    IM_DECTYPE symbol;

    /* FUNCTION BODY */
    window(1, 1, 20, 16); /* Set the application text window */
    clrscr(); /* Clear the screen */

    /* Display Demo message */
    printf("Demo IM_SET_ABORT_CALLBACK\n 'Q' to quit\n");

    /* Set Reader Wedge mode to program interface */
    im_set_input_mode(IM_PROGRAMMER);

    /* Set up abort callback notification hook */
    im_set_abort_callback(IM_ALL_SELECT, Abort_Callback);

    /* Clear the abort flag */
    abort_flag = 0;

    /* Demo's input loop */
    do
    {
        /* Test wait */
        printf("Start waiting for 3 seconds\n");
        im_standby_wait(3000);
        printf("Done waiting for 3 seconds\n");

        /* Test input IRL V */
        printf("IRL V test\n");

        /* Set source for labels and keypad */
        source = IM_LABEL_SELECT | IM_KEYBOARD_SELECT;
    }
}

```

```

/* Request input from Reader Wedge */
im_irl_v(IM_INFINITE_TIMEOUT,
        IM_ENABLE, IM_WEDGE_BEEP, IM_ENABLE,
        &source, input, &cc, &symbol);

/* Display the input */
printf("\n%s\n", input);

/* Show a message if abort command in IRL was parsed */
if (abort_flag)
{
    printf("\nAbort program parsed.\n%d\n", abort_flag);

    /* Clear the abort flag */
    abort_flag = 0;
}

} while (input[0] != 'Q' && input[0] != 'q' );

/* Clear abort call back notification hook */
im_clear_abort_callback();

/* Switch the Reader Wedge back to virtual Wedge mode */
im_set_input_mode(IM_WEDGE);
}

/*
*****
* PURPOSE: callback function for abort program reader command detection
*
* NOTE: Need enable interrupt for this callback function, because
*       abort program is disable interrupt when it call callback function.
*****
*/

void _loads Abort_Callback(IM_USHORT arg1, IM_USHORT arg2)
{
    /* Enable interrupt since the caller is disable the interrupt */
    _enable();
    /* Set the abort flag */
    abort_flag = arg1;

    /******
    /* Note: In Borlandc "C" compiler, printf() routine works          */
    /*       In Microsoft "C" compiler, all routines referring __iob  */
    /*       variable won't work. using routine (like putch()) or      */
    /*       directly output to console routine will work             */
    /******
    printf("\nabort arg:%d, %d\n", arg1, arg2); /* Does not work in Microsoft "C"*/
}

```

*im\_set\_contrast*

---

## ***im\_set\_contrast***

**Purpose:** This function sets the reader's LCD display contrast level. There are eight levels of contrast (0 to 7) from very light to very dark, which are the most frequently used contrast settings.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_set_contrast
(IM_UCHAR display_contrast_level);
```

**IN Parameters:** The *display\_contrast\_level* parameter is one of these constants:

|                 |         |
|-----------------|---------|
| IM_MIN_CONTRAST | Level 0 |
| IM_AVE_CONTRAST | Level 4 |
| IM_MAX_CONTRAST | Level 7 |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The functions *im\_set\_contrast* and *im\_get\_contrast* use a scale of 0 to 7 that is related to the scale of 0 to 31 used by *im\_increase\_contrast* and *im\_decrease\_contrast*. The following table compares the two scales.

| This Value on<br>Scale 0 to 7 | Equates to This Value on<br>Scale 0 to 31 | Contrast<br>Level |
|-------------------------------|-------------------------------------------|-------------------|
| 0                             | 10                                        | Very light        |
| 1                             | 12                                        |                   |
| 2                             | 14                                        |                   |
| 3                             | 16                                        |                   |
| 4                             | 18                                        |                   |
| 5                             | 20                                        |                   |
| 6                             | 22                                        | Very dark         |
| 7                             | 24                                        |                   |

This function has no effect on the JANUS 2050.

**See Also:** *im\_get\_contrast*, *im\_decrease\_contrast*, *im\_increase\_contrast*

---

**Example**

```
/****** im_set_contrast *****/
/* Also with: im_get_contrast */

#include <stdio.h>
#include <conio.h>
#include "im20lib.h"
#include "immsg.h"

void main (void)
{
    IM_STATUS status;
    IM_UCHAR  contrast;
    IM_UCHAR  level;

    clrscr();

    for (level = 0; level < 10; level++)
    {
        status = im_set_contrast(level);

        /* If the most significant bit is set, there is an error */
        if (IM_ISERROR(status))
            printf("\nSet Contrast error = %x\n", status);
        else
            printf("\nContrast set to %d\n", level);

        status = im_get_contrast(&contrast);

        /* If the most significant bit is set, there is an error */
        if (IM_ISERROR(status))
            printf("\nGet Contrast error = %x\n", status);
        else
            printf("\nContrast is %d\n", level);

        /* Pause to see result */
        printf("\nAny key to continue");
        getch();
    }
}
```

*im\_set\_control\_key*

---

## ***im\_set\_control\_key***

**Purpose:** This function enables or disables the **Ctrl** key setting. When disabled, none of the key combinations that use the **Ctrl** key will work. For example, the warm boot key sequence **Ctrl-Alt-Del** will not work.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_set_control_key
    (IM_CONTROL control_key);
```

**IN Parameters:** The *control\_key* parameter is one of these constants:

|            |                             |
|------------|-----------------------------|
| IM_ENABLE  | Enable the <b>Ctrl</b> key  |
| IM_DISABLE | Disable the <b>Ctrl</b> key |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_get\_control\_key*

---

### ***Example***

See example for *im\_get\_control\_key*.

---

## *im\_set\_display\_mode*

**Purpose:** This function sets the size mode, video mode, scroll mode, and character height of the display.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_set_display_mode
    (IM_STD_SIZE_MODE size_mode,
    IM_STD_VIDEO_MODE video_mode,
    IM_SCROLL_MODE scroll_mode,
    IM_CHARACTER_HEIGHT char_ht);
```

**IN Parameters:** The *size\_mode* parameter is required and is one of these constants:

|                    |                                   |
|--------------------|-----------------------------------|
| IM_SIZE_MODE_80X25 | 80 x 25 text mode                 |
| IM_SIZE_MODE_20X16 | 20 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_20X8  | 20 x 8 text mode (2010 and 2020)  |
| IM_SIZE_MODE_10X16 | 10 x 16 text mode (2010 and 2020) |
| IM_SIZE_MODE_10X8  | 10 x 8 text mode (2010 and 2020)  |

If the *size\_mode* parameter is set to IM\_SIZE\_MODE\_80X25, you also need to set the video mode, scroll mode, and character height. If any other *size\_mode* is set, the video mode, scroll mode, and character height are automatically set.

The *video\_mode* parameter requires IM\_SIZE\_MODE\_80X25. The standard PC BIOS supports up to video mode 13H. The reader only supports up to video mode 6. You can also set video modes 0 through 3 with IC.EXE.

The *video\_mode* parameter is one of these constants:

|                     |                                         |
|---------------------|-----------------------------------------|
| IM_STD_VIDEO_MODE_0 | 40 x 25 (use for double-wide character) |
| IM_STD_VIDEO_MODE_1 | 40 x 25 (use for double-wide character) |
| IM_STD_VIDEO_MODE_2 | 80 x 25                                 |
| IM_STD_VIDEO_MODE_3 | 80 x 25                                 |
| IM_STD_VIDEO_MODE_4 | 300 x 200 2-color                       |
| IM_STD_VIDEO_MODE_5 | 300 x 200 monochrome                    |
| IM_STD_VIDEO_MODE_6 | 640 x 200 2-color (2050)                |

## *im\_set\_display\_mode*

The *scroll\_mode* requires IM\_SIZE\_MODE\_80X25 and is one of these constants:

|                     |                                            |
|---------------------|--------------------------------------------|
| IM_LCD_SCROLL_AT_25 | Scroll at line 25                          |
| IM_LCD_SCROLL_AT_16 | Scroll at line 16 (2010 and 2020)          |
| IM_LCD_SCROLL_AT_13 | Scroll at line 13 (2050 and double height) |
| IM_LCD_SCROLL_AT_8  | Scroll at line 8 (2010 and 2020)           |

The *char\_ht* requires IM\_SIZE\_MODE\_80X25 and is one of these constants:

|                         |                                                                                                       |
|-------------------------|-------------------------------------------------------------------------------------------------------|
| IM_STANDARD_CHAR_HEIGHT | Standard height characters. You must have set the <i>scroll_mode</i> to scroll at line 25 or line 16. |
| IM_DOUBLE_CHAR_HEIGHT   | Double height characters. You must have set the <i>scroll_mode</i> to scroll at line 8 or line 13.    |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** Changing display modes clears the screen.

The IRL input commands do not display correctly when the display is in 80 x 25 mode and the cursor has scrolled off the display. To alleviate this problem, set the display mode to one of the other modes, such as 20 x 16.

If your application uses an 8 x 10 or 16 x 10 (double width) display size and direct video addressing, the application will lock up because the display size does not provide enough characters to be detected by the hardware and displayed to the JANUS reader's screen. To avoid this problem, you must write the video using the BIOS when using a double width display size. For example, you can use the Borland global variable *directvideo*, which determines whether video writing goes to BIOS or direct video.

**Note:** Intermec recommends that all applications write video using the BIOS instead of using direct video addressing.



The mode does not change if there are conflicting parameters, such as trying to set the *video\_mode* to 16 lines and the *scroll\_mode* at line 8.

If you want to use one of the graphics modes, use the appropriate function call provided by your programming language. For example, Borland uses `initgraph` and Microsoft uses `_setvideomode`.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

**See Also:** `im_get_display_mode`, `im_set_follow_cursor`

---

### *Example*

See example for `im_viewport_setxy`.

*im\_set\_follow\_cursor*

---

## ***im\_set\_follow\_cursor***

**Purpose:** When the display is in 80 x 25 mode, the viewport follows the cursor as it moves. This function enables or disables the follow-the-cursor feature.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_set_follow_cursor
    (IM_CONTROL follow_cursor);
```

**IN Parameters:** The *follow\_cursor* parameter is one of these constants:

|            |                                |
|------------|--------------------------------|
| IM_ENABLE  | Enable follow-the-cursor mode  |
| IM_DISABLE | Disable follow-the-cursor mode |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The display must be in 80 x 25 mode for this function to work correctly.

This function has no effect on the JANUS 2050.

**See Also:** *im\_get\_follow\_cursor*

---

### ***Example***

See example for *im\_get\_follow\_cursor*.

---

## *im\_set\_input\_mode*

**Purpose:** This function clears the input buffers and sets the input manager to one of three modes: Wedge, Programmer, or Desktop.

**Syntax:**

```
#include <im20lib.h>
void im_set_input_mode (IM_MODE mode);
```

**IN Parameters:** The *mode* parameter is one of these constants:

|               |                 |
|---------------|-----------------|
| IM_WEDGE      | Wedge mode      |
| IM_PROGRAMMER | Programmer mode |
| IM_DESKTOP    | Desktop mode    |

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see “Runtime Requirements” earlier in this chapter.

There are three different reader input modes: Wedge, Programmer, or Desktop. These modes affect how the reader interprets and stores input.

**Wedge Mode** Keypad and label inputs go into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services (RSERVICE.EXE) is loaded. Use Wedge mode when the reader is running an application that uses the Virtual Wedge. When in this mode, use standard input functions to retrieve keypad or label input.

Wedge mode does not take full advantage of the reader’s power management capabilities. You will probably notice reduced battery life when the reader is in this mode compared to either Programmer or Desktop mode. For more information on power management, see Chapter 4, “Advanced Programming.”

**Programmer Mode** Inputs are echoed to the screen. Reader commands are executed and saved. Use Programmer mode when the reader is executing IRL commands. In general, when you are running an application that uses the function libraries or software interrupts, the reader should be in Programmer mode.

*im\_set\_input\_mode*

**Desktop Mode** The application is responsible for retrieving and displaying input. Use Desktop mode when you need detailed information about a pressed key. Each character returned consists of four bytes: the ASCII code, scan code, and two bytes for the keyboard flags (**Shift**, **Ctrl**, **Alt**). See the structure `IM_KEYCODE` in `IM20LIB.H` for further details.

For more information about reader input modes, see “Reader Input Modes” in Chapter 4, “Advanced Programming.”

Upon exiting the program, set the input mode to `IM_WEDGE` so that DOS will work as expected.

**See Also:** `im_get_input_mode`, `im_receive_input`

---

**Example**

See example for `im_get_input_mode`.

---

## ***im\_set\_keyclick***

**Purpose:** Each time you press a key, the reader can emit a click. This function enables or disables the keyclick.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_set_keyclick
    (IM_CONTROL keyclick_status);
```

**IN Parameters:** The *keyclick\_status* parameter is one of these constants:

|            |                      |
|------------|----------------------|
| IM_ENABLE  | Enable the keyclick  |
| IM_DISABLE | Disable the keyclick |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** `im_get_keyclick`

---

### ***Example***

See example for `im_get_keyclick`.

*im\_set\_viewport\_lock*

---

## ***im\_set\_viewport\_lock***

**Purpose:** This function enables or disables the keys that move the viewport.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_set_viewport_lock
    (IM_CONTROL viewport_lock);
```

**IN Parameters:** The *viewport\_lock* parameter is one of these constants:

|            |                     |
|------------|---------------------|
| IM_ENABLE  | Lock the viewport   |
| IM_DISABLE | Unlock the viewport |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The display must be in 80 x 25 mode for this function to work correctly.

This function controls whether the viewport moves (unlocked) or does not move (locked) when the cursor movement keys are pressed.

This function has no effect on the JANUS 2050.

**See Also:** *im\_get\_viewport\_lock*, *im\_set\_follow\_cursor*

---

### ***Example***

See example for *im\_get\_viewport\_lock*.

---

## ***im\_set\_warm\_boot***

**Purpose:** This function enables or disables the **Ctrl-Alt-Del** warm boot key sequence. When disabled, the **Ctrl-Alt-Del** key sequence does not reboot the reader.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_set_warm_boot
    (IM_CONTROL warm_boot);
```

**IN Parameters:** The *warm\_boot* parameter is one of these constants:

|            |                                       |
|------------|---------------------------------------|
| IM_ENABLE  | Enable <b>Ctrl-Alt-Del</b> warm boot  |
| IM_DISABLE | Disable <b>Ctrl-Alt-Del</b> warm boot |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** *im\_get\_warm\_boot*

---

### ***Example***

See example for *im\_get\_warm\_boot*.

*im\_setup\_trx*

---

## ***im\_setup\_trx***

**Purpose:** This function sets up the protocol parameters for a DCM transaction. If your program calls a DCM function without first calling *im\_setup\_trx*, then the default protocol values listed below are used.

For a detailed discussion of programming database transactions, see Chapter 5, "Using the PSK With DCM."

**Syntax:**

```
#include "im20lib.h"
IM_USHORT im_setup_trx
    (IM_COM_PORT port_id,
     IM_USHORT tx_timeout,
     IM_USHORT rx_timeout,
     IM_USHORT db_protocol,
     IM_UCHAR sys_delimiter,
     IM_UCHAR parse_char,
     IM_USHORT packet_max_len,
     int hsafety);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                |
|---------|----------------|
| IM_COM1 | COM1 (Default) |
| IM_COM4 | COM4 (RF only) |

The *tx\_timeout* parameter is the transmit timeout and is a numeric value in seconds or IM\_INFINITE\_TIMEOUT. The numeric range is between 0 and 65,000 seconds. The default is IM\_INFINITE\_TIMEOUT.

The *rx\_timeout* parameter is the receive timeout and is a numeric value in seconds or IM\_INFINITE\_TIMEOUT. The numeric range is between 0 and 65,000 seconds. The default is IM\_INFINITE\_TIMEOUT.



The *db\_protocol* parameter is one or more of these constants:

|                  |                                                                                                                                               |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| IM_DBPACE_ENABLE | Enable pacing for database read. The database sends one record to the reader and then waits for a request for the next record. Default is on. |
| IM_BATCH_ENABLE  | Store all records in standby file, if one is enabled with <i>hsafety</i> . Default is off, no standby file.                                   |
| IM_DOBEST_ENABLE | Ignore NAK and continue sending records when uploading standby records. Default is off: stop sending records on NAK.                          |

The *sys\_delimiter* parameter is the default transaction ID delimiter set in DCM. Default is a comma (,).

The *parse\_char* parameter is the user-defined, data field-specific delimiter set in DCM. Default is a comma (,).

The *packet\_max\_len* parameter defines the maximum length for a transaction packet and is one of these values:

|       |                                                        |
|-------|--------------------------------------------------------|
| 0     | Use the default value and do not send a value.         |
| -1    | Use the previous setting.                              |
| 1-256 | Set the maximum length to this number. Default is 256. |

The *hsafety* parameter is the file handler for the standby file. Valid values are:

|            |                                                                                                                   |
|------------|-------------------------------------------------------------------------------------------------------------------|
| 0          | No standby file. Default.                                                                                         |
| <i>num</i> | Use a standby file. A nonzero value that is the file handler created from <code>open( )</code> . See Notes below. |

**OUT Parameters:** None.

**Return Value:** This function returns one of the status codes from the following table. For more information on these return codes, see Chapter 5, “Using the PSK With DCM.”

|                 |      |                                      |
|-----------------|------|--------------------------------------|
| IM_DCM_OK       | 1A00 | Protocol parameters set successfully |
| IM_DCM_FILE_ERR | 9A09 | Standby file I/O error               |

*im\_setup\_trx*

**Notes:** To use a standby file, you must set *hSafety* by opening the file. The action of the standby file is determined by IM\_BATCH\_ENABLE.

If IM\_BATCH\_ENABLE is off, only transactions that cannot be sent are logged into the file. Usually this happens when the transmission times out.

If IM\_BATCH\_ENABLE is on, then all transactions are logged into the standby file. To transmit the standby file, you must set IM\_BATCH\_ENABLE to off, or use *im\_standard\_trx* with IM\_ZIP\_STANDBY to flush the standby records.

See Chapter 5, "Using the PSK With DCM."

**See Also:** *im\_standard\_trx*, *im\_parse\_host\_response*

---

**Example**

See the sample program in Chapter 5, "Using the PSK With DCM."

---

## *im\_sound*

**Purpose:** This function generates a beep of specified pitch and duration. For example, use a soft beep for library use, a loud beep for manufacturing use, or a unique beep to distinguish between other readers.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_sound
    (IM_USHORT pitch,
     IM_USHORT duration,
     IM_USHORT volume);
```

**IN Parameters:** The *pitch* parameter is the frequency of the beep you want the reader to make. The numeric range for *pitch* is from 20 to 20,000 Hz. You can also use one of these constants:

|                   |         |
|-------------------|---------|
| IM_HIGH_PITCH     | 2400 Hz |
| IM_LOW_PITCH      | 1200 Hz |
| IM_VERY_LOW_PITCH | 600 Hz  |

The *duration* parameter is the length of the beep. The numeric range for *duration* is from 1 to 65,000 ms. You can also use one of these constants:

|                   |       |
|-------------------|-------|
| IM_BEEP_DURATION  | 50 ms |
| IM_CLICK_DURATION | 4 ms  |

The *volume* parameter is one of these constants:

|                      |                              |
|----------------------|------------------------------|
| IM_OFF_VOLUME        | Volume is off                |
| IM_QUIET_VOLUME      | Volume is quiet              |
| IM_NORMAL_VOLUME     | Volume is normal             |
| IM_LOUD_VOLUME       | Volume is loud               |
| IM_EXTRA_LOUD_VOLUME | Volume is extra loud         |
| IM_CURRENT_VOLUME    | Volume is the current volume |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

## *im\_sound*

---

### **Example**

```
/****** im_sound *****/
#include <time.h>
#include <conio.h>
#include <im20lib.h>

enum NOTES /* Enumeration of notes and frequencies */
{
    C0 = 262, D0 = 296, E0 = 330, F0 = 349, G0 = 392, A0 = 440, B0 = 494,
    C1 = 523, D1 = 587, E1 = 659, F1 = 698, G1 = 784, A1 = 880, B1 = 988,
    EIGHTH = 125, QUARTER = 250, HALF = 500, WHOLE = 1000, END = 0
} song[] = /* Array initialized to notes of song */
{
    C1, HALF, G0, HALF, A0, HALF, E0, HALF, F0, HALF, E0, QUARTER,
    D0, QUARTER, C0, WHOLE, END
};

/* Predefined the play volume */
IM_USHORT volume[] = {
    IM_NORMAL_VOLUME, /* Play normal volume */
    IM_EXTRA_LOUD_VOLUME, /* Play extra loud volume */
    IM_QUIET_VOLUME, /* Play quiet volume */
    IM_NORMAL_VOLUME /* Play normal volume */
};

void main (void)
{
    int note;
    int index;

    /* Play 4 times with 5 seconds dealy between each play */
    for ( index = 0; index < 4; index++)
    {
        for ( note = 0; song[note] != 0; note += 2 )
            im_sound( song[note], song[note + 1], volume[index]);

        /* Delay 5 seconds for next throughput*/
        im_standby_wait(5000);
    }
}
```

---

## im\_standard\_trx

**Purpose:** This function packs reader data into a DCM transaction. The function packs the data, transmits the packed transaction through a communications port, and then reads the host response message from the communications port.

For a detailed discussion of programming database transactions, see Chapter 5, “Using the PSK With DCM.”

**Syntax:**

```
#include "im20lib.h"
IM_USHORT im_standard_trx
    (IM_UCHAR *trans_id,
     IM_UCHAR request_type,
     IM_UCHAR *send_var_array[],
     IM_USHORT max_str_len,
     IM_UCHAR *ret_string,
     IM_DCMSTRN ret_array[],
     IM_UCHAR *oper_type);
```

**IN Parameters:** The *\*trans\_id* parameter is a pointer to the transaction ID string. The transaction ID must match the ID already defined in DCM. See the example in Chapter 5, “Using the PSK With DCM.”

The *request\_type* parameter is associated with the transaction ID and either accesses the remote database or manipulates the standby file. The *request\_type* is one of these constants:

### For Accessing the Remote Database

|                  |   |                              |
|------------------|---|------------------------------|
| IM_DBRQT_DATA    | D | Request data                 |
| IM_DBRQT_NEXTROW | N | Request next row             |
| IM_DBRQT_DISCARD | S | Delete the following records |

### For Manipulating the Standby File

|                   |   |                                                                              |
|-------------------|---|------------------------------------------------------------------------------|
| IM_ERROR_RECORD   | E | Report error record without advancing the record pointer in the standby file |
| IM_ADVANCE_RECORD | A | Report error record and advance the record pointer in the standby file       |
| IM_ZIP_STANDBY    | Z | Flush the standby records                                                    |

*im\_standard\_trx*

The *\*send\_var\_array[]* parameter is valid only when *request\_type* is "D." It is a pointer to the array containing the data to send to the database. Each element in the array corresponds to a DCM transaction field.

The *max\_str\_len* parameter is the maximum length of the return string buffer.

**OUT Parameters:** The *\*ret\_string* parameter is a pointer to the return string buffer. The buffer contains the database server's transaction message unless a timeout occurred.

If the reader receives IM\_DCM\_TIMEOUT, then the communication error status is placed in the first two bytes of the return buffer. You can check this communication status code against the list in Appendix A, "Status Codes."

The return string buffer must be large enough to hold a complete packet from the controller.

The *ret\_array[]* parameter is the array containing pointers to the variables that hold the data returned from the database. The received data field is parsed and then placed into the variables.

The *\*oper\_type* parameter is a pointer to the operation type returned by the remote database and is one of these constants:

|               |   |                                  |
|---------------|---|----------------------------------|
| IM_DB_READ    | R | Read records from the database   |
| IM_DB_INSERT  | W | Write records to the database    |
| IM_DB_UPDATE  | U | Update records in the database   |
| IM_DB_DELETE  | D | Delete records from the database |
| IM_DB_UNKNOWN | X | Unknown                          |

**Return Value:** This function returns one of the status codes from the following table. For more information on these return codes, see Chapter 5, "Using the PSK With DCM."

| Return Code          | Hex  | Description                                                                                           |
|----------------------|------|-------------------------------------------------------------------------------------------------------|
| IM_DCM_OK            | 1A00 | Transaction successful<br>Retrieved record from standby file<br>All standby records sent successfully |
| IM_DCM_ACK_RCD       | 1A01 | Transaction successful, ACK                                                                           |
| IM_DCM_MSG_RCD       | 1A10 | Received message on Read operation                                                                    |
| IM_DCM_NAK_RCD       | 5A02 | Transaction failed, NAK received                                                                      |
| IM_DCM_NO_RECORD     | 5A07 | Standby file is empty                                                                                 |
| IM_DCM_TRUNCATED     | 5A11 | Data was truncated                                                                                    |
| IM_DCM_EXCESSFIELD   | 5A12 | Too many fields                                                                                       |
| IM_DCM_STANDBY       | 5A20 | Record stored in standby file successfully                                                            |
| IM_DCM_STANDBY_TXERR | 5A21 | Record stored in standby file, but upload standby error                                               |
| IM_DCM_NOTRANSMIT    | 9A03 | Transmit failed<br>Transmit channel error                                                             |
| IM_DCM_TIMEOUT       | 9A04 | Receive port timeout                                                                                  |
| IM_DCM_HEAD_ERR      | 9A05 | Packet header error                                                                                   |
| IM_DCM_TRANSID_ERR   | 9A06 | Missing transaction ID                                                                                |
| IM_DCM_FILE_ERR      | 9A08 | Standby file I/O error                                                                                |
| IM_DCM_NO_HANDLE     | 9A09 | Missing standby file                                                                                  |
| IM_DCM_FILLED        | 9A40 | Buffer overflow                                                                                       |
| IM_DCM_FILLED_TXERR  | 9A41 | Buffer overflow with upload standby error                                                             |

**Notes:** You can use the *\*oper\_type* and *request\_type* to verify that the database, the DCM interface, and the JANUS transaction are configured properly. For example, if the *request\_type* is IM\_DBRQT\_DATA (read or write), but the *\*oper\_type* is IM\_DB\_DELETE (delete), then you need to correct the configuration.

See Chapter 5, “Using the PSK With DCM.”

**See Also:** im\_setup\_trx, im\_parse\_host\_response

---

### Example

See the sample program in Chapter 5, “Using the PSK With DCM.”

*im\_standby\_wait*

---

## ***im\_standby\_wait***

**Purpose:** This function requests that reader services wait in standby mode for a specific period of time. You use this function to suspend the reader for a length of time to save the battery power.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_standby_wait
    (IM_UINT timeout);
```

**IN Parameters:** The *timeout* parameter is the amount of time to wait in standby mode. You can exit the function before data is received or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** None.

---

### ***Example***

See example for `im_irl_a`.



---

## *im\_transmit\_buffer*

**Purpose:** This function transmits the contents of a data buffer through a designated communications port. This function continues operating until the buffer transmission is complete or until an error status is detected.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_transmit_buffer
    (IM_COM_PORT port_id,
     IM_USHORT user_length,
     IM_UCHAR far *data_buffer,
     IM_USHORT timeout);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *user\_length* parameter is the length of the data string that you want to transmit.

The *data\_buffer* parameter is a far pointer to the data array that you want to transmit.

The *timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

## *im\_transmit\_buffer*

**Notes:** You must install a protocol handler to use this function.

**See Also:** `im_receive_buffer`, `im_transmit_buffer_no_wait`, `im_transmit_buffer_noprot`

---

### *Example*

```
/****** im_transmit_buffer ******/
/* Also with: im_cancel_tx_buffer */
/* Note: Must have reader services and comm protocol handler installed to */
/* enable send/receive buffer functions. */
/* Run these TSR's at DOS prompt before running these tests: */
/* rservice */
/* phimec 1 ( 1 is COM1) */

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <string.h>
#include "im20lib.h"
#include "immsg.h"

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/

static IM_UCHAR *data_str[] = {
    "Hi There, It must have three lines down the road from this demo",
    "The line 2 demonstration proves the transmit buffer is working",
    "The demonstration of the transmit buffer is Done",
    NULL
};

void main (void)
{
    int index;
    size_t actual_count;
    IM_STATUS status;
    IM_UCHAR data_buffer[160];

    /* Call im_cancel_tx_buffer to initialize the communications port and its buffer */
    status = im_cancel_tx_buffer(com_port);
    printf("Cancel Tx status: %xH\n", status);

    /* Sending data string loop until it reaches NULL */
    for (index =0; data_str[index] != NULL; index++)
    {
        /* Copy string to big buffer */
        strcpy(data_buffer, data_str[index]);
        actual_count = strlen(data_buffer); /* Get its length */

        /* Call Intermec function, timeout within 50000 milliseconds */
        status = im_transmit_buffer(com_port, actual_count, data_buffer, 50000);

        if (IM_ISSUCCESS(status))
            printf("Line %d Sent\n", index + 1);
        else
            printf("Transmit error\nStatus = %xH\n", status);
    }
    printf("Transmit Done\n");
}
```

---

## ***im\_transmit\_buffer\_no\_wait***

**Purpose:** This function transmits the contents of a buffer and passes control back to its client.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_transmit_buffer_no_wait
    (IM_COM_PORT port_id,
     IM_COM_DATA_BUFFER far *data_struct);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *data\_struct* parameter is a far pointer to the data array that you want to transmit.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this function.

This function differs from *im\_transmit\_buffer* in that the client must set the buffer structure and monitor the buffer status until transmission is complete.

Use this function for multiple buffer transmissions in conjunction with checking the status in *data\_struct*.

You must build and maintain a *data\_struct* of the type *IM\_COM\_DATA\_BUFFER* as described in *IM20LIB.H*.

**See Also:** *im\_transmit\_buffer\_noprot*, *im\_cancel\_tx\_buffer*

## *im\_transmit\_buffer\_no\_wait*

---

### **Example**

```
/****** im_transmit_buffer_no_wait *****/
/* Also with: im_cancel_tx_buffer */
/* Note: Must have reader services and comm protocol handler installed to */
/* enable send/receive buffer functions. */
/* Run these TSR's at DOS prompt before running these tests: */
/* rservice */
/* phimec 1 ( 1 is COM1) */

#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "im20lib.h"
#include "immsg.h"

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/

static IM_UCHAR *data_str[] = {
    "Hi There, It must have four lines down the road from this demo\r",
    "The line 2 demonstration proves the Transmit Buffer No Wait working\r",
    "The line 3 demonstration proves the Transmit Buffer No Wait working\r",
    "The demonstration of the Transmit Buffer No Wait is Done\r",
    NULL
};

void main (void)
{
    IM_USHORT index;
    IM_COM_DATA_BUFFER com_buff_struct; /*data buffer structure for receive/transmit */
    IM_STATUS status;
    IM_UCHAR data_buff[300];

    /* Get the transmit environment ready */
    status = im_cancel_tx_buffer(com_port);
    printf("Cancel Tx status: %xH\n", status);

    /* Transmitting data string loop until it reaches NULL */
    for (index =0; data_str[index] != NULL; index++)
    {
        /* Copy string to transmit into big buffer */
        strcpy(data_buff, data_str[index]);

        /* Set up comm buffer parameters */
        com_buff_struct.command = IM_CU_TRANSMIT;
        com_buff_struct.user_length = strlen(data_buff);
        com_buff_struct.comm_length = 0;
        com_buff_struct.protocol_mode = IM_NO_PROTOCOL;
        com_buff_struct.eom_char = 0;
        com_buff_struct.data_ptr = (char far *)data_buff;
        com_buff_struct.protocol_xfer_status = IM_COMM_INUSE;

        /* Call Intermec routine */
        status = im_transmit_buffer_no_wait(com_port, (IM_COM_DATA_BUFFER far *)
            &com_buff_struct);

        if (IM_ISSUCCESS(status))
        {
            /* Wait for data transfer to complete */
            while (com_buff_struct.protocol_xfer_status == IM_COMM_INUSE)
                ; /* Waiting loop, end while */
        }
    }
}
```

*im\_transmit\_buffer\_no\_wait*

2

```
        printf("Line %d Sent\n", index + 1);
    }
    else
    {
        printf("Tx Error = %XH\n", status);
        printf("Buffer not sent\n");
    }
} /* for */
printf ("Transmit Done\n");
}
```

*im\_transmit\_buffer\_noprot*

---

## ***im\_transmit\_buffer\_noprot***

**Purpose:** This function transmits a buffer without protocol and sends only the specified number of characters.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_transmit_buffer_noprot
    (IM_COM_PORT port_id,
     IM_USHORT user_length,
     IM_UCHAR far *data_buffer
     IM_USHORT timeout);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *user\_length* parameter is the maximum number of bytes to transmit.

The *data\_buffer* parameter is a far pointer to the data array that you want to transmit.

The *timeout* parameter is the transmission timeout period. You can exit the function before data is sent or before the timeout occurs by performing an application break sequence (see your JANUS user's manual). The return status indicates whether the function was successful, a timeout occurred, or the application break was received.

The *timeout* parameter is a number or one of these constants:

|                     |               |
|---------------------|---------------|
| 1 to 65,534 ms      | Numeric range |
| IM_ZERO_TIMEOUT     | No wait       |
| IM_INFINITE_TIMEOUT | Wait forever  |

If IM\_INFINITE\_TIMEOUT is selected, the function will not return until the end of message character has been received.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler other than PHPCSTD.EXE to use this function.

If an existing transmit client is linked to the host, you must issue a cancel command first.

**See Also:** im\_transmit\_buffer\_no\_wait, im\_cancel\_tx\_buffer, im\_transmit\_buffer

---

### Example

```

/***** im_transmit_buffer_noprot *****/
/* Also with: im_cancel_tx_buffer */
/* Note: Must have reader services and comm protocol handler installed to */
/* enable send/receive buffer functions. */
/* Run these TSR's at DOS prompt before running these tests: */
/* rservice */
/* phimec 1 ( 1 is COM1) */

#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "im20lib.h"
#include "immsg.h"

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/

static IM_UCHAR *data_str[] = {
    "Hi There, It must have three lines down the road from this demo",
    "The line 2 demo proves the Transmit Buffer No Protocol is working",
    "The demonstration of the Transmit Buffer No Protocol is Done",
    NULL
};

void main (void)
{
    IM_STATUS status;
    IM_USHORT index;
    IM_UCHAR data_buffer[300];

    /* PHIMEC protocol handler must be installed to run this routine */
    /* It only works with PHIMEC protocol */

    /* Get the transmit environment ready */
    status = im_cancel_tx_buffer(com_port);
    printf("Cancel Tx status: %xH\n", status);

    /* Sending data string loop until it reaches NULL */
    for (index =0; data_str[index] != NULL; index++)
    {
        /* Copy string to transmit into big buffer */
        strcpy(data_buffer, data_str[index]);

        /* Call Intermec routine with infinite timeout */
        status = im_transmit_buffer_noprot(com_port, strlen(data_buffer),
   data_buffer, IM_INFINITE_TIMEOUT);
    }
}

```

*im\_transmit\_buffer\_noprot*

```
    if (IM_ISSUCCESS(status))
        printf("Line %d Sent\n", index + 1);
    else
        printf("Tx Error\nStatus = %xH\n", status);
}
printf("Tx No Protocol Done\n");
}
```



---

## *im\_transmit\_byte*

**Purpose:** This function transmits one byte of data out from the designated communications port. This function is identical to MS-DOS INT 14H Service 01H.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_transmit_byte
    (IM_COM_PORT port_id,
     IM_UCHAR transmit_byte);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

The *transmit\_byte* parameter is the byte of data to transmit.

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function requires the PC standard protocol handler PHPCSTD.EXE.

Intermec recommends using *im\_transmit\_buffer* (with a *user\_length* of one) instead of using *im\_transmit\_byte*.

You can use this function for an acknowledgment.

**See Also:** *im\_receive\_byte*, *im\_transmit\_buffer*

## *im\_transmit\_byte*

---

### **Example**

```
/****** im_transmit_byte *****/
/* Uses Borland _bio_serialcom or Microsoft _bios_serialcom to init the */
/* com port for single byte. */
/* Operations. It sets up for 9600,E,7,1 on serial port */
/* Note: Phimec protocol handler must NOT be installed to run this routine */

#include <stdio.h>
#include <dos.h>
#include <conio.h>
#include <stdlib.h>
#include <bios.h>
#include <string.h>
#include "im20lib.h"
#include "immsg.h"

/* Byte oriented defines */
#define COM1 0
#define SETTINGS (_COM_9600 | _COM_CHR7 | _COM_STOP1 | _COM_EVENPARITY )

static IM_COM_PORT com_port = IM_COM1; /* Uses COM1*/

void main (void)
{
    IM_UCHAR outchar;
    IM_STATUS status;

    printf("\nChoose a protocol:\n");
    printf("1) PC Standard\n");
    printf("2) No protocol\n");

    if (getche() == '2') /* Call bios to initialize com port */
    {
        /* Communications port init */
        _bios_serialcom(_COM_INIT, COM1, SETTINGS);
    }

    /* Display instruction */
    printf ("Enter characters\n");
    printf (" to be transmitted\n");
    printf (" <ESC> to quit\n");

    /* Phimec protocol handler must NOT be installed ...*/
    while ((outchar = getche()) != '\x1B') /* Send char until <ESC> char*/
    {
        /* Call Intermec function */
        status = im_transmit_byte( com_port, outchar);
        if ( IM_ISERROR(status))
            im_message(status);
    }
}
```

---

## ***im\_unlink\_comm***

**Purpose:** This function removes the link between the Reader Wedge function and a designated communications port. After this function executes, the Reader Wedge is not notified of receive buffer functions.

You only need to use this procedure one time, at the end of your program.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_unlink_comm
    (IM_COM_PORT port_id);
```

**IN Parameters:** The *port\_id* parameter identifies the communications port as follows:

|         |                                    |
|---------|------------------------------------|
| IM_COM1 | COM1                               |
| IM_COM2 | COM2, scanner port (2010 and 2050) |
| IM_COM4 | COM4 (RF only)                     |

**OUT Parameters:** None.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this function.

You must install the Reader Wedge to use this function. For information on loading RWTSR.EXE, see "Runtime Requirements" earlier in this chapter.

**See Also:** im\_link\_comm

---

### ***Example***

See example for im\_receive\_input.

*im\_viewport\_end*

---

## ***im\_viewport\_end***

**Purpose:** This function sets the viewport to the lower right corner (end) of the virtual display.

**Syntax:**

```
#include <im20lib.h>
void im_viewport_end(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** `im_cursor_to_viewport`, `im_viewport_home`, `im_viewport_move`,  
`im_viewport_page_down`, `im_viewport_page_up`, `im_viewport_to_cursor`

---

### ***Example***

See example for `im_viewport_setxy`.

---

## *im\_viewport\_getxy*

**Purpose:** This function retrieves the column and row of the upper left corner of the viewport.

**Syntax:**

```
#include "im20lib.h"
IM_STATUS im_viewport_getxy
    (IM_USHORT *row,
     IM_USHORT *col);
```

**IN Parameters:** None.

**OUT Parameters:** The *row* parameter returns the row value (Y-coordinate) of the viewport.  
The *col* parameter returns the column value (X-coordinate) of the viewport.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** This function is valid only when the display is in 80 x 25 mode.

This function has no effect on the JANUS 2050.

**See Also:** im\_viewport\_end, im\_viewport\_home, im\_viewport\_move,  
im\_viewport\_page\_up, im\_viewport\_page\_down, im\_viewport\_setxy,  
im\_viewport\_to\_cursor

---

### *Example*

See example for im\_viewport\_setxy.

*im\_viewport\_home*

---

## ***im\_viewport\_home***

**Purpose:** This function sets the viewport to the upper left corner (home) of the virtual display.

**Syntax:**

```
#include <im20lib.h>
void im_viewport_home(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** `im_cursor_to_viewport`, `im_viewport_end`, `im_viewport_move`,  
`im_viewport_page_down`, `im_viewport_page_up`, `im_viewport_to_cursor`

---

### ***Example***

See example for `im_viewport_setxy`.

---

## *im\_viewport\_move*

**Purpose:** This function moves the viewport the specified distance and direction.

**Syntax:**

```
#include <im20lib.h>
IM_STATUS im_viewport_move
    (IM_VIEWPORT_DIRECTION direction,
     IM_USHORT distance,
     IM_USHORT *row,
     IM_USHORT *col);
```

**IN Parameters:** The *direction* parameter is one of these constants:

|                   |            |
|-------------------|------------|
| IM_VIEWPORT_LEFT  | Move left  |
| IM_VIEWPORT_RIGHT | Move right |
| IM_VIEWPORT_UP    | Move up    |
| IM_VIEWPORT_DOWN  | Move down  |

The *distance* parameter indicates the number of units to move the viewport and is either a numeric value between 1 and 70 or is IM\_DEFAULT\_DISTANCE.

If the distance parameter is IM\_DEFAULT\_DISTANCE, the default step size is used.

The distance moved is a configurable parameter. For more information on configuring the viewport, see your JANUS user's manual.

**OUT Parameters:** The *row* parameter returns the row number to which the viewport has moved.

The *col* parameter returns the column number to which the viewport has moved.

**Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."

*im\_viewport\_move*

**Notes:** The (*row*, *column*) pair represents the upper left corner of the viewport being displayed.

The minimum value for both the *row* and *column* is (0,0), which is the upper left corner of the virtual window. The maximum value is determined by the video mode and the number of lines and columns displayed.

For example, for the normal video mode 3 (80 x 25 display) with a 20 x 16 display size, the maximum value of *row* is 9 (25 minus 16) and the maximum value of *column* is 60 (80 minus 20).

The row and column viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *row* and *col*.

This function has no effect on the JANUS 2050.

**See Also:** *im\_viewport\_end*, *im\_viewport\_home*, *im\_viewport\_page\_down*, *im\_viewport\_page\_up*, *im\_viewport\_to\_cursor*, *im\_cursor\_to\_viewport*

---

**Example**

See example for *im\_viewport\_setxy*.



---

## ***im\_viewport\_page\_down***

**Purpose:** This function moves the viewport down one viewport length.

**Syntax:**

```
#include <im20lib.h>
void im_viewport_page_down(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** *im\_cursor\_to\_viewport*, *im\_viewport\_end*, *im\_viewport\_home*,  
*im\_viewport\_move*, *im\_viewport\_page\_up*, *im\_viewport\_to\_cursor*

---

### ***Example***

See example for *im\_viewport\_setxy*.

*im\_viewport\_page\_up*

---

## ***im\_viewport\_page\_up***

**Purpose:** This function moves the viewport up one viewport length.

**Syntax:**

```
#include <im20lib.h>
void im_viewport_page_up(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** This function has no effect on the JANUS 2050.

**See Also:** `im_cursor_to_viewport`, `im_viewport_end`, `im_viewport_home`,  
`im_viewport_move`, `im_viewport_page_down`, `im_viewport_to_cursor`

---

### ***Example***

See example for `im_viewport_setxy`.

---

## *im\_viewport\_setxy*

- Purpose:** This function sets the viewport row and column to a specific value when moving between two screens.
- Syntax:**
- ```
#include <im20lib.h>
IM_STATUS im_viewport_setxy
    (IM_USHORT *row,
     IM_USHORT *col);
```
- IN/OUT Parameters:** The *row* parameter sets the row value (Y-coordinate) of the viewport.  
The *col* parameter sets the column value (X-coordinate) of the viewport.
- Return Value:** This function returns one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** The (*row*, *col*) pair represents the upper left corner of the viewport being displayed. The minimum values for both the *row* and *col* are (0,0), which is the upper left corner of the virtual window. For the normal video mode 3 (80 x 25 display) with 20 x 16 display character size, the maximum value of *row* is 9 (25 minus 16) and the maximum value of *col* is 60 (80 minus 20).
- The row and column viewport settings are set to the maximum allowed for the current mode and display size. To determine the actual values set, check the returned values of *row* and *col*.
- This function has no effect on the JANUS 2050.
- See Also:** im\_viewport\_move

## *im\_viewport\_setxy*

---

### **Example**

```
/****** im_viewport_setxy ******/
/* Also with: im_viewport_getxy */
/* im_viewport_home */
/* im_viewport_end */
/* im_viewport_page_down */
/* im_viewport_page_up */
/* im_viewport_move */
/* im_set_display_mode */
/* im_get_display_mode */
/* im_viewport_to_cursor */
/* im_cursor_to_viewport */

#include <stdio.h>
#include <dos.h>
#include <conio.h>
#include <stdlib.h>
#include "im20lib.h"

#define SOUND_TIME 200 /* 200 milliseconds */

void main (void)
{
    IM_USHORT row, col;
    IM_STD_SIZE_MODE std_size, cmode_size;
    IM_STD_VIDEO_MODE std_video, cmode_video;
    IM_SCROLL_MODE std_scroll, cmode_scroll;
    IM_CHARACTER_HEIGHT std_charhigh, cmode_charhigh;

    /* Set display mode to 80 x 25 and remaining parameters standard. */
    std_size = IM_SIZE_MODE_80X25;
    std_video = IM_STD_VIDEO_MODE_3;
    std_scroll = IM_LCD_SCROLL_AT_25;
    std_charhigh = IM_STANDARD_CHAR_HEIGHT;
    im_set_display_mode(std_size, std_video, std_scroll, std_charhigh);

    /* Set up mark for viewport operation fuctions */
    /* DOS Screen uses (1,1) as home but im functions start at (0,0) */
    gotoxy( 1, 1 ); cputs("1-viewport_home"); /* viewport_home mark*/
    gotoxy( 1, 1+1); cputs(" row:0, col:0");
    gotoxy( 61, 24 ); cputs("2-viewport_end"); /* viewport_end mark*/
    gotoxy( 61, 24+1); cputs(" row:23, col:60");
    gotoxy( 61, 1 ); cputs("3-viewport_page_up"); /* viewport_page_up */
    gotoxy( 61, 1+1); cputs(" row:0, col:60");
    gotoxy( 21, 1 ); cputs("4-viewport_setxy"); /* viewport_setxy */
    gotoxy( 21, 1+1); cputs(" row:0, col:20");
    gotoxy( 41, 1 ); cputs("5-viewport_move"); /* viewport_move */
    gotoxy( 41, 1+1); cputs(" row:0, col:40");
    gotoxy( 41, 19 ); cputs("6-viewport_page_down"); /* viewport_page_down */
    gotoxy( 41, 19+1); cputs(" row:18, col:40");
    gotoxy( 21, 19 ); cputs("7-viewport_to_cursor"); /* viewport_to_cursor*/
    gotoxy( 21, 19+1); cputs(" row:18, col:20");

    /* Bring cursor back so that viewport will stay with it */
    gotoxy( 1, 1);

    /* Action 1: Set viewport back to Home */
    im_viewport_home();
    im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
    getch();
}
```

```

/* Action 2: Viewport End */
im_viewport_end();
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 3: Viewport Page Up */
im_viewport_page_up();
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 4: Viewport Setxy */
row = 0; col = 20;
im_viewport_setxy(&row, &col);
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 5: Viewport Move */
im_viewport_move(IM_VIEWPORT_RIGHT, 20, &row, &col);
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 6: Viewport Page Down */
im_viewport_page_down();
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 7: set cursor at row:18, column:10 and viewport_to_cursor */
/* Note: Cursor at the center of viewport */
gotoxy(20+10, 18); /* Need offset 10 to let cursor at center*/
im_viewport_to_cursor();
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 8: Viewport Getxy */
im_viewport_end(); /* Force viewport to end */
/* In 80X25 mode, viewport_end causes the viewport move at (9,60) */
/* You should see value is row:9, col:60 */
im_viewport_getxy(&row, &col);
im_viewport_home(); /* Force viewport to home */
gotoxy(1, 1); cputs ("8-viewport_getxy"); /* Start at home again */
gotoxy(1, 1+1); cputs (" Row:%d, Col:%d", row, col);
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();

/* Action 9: Mark ref. c->v */
clrscr();
gotoxy(51, 10); cputs("Ref. C->V"); /* viewport_to_cursor*/
gotoxy( 1, 1); cputs("9-C->V");
gotoxy( 1, 1+1); cputs("Cursor at Ref.");
getch();
/* Action 9: Move viewport to end, then Do cursor_to_viewport */
row = 2; col = 40;
im_viewport_setxy(&row, &col);
im_viewport_end(); /* Force viewport to end */
im_cursor_to_viewport(); /* Cursor go to center */
im_sound(IM_LOW_PITCH, SOUND_TIME, IM_LOUD_VOLUME);
getch();
/* Action 10: Get Display Mode */
im_get_display_mode(&cmode_size, &cmode_video, &cmode_scroll,
&cmode_charhigh);
if ( (std_size == cmode_size) && (std_video == cmode_video) &&
(std_scroll == cmode_scroll) && (std_charhigh == cmode_charhigh) )

```

### *im\_viewport\_setxy*

```
        printf("\nDisplay mode setup ok\n");
else    printf("\nError in display_mode\nsetup\n");
        im_sound(IM_LOW_PITCH,SOUND_TIME,IM_LOUD_VOLUME);
        getch();
}
```

---

## ***im\_viewport\_to\_cursor***

**Purpose:** This function centers the viewport around the cursor.

**Syntax:**

```
#include <im20lib.h>
void im_viewport_to_cursor(void);
```

**IN Parameters:** None.

**OUT Parameters:** None.

**Return Value:** None.

**Notes:** When the cursor is not displayed, use this function to move the viewport to the cursor.

This function has no effect on the JANUS 2050.

**See Also:** *im\_cursor\_to\_viewport*, *im\_viewport\_end*, *im\_viewport\_home*,  
*im\_viewport\_move*, *im\_viewport\_page\_down*

---

### ***Example***

See example for *im\_viewport\_setxy*.





# 3

## *Software Interrupts*



*This chapter explains how to use software interrupts in your programs.*

## ***Using the Software Interrupts***

---

If PSK library functions are not available for your programming language, you can use software interrupts to invoke the special functions of the reader. These special functions are called *reader services*.

Reader services include several functions, ranging in complexity from controlling the beeper to controlling the internal power management software.

The reader supports other standard PC/AT interrupts that control the DOS and BIOS functions of a normal PC. It is beyond the scope of this manual to list all the normal PC interrupts. This chapter deals only with the interrupts specific to the JANUS family of PC-compatible readers.

Use the following tables as a quick reference point for finding the interrupts you need.

| Interrupt Range | Usage                        |
|-----------------|------------------------------|
| 00H - 1FH       | Internal hardware interrupts |
| 20H - 3FH       | DOS interrupts               |
| 3FH and above   | Intermec-specific interrupts |

---

**Vector Interrupts**

| <b>Vector</b> | <b>Standard PC</b>                   | <b>Reader</b>  |
|---------------|--------------------------------------|--|
| 0             | Divide by Zero                       | Divide by Zero   |
| 1             | Single Step                          | Single Step  |
| 2             | Nonmaskable Interrupt                | Nonmaskable Interrupt  |
| 3             | Breakpoint                           | Breakpoint   |
| 4             | Overflow                             | Overflow   |
| 5             | Print Screen or Bounds Check         | Print Screen or Bounds Check   |
| 6             | Invalid Opcode                       | Invalid Opcode   |
| 7             | Coprocessor Not Available            | Coprocessor Not Available  |
| 8             | System Timer (IRQ 0) or Double Fault | System Timer (IRQ 0) or Double Fault   |
| 9             | Keyboard (IRQ 1) or Coprocessor      | Keyboard (IRQ 1) or Coprocessor Segment Overflow   |
| A             | Reserved                             | Slave PIC (IRQ 2) or Invalid TSS   |
| B             | COM                                  | COM 2 or 4 (IRQ 3) or Segment Not Present<br>COM 2 is available only on the 2010 or 2050 |
| C             | COM                                  | COM 1 or 3 (IRQ 4) or Stack Exception  |
| D             | Hard Disk or LPT                     | Intermec Count Gathering (IRQ 5) or General Protection                                   |
| E             | Floppy Disk                          | Reserved (IRQ 6) or Page Fault   |
| F             | LPT                                  | Reserved (IRQ 7)   |
| 10-1F         | BIOS                                 | BIOS   |
| 20-3F         | DOS                                  | DOS  |
| 40-43         | BIOS                                 | Pointers to BIOS Table   |
| 44-45         | BIOS                                 | Reserved   |
| 46            | BIOS                                 | Pointers to BIOS Table   |
| 47-49         |                                      | Reserved   |
| 4A            |                                      | User Alarm (RTC)   |
| 4B-59         |                                      | Reserved   |
| 5A-5B         | NET                                  | Cluster Adapter  |
| 5C            | NET                                  | Net BIOS   |
| 5D-5F         |                                      | Power Management (IPM)   |

---

*Vector Interrupts (continued)*

| <i>Vector</i> | <i>Standard PC</i> | <i>Reader</i>                             |
|---------------|--------------------|---|
| 60–66         |                    | User Reserved                             |
| 67            | EMS Driver         | EMS Driver                                |
| 68–6F         | VGA                | Reserved                                  |
| 70            | IRQ 8              | RTC (IRQ 8)                               |
| 71            | IRQ 9              | Reserved (IRQ 9)                          |
| 72            | IRQ 10             | Keypad Scanner (IRQ 10)                   |
| 73            | IRQ 11             | Reserved (IRQ 11)                         |
| 74            | IRQ 12             | Reserved (IRQ 12)                         |
| 75            | IRQ 13             | Reserved (IRQ 13)                         |
| 76            | IRQ 14             | Reserved (IRQ 14)                         |
| 77            | IRQ 15             | Power Management (IRQ 15)                 |
| 78            |                    | System Configuration and Control Services |
| 79            |                    | Display Services                          |
| 7A            |                    | Bootstrap Services                        |
| 7B            |                    | Reserved                                  |
| 7C            |                    | Beep Utility                              |
| 7D            |                    | Reader Services                           |
| 7E            |                    | Special Keypad Services                   |
| 7F            |                    | Bootstrap Hook                            |
| 80–F0         | BASIC              | BASIC                                     |
| F1–FF         | User Reserved      | User Reserved                             |

## ***Programming With Software Interrupts***

---

To invoke the Intermec utilities, you must have a programming language that supports interrupt-level routines. Most programming languages include this type of functionality, but the support methods vary from language to language.

For example, Microsoft C uses the INT86 and INT86X functions to execute software interrupts, and Microsoft QuickBasic uses the INTERRUPT and INTERRUPTX calls. For more information about interrupt functions, see the documentation for your compiler and the programming examples in Appendix B, "Sample Interrupt Programs."

## ***Specific Software Interrupt Definitions***

---

The following pages list software interrupts that are unique to the JANUS readers, along with notes on usage and examples of how each interrupt is generated in a program.

**Note:** *Do not run programs that use PSK library functions on your PC. If you attempt to run these programs, you will receive an error message and the program will not run.*



### **Caution**

***Do not run programs that use Intermec-specific interrupt extensions on your PC. If you attempt to run these programs, they will cause your PC to lock up and possibly corrupt your system BIOS.***

### **Consiel**

***N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.***

---

## ***INT 14H, Function 17H***

### ***Receive Next Buffer***

**Purpose:** This function requests the protocol handler to receive the next data buffer from the communications port. Use this function to receive subsequent transmissions after INT 14H, function 60H, has established the link to the protocol handle.

**Call With:** AH = 17H Receive next buffer

DX = Port ID:  
00H COM1  
01H COM2, scanner port (2010 and 2050)  
03H COM4

**Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 14H, Function 50H***

### ***Transmit Buffer***

- Purpose:** This function transmits the contents of a data buffer using the selected communications port. You must install a protocol handler to use this interrupt.
- Call With:**
- |         |          |  |
|---------|----------|--|
| AH =    | 50H      | Transmit buffer  |
| DX =    | Port ID: |  |
|         | 00H      | COM1   |
|         | 01H      | COM2, scanner port (2010 and 2050)                         |
|         | 03H      | COM4   |
| ES:BX = |          | Pointer to the data buffer structure defined in IM20LIB.H. |
- Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."
- See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."



---

## ***INT 14H, Function 60H***

### ***Receive Buffer***

- Purpose:** This function first establishes a link with the protocol handler and then receives the first record through the selected communications port.
- Call With:**
- |         |          |  |
|---------|----------|--|
| AH =    | 60H      | Receive buffer   |
| DX =    | Port ID: |  |
|         | 00H      | COM1   |
|         | 01H      | COM2, scanner port (2010 and 2050)   |
|         | 03H      | COM4   |
| ES:BX = |          | Pointer to the IM_COM_DATA_BUFFER data structure defined in IM20LIB.H. The buffer must be larger than 256 bytes. |
- Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** You must install a protocol handler to use this interrupt.  
Use this function only once at the start of your program.
- See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 14H, Function 71H***

### ***Protocol Extended Status***

- Purpose:** This function returns the protocol extended status for a selected communications port.
- Call With:**
- AH = 71H Protocol extended status
  - DX = Port ID:
    - 00H COM1
    - 01H COM2, scanner port (2010 and 2050)
    - 03H COM4
  - CX = Status buffer length
  - ES:BX = Pointer to the status buffer. See the file IM20LIB.H for details.
- Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."
- See Also:** EXSTAT.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 14H, Function 84H***

### ***Cancel RX Buffer***

**Purpose:** This function terminates the protocol handler's connection to the receiving buffer.

**Call With:** AH = 84H Cancel RX buffer

DX = Port ID:  
00H COM1  
01H COM2, scanner port (2010 and 2050)  
03H COM4

**Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this interrupt.

**See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 14H, Function 85H***

### ***Cancel TX Buffer***

**Purpose:** This function terminates the protocol handler's connection to the transmit buffer for a selected communications port.

**Call With:** AH = 85H Cancel TX buffer

DX = Port ID:  
00H COM1  
01H COM2, scanner port (2010 and 2050)  
03H COM4

**Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** You must install a protocol handler to use this interrupt.

**See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 16H, Function B4H***

### ***Enable/Disable Expanded Keyboard Buffer***

**Purpose:** This function enables or disables the expanded keyboard buffer. If it is enabled, the keyboard buffer is 269 bytes long. If it is disabled, the keyboard buffer is 16 bytes long.

**Call With:** AH = B4H Enable/disable expanded keyboard buffer

AL = 00H Get status only  
01H Enable expanded keyboard  
02H Disable expanded keyboard

**Return Value:** AH = 00H Always

AL = 00H Command completed  
01H Expanded buffer is already installed or already enabled  
02H Expanded buffer is disabled  
03H Cannot disable because expanded buffer is not empty  
04H Invalid command

**Notes:** You must use INT 16H to read keycodes or first call the “Flush expanded key buffer” service to empty the buffer.

**See Also:** KEYBUFF.CPP in Appendix B, “Sample Interrupt Programs.”

---

## **INT 16H, Function B5H**

### **Insert String Into Expanded Keyboard Buffer**

**Purpose:** This function inserts a string of up to 255 characters into the keyboard buffer with a single call to the BIOS. You can encode a passed string in two ways:

- Simple byte-aligned ASCII only
- Entire character keycode

Use the entire character keycode method to implement a unique character tagging scheme or to pass special keys such as **Ctrl**, **F1**, and **Esc**. The calling routine must supply the scan code.

**Call With:**

|      |     |  |
|------|-----|--|
| AH = | B5H | Insert string into expanded keyboard buffer                |
| AL = | 00H | Use byte-aligned ASCII string format with scan code lookup |
|      | 01H | Use word-aligned keycode format                            |
|      | 02H | Use byte-aligned ASCII string format without lookup        |

CX =           Number of characters to put into buffer

ES:BX =Far pointer to the string

**Return Value:**

|      |           |  |
|------|-----------|--|
| AH = | 00H       | Always   |
| AL = | 00H       | Successful   |
|      | 01H       | Expanded buffer has not been installed   |
|      | 02H       | Keyboard buffer is full and the entire string was rejected   |
|      | 03H       | Invalid mode value   |
| DX = | <i>nn</i> | Number of unused keys ( <i>nn</i> ) that remain in the buffer after the passed string has been inserted, or the number available prior to the call if the buffer cannot hold the string. |

**Notes:** Pass strings instead of individual characters to eliminate label fragmentation and speed up the software interface between DECODES and the keyboard stream.

**See Also:** KEYBUFF.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 16H, Function B6H***

### ***Flush Expanded Keyboard Buffer***

**Purpose:** This function initializes the expanded keyboard buffer from an unknown state. The contents of both the native and expanded buffers (all pending keycodes) are cleared and the expanded buffer is ready for new input from the keypad or from string and character insertions. This function has no effect if the expanded buffer is not enabled and keys in the native buffer are preserved.

**Call With:** AH = B6H Flush expanded keyboard buffer

**Return Value:** AH = 00H Always

AL = 00H Buffer is cleared  
01H Expanded buffer is not installed

**See Also:** KEYBUFF.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 16H, Function B7H***

### ***Enable/Disable Ctrl-Alt-Del Warm Boot***

**Purpose:** This function blocks the user's attempt to warm boot the reader from the keypad.

**Call With:**

|      |     |  |
|------|-----|--|
| AH = | B7H | Enable/disable <b>Ctrl-Alt-Del</b> warm boot |
| AL = | 00H | Disable warm boot                            |
|      | 01H | Enable warm boot                             |
|      | 02H | Get status only                              |

**Return Value:**

|      |                             |
|------|-----------------------------|
| AH = | General status              |
|      | 00H Valid service call      |
|      | 01H Invalid function number |
| AL = | Keypad warm boot status     |
|      | 00H Warm boot is prohibited |
|      | 01H Warm boot is permitted  |

**Notes:** This feature locks the application program to protect transient data from being lost during warm boot.

**See Also:** JBOOT.CPP in Appendix B, "Sample Interrupt Programs."



---

**INT 78H, Function 06H****Restore UART Configurations**

**Purpose:** This function restores the UART registers for COM1. Use this function to restore the UART parameters after the reader has gone through a suspend/resume cycle.

**Call With:**

|      |           |   |
|------|-----------|---|
| AH = | 06H       | Restore UART configurations   |
| AL = | 00H       | Save the current UART parameters, and get current UART configurations |
| BL = | 01H       | COM1  |
|      | 02H       | COM2, scanner port (2010 and 2050)                                    |
| BH = | 00H       |   |
| CX = | 0000H     |   |
| DX = | 0000H     |   |
| AL = | 04H       | Restore the UART configuration  |
| BL = | 01H       | COM1  |
|      | 02H       | COM2, scanner port (2010 and 2050)                                    |
| BH = | 00H       |   |
| CX = | 0000H     |   |
| DX = | 0000H     |   |
| AL = | 06H       | Store the FCR parameter (FIFO control register)                       |
| BL = | 01H       | COM1  |
|      | 02H       | COM2, scanner port (2010 and 2050)                                    |
| BH = | FCR value |   |
| CX = | 0000H     |   |
| DX = | 0000H     |   |

**Notes:** The parameter values for the communications ports (01H and 02H) are correct as shown. COM4 is not allowed.

You can find complete register descriptions in generic data sheets for the 16x550 UART. You can find the FIFO Control Register (FCR) descriptions in your JANUS user's manual.

*INT 78H, Function 06H*

**Notes:**

When power resumes after a suspend/resume cycle, reader services are restored in a manner transparent to client software. If your application uses the COM1 or COM2 UART directly for serial communications without the Intermec protocol handler software, your application must follow these guidelines:

**16x550 UART** The 16x550 UART prevents transparent restoration of COM1 or COM2 configurations when the reader is cycled through suspend/resume. Specifically, the 16x550's FCR is a write-only register that prohibits a transparent save operation prior to removing power from the UART. To prevent FCR-related problems in your communications application, use subfunction 06H as described below.

**PC-Native UART** You can ignore the UART restore issue altogether by using the UART in its PC-native mode (for example, without the FIFO buffering feature that is equivalent to a 16x450 or the original 8250 UART), since all other registers are readable and the system software manages them transparently.

**Using Subfunctions** If your application uses the FIFO feature of the 16x550, you can use subfunction 06H to store the FCR parameter (assuming all other UART registers are configured by the application). Once the FCR value is stored (a one-time operation), the entire set of UART registers are restored transparent to the application. Serial communications can survive all suspend/resume cycles for the duration of the application's run session.

Baud rates and their corresponding index values are as follows:

| Baud Rate | Index Value | Baud Rate | Index Value |
|-----------|-------------|-----------|-------------|
| 110       | 0           | 9600      | 6           |
| 300       | 1           | 19200     | 7           |
| 600       | 2           | 38400     | 8           |
| 1200      | 3           | 57600     | 9           |
| 2400      | 4           | 115000    | 10          |
| 4800      | 5           |           |             |

**Notes:**

The restore option is applied to the entire set of UART registers:

- FIFO Control Register FCR
- Divisor Latch least significant byte DLL, most significant byte DLL, and DLM baud rate selectors
- Interrupt Enable Register IER
- Line Control Register LCR
- Modem Control Register MCR
- Scratch Register SCR

The Receive Buffer Register (RBR) holding the last received data value (prior to entering the Suspend state) is not restored. The serial communications application currently controlling the COM port must handle this protocol recovery issue. Serial activity occurring at the time of a Suspend keeps the unit awake until a timeout (see Chapter 4, “Advanced Programming”). However, critical Suspend conditions can cause a Suspend before all serial activity is completed.

**Client Software Requirements** The power management (IPM) software normally calls the restore service. Thus, the COM1 or COM2 communications software does not need subfunction 04H. For testing purposes, any software client that wants to restore all preset (memorized) UART configurations can call subfunction 04H.

Before invoking the restore service, client software must protect the system by ensuring that either all COM interrupts are disabled (IRQ3 and IRQ4), or that the COM(n) interrupt service is initialized to begin processing serial data before the UART restore service returns to the calling software.

**Return Value:**

When AL = 00H, the function returns:

|      |     |  |
|------|-----|--|
| AL = | 00H | Successful                             |
|      | 01H | Invalid AX register                    |
|      | 05H | Invalid COM port number in BL register |
|      | FFH | Undefined baud rate                    |

AH = Baud rate table index value (see Notes)

*INT 78H, Function 06H*

**Return Value:**

- BL = Interrupt enable register
- BH = FIFO control register (returns the value set by subfunction 06 only, since you cannot read the FCR)
- CL = DLL value (baud divisor LSB)
- CH = DLM value (baud divisor MSB)
- DL = LCR value (line control register)
- DH = MCR value (modem control register)

When AL = 06H, the function returns:

- AL = 00H Valid service
- 01H Invalid AX register
- 05H Invalid parameters (BL must be 01H, and DL must be 00H)

- AH = 00H
- BX = Unchanged
- CX = Unchanged
- DX = Unchanged

**See Also:** FIFO.CPP in Appendix B, "Sample Interrupt Programs."

---

**INT 79H, Function 00H****LCD Display Contrast**

**Purpose:** This function controls the LCD contrast. It does not interfere with the keypad user control.

**Call With:**

- AH = 00H LCD display contrast
- AL = 00H Increase or decrease contrast by one level
  - BL = 00H Increase
  - BL = 01H Decrease
- AL = 01H Set contrast to an absolute value
  - BL = 00H to
    - 1FH Indicates the absolute contrast value (0 to 31)
    - 02H Restore contrast level
    - 03H Return current contrast level

**Return Value:** AL = Absolute contrast value achieved. If AL = FFH, then the interrupt routine received bad parameters.

**See Also:** CONTRAST.CPP in Appendix B, "Sample Interrupt Programs."

---

## **INT 79H, Function 01H**

### **LCD Display Backlight**

**Purpose:** This function controls the LCD backlight. It does not interfere with the keypad user control.

**Call With:**

|      |                 |  |
|------|-----------------|--|
| AH = | 01H             | LCD display backlight                  |
| AL = | 00H             | Backlight OFF                          |
|      | 01H             | Backlight ON                           |
|      | 02H             | Backlight toggle                       |
|      | 03H             | Return status                          |
|      | 04H             | Enable or disable the auto-off feature |
|      | BL = 00H        | Disable                                |
|      | BL = 01H        | Enable                                 |
|      | 05H             | Set backlight timeout period           |
|      | BL = 01H to 3CH | 1 to 60 seconds                        |
|      | 06H             | Return backlight timeout period        |
|      | 07H             | Return auto-off status                 |

**Return Value:** When AL = 00H, 001H, or 05H, the return values are:

|      |     |                               |
|------|-----|-------------------------------|
| AL = | 00H | Good parameters were received |
|      | FFH | Bad parameters were received  |

When AL = 02H, the return values are:

|      |     |                               |
|------|-----|-------------------------------|
| AL = | 00H | Backlight is OFF after toggle |
|      | 01H | Backlight is ON after toggle  |
|      | FFH | Bad parameters were received  |

When AL = 03H, 04H, or 07H, the return values are:

|      |     |                              |
|------|-----|------------------------------|
| AL = | 00H | Disable                      |
|      | 01H | Enable                       |
|      | FFH | Bad parameters were received |

**Return Value:** When AL = 06H, the return values are:

AL = 0 to 60 Backlight timeout in seconds  
FFH Bad parameters were received

**See Also:** BACKLITE.CPP in Appendix B, “Sample Interrupt Programs.”

---

## **INT 79H, Function 02H**

### **LCD Display Size Mode Manager**

**Purpose:** This function establishes the display setup when in text mode.

**Call With:**

|      |      |   |
|------|------|---|
| AH = | 02H  | LCD display size mode manager   |
| AL = | 00H  | Initialize 80x25 or 40x25 text mode   |
| BH = | 00H  | Video mode 0 (40 x 25)  |
| BH = | 01H  | Video mode 1 (40 x 25)  |
| BH = | 02H  | Video mode 2 (80 x 25)  |
| BH = | 03H  | Video mode 3 (80 x 25)  |
| BL = | 00H  | Scroll at line 25   |
| BL = | 01H  | Scroll at line 16 (2010 and 2020)   |
| BL = | 02H  | Scroll at line 8 (2010 and 2020)  |
| BL = | 03H  | Scroll at line 13 (2050 and double height)  |
| CH = | 00H  | Standard character height   |
| CH = | 01H  | Double character height   |
| AL = | 01H  | Initialize 20x16 text mode (2010 and 2020)  |
|      | 02H  | Initialize 20x8 text mode (2010 and 2020)   |
|      | 03H  | Return current video mode, size mode, character height, and scroll mode           |
|      | 04H  | Initialize 10x16 text mode (2010 and 2020)  |
|      | 05H  | Initialize 10x8 text mode (2010 and 2020)   |
|      | 06H  | Enable or disable character height and scroll mode keys                           |
|      | BL = | 00H Disable   |
|      |      | 01H Enable  |
| AL = | 07H  | Returns whether the character height and scroll mode keys are enabled or disabled |



**Return Value:** When AL = 03H, the return values are:

|      |     |                                 |
|------|-----|---------------------------------|
| AH = | 00H | Video mode 0                    |
|      | 01H | Video mode 1 (40x25)            |
|      | 02H | Video mode 2 (80x25)            |
|      | 03H | Video mode 3 (80x25)            |
| AL = | 00H | 80x25 or 40x25 size mode        |
|      | 01H | 20x16 size mode (2010 and 2020) |
|      | 02H | 20x8 size mode (2010 and 2020)  |
|      | 03H | 10x16 size mode (2010 and 2020) |
|      | 04H | 10x8 size mode (2010 and 2020)  |
| BH = | 00H | Standard character height       |
|      | 01H | Double character height         |
| BL = | 00H | Scroll mode 0                   |
|      | 01H | Scroll mode 1                   |
|      | 02H | Scroll mode 2                   |

When AL = 07H, the return values are:

|      |     |                              |
|------|-----|------------------------------|
| AL = | 00H | Disabled                     |
|      | 01H | Enabled                      |
|      | FFH | Bad parameters were received |

When AL = any other value (except 03H and 07H), the return values are:

|      |     |                               |
|------|-----|-------------------------------|
| AL = | 00H | Good parameters were received |
|      | FFH | Bad parameters were received  |

**See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."

---

## **INT 79H, Function 03H**

### **Viewport Move**

**Purpose:** This function provides program and keypad control of the viewport. This service is available only in modes where the display buffer cannot be completely viewed within a 20x16 window.

This function does not apply to the JANUS 2050.

**Call With:**

- AH = 03H    Viewport move
  
- AL = 00H    Disable or enable movement keys
  - BL = 00H    Disable
  - BL = 01H    Enable
  
- AL = 01H    Absolute viewport move
  - BX = Row number
  - CX = Column number
  
- AL = 02H    Relative viewport move
  - BH = Direction
    - 00H    Left
    - 01H    Right
    - 02H    Up
    - 03H    Down
  - BL = Calling source
    - 00H    Keypad
    - 01H    Application
  - CX = Distance
    - 00H    Default distance
  
- AL = 03H    Set the viewport default step size
  - BL = Video mode
  - BH = Row default step size
  - CX = Column default step size
  
- AL = 04H    Get the viewport default step size
  
- AL = 05H    Get the video, size, and position mode

**Call With:** AL = 06H Return whether viewport keys are enabled or disabled

**Return Value:** When AL = 01H, the return values are:

AX = *nn* Row number (*nn*) actually achieved  
FFH Bad parameters were received

BX = *nn* Column number (*nn*) actually achieved  
FFH Bad parameters were received

When AL = 02H, the return values are:

AX = *nn* Row number (*nn*) actually achieved  
FFH Bad parameters were received

BX = *nn* Column number (*nn*) actually achieved  
FFH Bad parameters were received

When AL = 03H, the return values are:

AL = 00H Good parameters were received  
FFH Bad parameters were received

When AL = 04H, the return values are:

AL = *nn* Row step size (*nn*)  
FFH Bad parameters were received

BH = *nn* Row default step size (*nn*)

BX = *nn* Column step size (*nn*)

CX = *nn* Column default step size (*nn*)

*INT 79H, Function 03H*

**Return Value:** When AL = 05H, the return values are:

AH = *nn* Video mode (*nn*)

AL = *nn* Size mode (*nn*)  
FFH Bad parameters were received

BX = *nn* Row number (*nn*)

CX = *nn* Column number (*nn*)

When AL = 06H, the return values are:

AL = 00H Disabled  
01H Enabled  
FFH Bad parameters were received

**See Also:** PHTERM.CPP in Appendix B, "Sample Interrupt Programs."

---

**INT 7CH, Function 64H****Generate Sound**

**Purpose:** This function generates a sound of specified pitch and duration.

**Call With:** AX = 64H Generate sound

CX = 00H

DX = 00H

ES:BX = Pointer to the IM\_BEEP\_PARAMS structure

The definition for this structure is as follows:

| Byte   | Description   |
|--------|---|
| 0      | Requested volume<br>0 = Off<br>1 = Quiet<br>2 = Normal<br>3 = Loud<br>4 = Very loud<br>5 = Default volume |
| 1 to 2 | Pitch (20 to 20,000 Hz)   |
| 3 to 4 | Duration (1 to 65,000 ms)   |
| 5 to 6 | Off time (1 to 65,000 ms)   |

**Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** JBEEP.CPP in Appendix B, "Sample Interrupt Programs."

---

## **INT 7DH, Function 08H**

### **Reader Wedge Control**

**Purpose:** This function provides Reader Wedge control.

**Call With:**

|      |       |   |
|------|-------|---|
| AH = | 08H   | Reader Wedge control  |
| AL = | 00H   | Clear abort callback address  |
|      | 01H   | Modify reader configuration   |
|      | ES:BX | Far pointer to a reader command string                                      |
|      | CX    | Length of the reader string   |
|      | 03H   | Get input mode  |
|      | 06H   | Get label symbology   |
|      | ES:BX | Far pointer to a variable receiving the symbology                           |
|      | 07H   | Get length of received string   |
|      | CX    | 0010H Label selected  |
|      |       | 0020H Keyboard selected   |
|      |       | 0001H COM1 selected   |
|      |       | 0002H COM2, scanner selected (2010 and 2050)                                |
|      |       | 0008H COM4 selected   |
|      | 08H   | Get input status  |
|      | 0AH   | Get input from keyboard or scanned label<br>(see IRL command A)             |
|      | ES:BX | Far pointer to IRL_PARAMS_S   |
|      | 0BH   | Receive input from keyboard (see IRL command K)                             |
|      | ES:BX | Far pointer to IRL_PARAMS_S   |
|      | 0CH   | Receive numeric input from keyboard or scanned label<br>(see IRL command N) |
|      | ES:BX | Far pointer to IRL_PARAMS_S   |

**Call With:**

AL = 0DH Receive input from any source in any format  
(see IRL command V)

ES:BX Far pointer to IRL\_PARAMS\_S

CL 00H Edit disable  
01H Edit enable

CH Beep mode:  
00H Application beep  
01H Wedge beep  
02H No beep

DL Display flag:  
00H Flag disable  
01H Flag enable

DS:SI Far pointer to allowable input sources:  
0000H No input source  
0010H Label selected  
0020H Keyboard selected  
0001H COM1 selected  
0002H COM2, scanner selected (2010 and 2050)  
0008H COM4 selected  
007FH All selected

0EH Receive input from a selected communications port  
(see IRL command Y)

ES:BX Far pointer to IRL\_PARAMS\_S

CL 00H COM1 selected  
01H COM2, scanner selected (2010 and 2050)  
03H COM4 selected

DL Protocol mode:  
00H No change  
01H Protocol on  
02H Protocol off  
03H New end-of-message character

DS:SI Far pointer to the end-of-message character

10H Link to a selected communications port

ES:BX Far pointer to memory area used by Reader Wedge

CX 0000H COM1 selected  
0001H COM2, scanner selected (2010 and 2050)  
0003H COM4 selected

DX Number of bytes to allocate for the buffer array

*INT 7DH, Function 08H*

**Call With:**           AL = 1BH   Receive input from selected source and place into buffer

                  CX     Allowed input source:  
                          0010H Label selected  
                          0020H Keyboard selected  
                          0001H COM1 selected  
                          0002H COM2, scanner port (scanner) selected  
                                  (2010 and 2050)  
                          0008H COM4 selected

                  DX     Timeout value

                  ES:BX Far pointer to the returned source:  
                          0000H No selection made  
                          0010H Label selected  
                          0020H Keyboard selected  
                          0001H COM1 selected  
                          0002H COM2, scanner port (scanner) selected  
                                  (2010 and 2050)  
                          0008H COM4 selected

                  DS:SI Far pointer to the input string

                  1EH   Set serial protocol mode

                          CL     00H   COM1  
                                  01H   COM2, scanner port (2010 and 2050)  
                                  03H   COM4

                          CH     Protocol mode:  
                                  00H   No change  
                                  01H   Protocol on  
                                  02H   Protocol off  
                                  03H   New end-of-message character

                          DL     End-of-message character

                  1FH   Set abort callback address

                          CX     Input source:  
                                  0010H Label selected  
                                  0020H Keyboard selected  
                                  0001H COM1 selected  
                                  0002H COM2, scanner selected (2010 and 2050)  
                                  0008H COM4 selected  
                                  007FH All selected

                          ES:BX Far pointer to the callback routine



**Call With:**

|      |      |  |
|------|------|--|
| AL = | 20H  | Set input mode   |
|      | CX   | 0000H Programmer mode<br>0001H Wedge mode<br>0002H Desktop mode      |
|      | 22H  | Set standby wait mode  |
|      | CX   | Timeout value  |
|      | 23H  | Unlink a communications port   |
|      | CX = | 0000H COM1<br>0001H COM2, scanner port (2010 and 2050)<br>0003H COM4 |

**Return Value:** When AL is one of the following values, the return value in register AX is one of the standard status codes defined in Appendix A, "Status Codes."

|      |     |     |     |     |
|------|-----|-----|-----|-----|
| AL = | 00H | 0BH | 10H | 22H |
|      | 01H | 0CH | 1BH | 23H |
|      | 06H | 0DH | 1EH |     |
|      | 0AH | 0EH | 1FH |     |

When AL = 03H, the return values are:

|      |     |                 |
|------|-----|-----------------|
| AX = | 00H | Programmer mode |
|      | 01H | Wedge mode      |
|      | 02H | Desktop mode    |

When AL = 07H, the return value is:

AX = The length of the string.

When AL = 08H, the return values are:

|      |     |   |
|------|-----|---|
| AX = | 00H | No selection made                           |
|      | 10H | Label selected                              |
|      | 20H | Keyboard selected                           |
|      | 01H | COM1 selected                               |
|      | 02H | COM2, scanner port selected (2010 and 2050) |
|      | 08H | COM4 selected                               |
|      | 7FH | All selected                                |

*INT 7DH, Function 08H*

**Return Value:** When AL = 20H, there is no return value.

**Notes:** Because the number of parameters passed to the IRL functions exceed the registers available, you must pass a structure variable of type struct IRL\_PARAMS\_S as shown in the following C code:

```
typedef struct
{
    IM_USHORT timeout;
    IM_LENGTH_SPEC test_table[];
    IM_UCHAR mask_string[];
    IM_UCHAR *string;
    IM_USHORT *cmd_count;
    IM_DECTYPE *symbology;
} IRL_PARAMS_S;
```

---

**INT 7DH, Function 0AH****Get 2D Decoder Firmware Version**

**Purpose:** This function returns all pertinent information about the revision level of the 2D Decoder and its firmware.

**Call With:** AH = 0AH Get 2D Decoder version

ES:BX = Far pointer to the client's Decoder response buffer  
(response buffer must be large enough to hold the response string)

**Return Value:** The return value in register AX is one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The JANUS 2D upon boot queries the decoder for the firmware revision level. This function returns the string "UNKNOWN" until the decoder replies with the decoder revision level.

**See Also:** PL220VER.CPP in Appendix B, "Sample Interrupt Programs."

---

***INT 7DH, Function 0CH***

***Open COM2***

**Purpose:** This function opens COM2 for use by the 2D Decoder.

**Call With:** AH = 0CH Open COM2

**Return Value:** The return value in register AX is one of the standard status codes defined in Appendix A, "Status Codes."

**Notes:** The JANUS 2D upon boot opens COM2 for use by the 2D Decoder. When COM2 is being shared with other RS-232C devices (i.e., SAVI Interrogator), it is necessary to close COM2 prior to the other device using the port and open it backup prior to the 2D Decoder using COM2.

**See Also:** OPEN.CPP in Appendix B, "Sample Interrupt Programs."

---

**INT 7DH, Function 0DH****Close COM2**

- Purpose:** This function closes COM2 so other devices (i.e. SAVI Interrogator) can use COM2.
- Call With:** AH = 0DH Close COM2
- Return Value:** The return value in register AX is one of the standard status codes defined in Appendix A, "Status Codes."
- Notes:** The JANUS 2D upon boot opens COM2 for use by the 2D Decoder. When COM2 is being shared with other RS-232C devices (i.e., SAVI Interrogator), it is necessary to close COM2 prior to the other device using the port and open it backup prior to the 2D Decoder using COM2.
- See Also:** CLOSE.CPP in Appendix B, "Sample Interrupt Programs."

---

## **INT 7EH, Function 01H**

### **Get Application Break Status**

- Purpose:** This function determines if the application break sequence was entered on the keypad.
- Call With:**
- AH = 01H Get application break status
  - ES:BX = Far pointer to the client's response buffer structure (two bytes, R0 and R1)
- Return Value:**
- AH = General status:
    - 00H Valid service call
    - 01H Invalid function number
  - R0 = Keyboard scanner CPU (KSCPU) communication status
    - 00H Successful
    - 01H Timeout occurred during the execution of the transaction
    - 02H No KSCPU response (timeout on first attempted transmit)
    - 03H KSCPU is busy
    - 04H Forced the transaction to abort
    - 05H KSCPU failed to process an acknowledged command within the timeout period
  - R1 = Application break status
    - 00H Application break request has not been made
    - FFH Application break request has been made
- Notes:** Applications that support the application break feature must either poll the unlock status using this service or implement a **Ctrl-C** handler (INT 23H) that queries using this service. In the latter case, the operator is required to enter **Ctrl-C** on the keypad after entering the application break sequence and resume the unit by pressing the **1/0** key.

To enter an application break sequence

1. Press  $\text{I/O}$  to turn off the reader.
2. Press  $\text{F3}$  -  $\boxed{2}$  -  $\blacktriangleleft$  at the same time.
3. Press  $\boxed{1}$ . This sets the reader's application break bit.
4. Press  $\text{I/O}$  to turn on the reader.

This sequence resets the application break request bit if the bit is TRUE. A new application that monitors this bit can execute without terminating on the same condition that terminated the previous application.

**See Also:** APPBREAK.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 7EH, Function 03H***

### ***Get Keypad Scanner Version***

**Purpose:** This function returns all pertinent information about the revision level of the KSCPU and its firmware.

**Call With:** AH = 03H Get keypad scanner version

ES:BX = Far pointer to the client's KSCPU response buffer  
(five bytes, R0 to R4)

**Return Value:**

AH = General status  
00H Valid service call  
01H Invalid function

R0 = KSCPU communication status  
00H Successful  
01H Timeout occurred during the execution of the transaction  
02H No KSCPU response (timeout on first attempted transmit)  
03H KSCPU is busy  
04H Forced transaction abort  
05H KSCPU failed to process an acknowledged command within the timeout period

R1 = KSCPU minor revision level

R2 = KSCPU major revision level

R3, R4 = Workspace padding (required)

**See Also:** KEYSTAT.CPP in Appendix B, "Sample Interrupt Programs."



---

**INT 7EH, Function 04H****Get Keypad Map Table ID and Status**

- Purpose:** This function returns the keypad map table ID and status.
- Call With:** AH = 04H Get keypad map table ID and status
- ES:BX = Far pointer to the client's KSCPU response buffer  
(seven bytes, R0 to R6)
- Return Value:**
- AH = General status
    - 00H Valid service call
    - 01H Invalid function number
  - R0 = KSCPU communication status
    - 00H Success transaction
    - 01H Timeout occurred during the execution of the transaction
    - 02H No KSCPU response (timeout on first attempted transmit)
    - 03H KSCPU is busy
    - 04H Forced transaction abort
    - 05H KSCPU failed to process an acknowledged command within the timeout period
  - R1 = Keypad ID number
  - R2 = Table validation pass/fail
    - FFH Pass
    - 00H Fail
  - R3, R4 = Keypad checksum/CRC 16-bit word, R3 is LSB
  - R5, R6 = Workspace padding (required)
- See Also:** KEYSTAT.CPP in Appendix B, "Sample Interrupt Programs."

---

## **INT 7EH, Function 05H**

### **Enable/Disable KSCPU Keyclick**

**Purpose:** This function turns the keypad clicker ON or OFF.

**Call With:** AH = 05H Enable/disable KSCPU keyclick

AL = 00H Turn the keyclick OFF  
01H Turn the keyclick ON  
02H Get status only

ES:BX = Far pointer to the client's KSCPU response buffer  
(four bytes, R0 to R3)

**Return Value:** AH = General status  
00H Valid service call  
01H Invalid function number

R0 = KSCPU communication status  
00H Successful  
01H Timeout occurred during the execution of the transaction  
02H No KSCPU response (timeout on first attempted transmit)  
03H KSCPU is busy  
04H Forced transaction abort  
05H KSCPU failed to process an acknowledged command within  
the timeout period

R1 = Keyclick status  
00H Keyclick disabled  
FFH Keyclick enabled

R2, R3 = Workspace padding (required)

**See Also:** KEYCLICK.CPP in Appendix B, "Sample Interrupt Programs."

---

**INT 7EH, Function 06H****Enable/Disable Numeric Keypad**

**Purpose:** This function toggles the numeric keypad modes of the reader's keypad. When disabled, normal QWERTY scan codes are sent by the numeric keys. When enabled, the PC KB-102 numeric keypad scan codes are sent instead.

**Call With:**

|         |     |  |
|---------|-----|--|
| AH =    | 06H | Enable/Disable numeric keypad  |
| AL =    | 00H | Disable  |
|         | 01H | Enable with NUM LOCK on  |
|         | 02H | Enable with NUM LOCK off   |
|         | 03H | Get status only  |
| CL =    | 00H | Prohibit mode-switching from the keypad                                  |
|         | 01H | Permit mode switching from the keypad                                    |
|         | 02H | Reserved   |
|         | 03H | Get status only  |
| ES:BX = |     | Far pointer to the client's KSCPU response buffer (five bytes, R0 to R4) |

**Return Value:**

|      |   |
|------|---|
| AH = | General status  |
|      | 00H Valid service call  |
|      | 01H Invalid function number   |
| R0 = | KSCPU communication status  |
|      | 00H Successful  |
|      | 01H Timeout occurred during the execution of the transaction                  |
|      | 02H No KSCPU response (timeout on first attempted transmit)                   |
|      | 03H KSCPU is busy   |
|      | 04H Forced transaction abort  |
|      | 05H KSCPU failed to process an acknowledged command within the timeout period |

*INT 7EH, Function 06H*

**Return Value:** R1 = Number pad status  
00H Disabled  
FFH Enabled

R2 = Permit status  
00H Switching the number pad is prohibited  
FFH Switching the number pad is permitted

R3, R4 = Workspace padding required

**Notes:** The R2 permit status only affects the manual keypad method of switching the number pad ON and OFF. Even if the numeric keypad is not manually permitted, you can use program-controlled mode changes (regardless of the previous state).

**See Also:** NUMPAD.CPP in Appendix B, "Sample Interrupt Programs."

---

## INT 7EH, Function 08H

### Enable/Disable Ctrl Key

- Purpose:** This function enables or disables the **Ctrl** key on the reader's keypad.
- Call With:**
- AH = 08H Enable/disable **Ctrl** key
  - AL = 00H Disable
  - 01H Enable
  - 02H Get status only
  - ES:BX = Far pointer to the client's KSCPU response buffer (four bytes, R0 to R3)
- Return Value:**
- AH = General status
    - 00H Valid service call
    - 01H Invalid function number
  - R0 = KSCPU communication status
    - 00H Successful
    - 01H Timeout occurred during the execution of a transaction
    - 02H No KSCPU response (timeout on first attempted transmit)
    - 03H KSCPU is busy
    - 04H Forced transaction abort
    - 05H KSCPU failed to process an acknowledged command within the timeout period
  - R1 = **Ctrl** key status
    - 00H Disabled
    - FFH Enabled
  - R2, R3 = Workspace padding (required)
- Notes:** The system BIOS does not detect a **Ctrl** key press when you disable the **Ctrl** key with this interrupt.
- See Also:** CTLKEY.CPP in Appendix B, "Sample Interrupt Programs."

*INT 7EH, Function 10H*

---

## ***INT 7EH, Function 10H***

### ***Enable Viewport***

**Purpose:** This function enables the viewport so that it automatically follows the cursor. This function does not apply to the JANUS 2050.

**Call With:** AH = 10H Enable viewport

**Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."

**See Also:** VP\_CUR.CPP in Appendix B, "Sample Interrupt Programs."

---

## ***INT 7EH, Function 11H***

### ***Disable Viewport***

- Purpose:** This function disables the viewport from automatically following the cursor. This function does not apply to the JANUS 2050.
- Call With:** AH = 11H Disable viewport
- Return Value:** AX = *nnnn* One of the standard status codes defined in Appendix A, "Status Codes."
- See Also:** VP\_CUR.CPP in Appendix B, "Sample Interrupt Programs."





4

## *Advanced Programming*



*This chapter explains the various reader input modes and how to use the power management software.*

## ***Reader Input Modes***

---

Reader input modes affect how scanned input is interpreted and stored by the reader. You can control input modes by:

- Using the reader commands described in your JANUS user's manual.
- Using the `im_get_input_mode` and `im_set_input_mode` commands described in Chapter 2, "C Language Support."

There are three different input modes:

- Wedge mode
- Programmer mode
- Desktop mode

---

### ***Wedge Mode***

In Wedge mode, keypad and label inputs go into the keyboard buffer with minimal filtering. Wedge mode is the default mode at the DOS prompt after reader services are loaded (RSERVICE.EXE). Use this mode when the reader is running an application that uses the Virtual Wedge. For more information about the Virtual Wedge, see Chapter 1, "Getting Started."

When the reader is in Wedge mode, use standard input functions such as `getch` to retrieve keypad or label input. Do not use the methods described for other modes.

Wedge mode does not take full advantage of the reader power management capabilities. You will probably notice reduced battery life when the reader is in Wedge mode.

---

## ***Programmer Mode***

In Programmer mode, keypad input is echoed to the screen as the keys are pressed. Any reader commands that you enter are executed and saved. Use this mode when the reader is executing Interactive Reader Language (IRL) commands such as `im_irl_a` or `im_irl_k`.

---

## ***Desktop Mode***

In Desktop mode, the application is responsible for retrieving and displaying keypad input. Use this mode when you need detailed information about the pressed key.

Use the input function `im_receive_input` to capture the keys pressed. Each character returned uses the structure `IM_KEYCODE`, described in `IM20LIB.H`. This structure consists of four bytes: the ASCII code, the scan code, and two bytes of keyboard flags (Shift, Control, Alt).

---

## ***Differences in Input Modes***

Programmer mode and Desktop mode differ only in how they handle keypad inputs. In programmer mode, keypad entry terminates when you press the **Enter** key. In desktop mode, keypad entry terminates each time you press a key.

Do not use functions such as `getch` to retrieve input when the reader is in Desktop or Programmer modes. The internal software intercepts any input before functions such as `getch` can receive it, and the application waits forever on that instruction.

In Wedge mode, label input is placed directly into the keyboard buffer. In Programmer and Desktop modes, label input is not placed into the keyboard buffer. It is, however, retrieved in a manner similar to the way keyboard data is retrieved. An example of handling reader input is given below.

**Note:** For the reader to function as a bar code reader, `LOADSYMB.EXE` must be loaded. `RDG.BAT` loads both reader services (`RSERVICE.EXE`) and the decode algorithms (`LOADSYMB.EXE`).

---

**Example: Input Modes**

```
// This example demonstrates reader input from either the keyboard or a label. Additional
// sources (or a single source) can be given. All possible sources, including COM ports,
// can be selected using IM_ALL_SELECT.
//
// In programmer mode, the im_receive_input() function returns after the Enter key is
// pressed. In desktop mode, the im_receive_input() function returns after each
// key is pressed.
//
// This method is used primarily to receive input from multiple sources when you do not
// know the input source.

char    input[80];                // Input buffer (user sets the length)
IM_ORIGIN    source;             // Source(s) where input is to come from
IM_DECTYPE   symbol;            // Symbology (for label input)
IM_STATUS    istatus
im_set_input_mode(IM_PROGRAMMER); // Can also be IM_DESKTOP (but not IM_WEDGE)

istatus = im_receive_input
        (im_keyboard_select | im_label_select,
         im_infinite_timeout,
         &source, input);
if (source == IM_KEYBOARD_SELECT) {
    printf("Input from keyboard\n");
}
if (source == IM_LABEL_SELECT) {
    printf("Input from scanner\n");
}
printf("%s\n", input);
```

## Receiving Serial Data

---

There are two methods for receiving serial data:

- Reader service routines that allow multiple inputs
- Communications routines that use the INT 14H BIOS extensions

The method you use depends on how you want to receive keypad and label data. Both of these methods are valid in Desktop mode and Programmer mode. With minor modifications, these methods will work in Wedge mode.



### **Caution**

***Do not mix reader service routines with communications routines: a usable response is not returned.***

### **Conseil**

***Ne mélangez pas les routines de révision lecteur à des routines de communication: aucune réponse utilisable ne sera renvoyée.***

---

## Reader Services Routines

You can use reader service routines that include communications port inputs by following these application requirements:

- At the beginning of your application, link the reader service input functions using a call to `im_link_comm`. At the end of your application, unlink them with a call to `im_unlink_comm`.
- Enable or disable the protocol using `im_serial_protocol_control`. The default is to have the protocol enabled.
- Clear the receive buffer by disabling and then enabling the protocol. Do not use `im_cancel_rx_buffer` when using this method because it stops the reader from communicating.

---

**Example: Reader Services**

```
// This example shows how to accept input from either the keyboard or from a serial
// port. The function im_receive_input( ) is given two sources: keyboard or COM1.
// Additional sources (or a single source) can be given. Use IM_ALL_SELECT to select
// all possible sources (including label input).
//
// This program waits for input, and then makes it available by calling
// im_receive_input( ).
//
// Use this method when you want to receive input from multiple sources and you don't know
// the input source.
//
// This is not a complete program, but it demonstrates the required function calls.

char  input[300]; // Input buffer (user sets the length)
char  com_buff[300]; // Used by Communications link only
IM_ORIGIN  source; // Source(s) where input is to come from
IM_STATUS  status; // Results of call

im_set_input_mode(IM_PROGRAMMER); // In this example, the mode might be IM_DESKTOP
// (but not IM_WEDGE). If the reader is in
// IM_WEDGE mode, use a function like gets( )
// to retrieve keyboard and label input.
// The only sources that can be Ored together in
// IM_WEDGE mode are COM ports.

//
im_link_comm(IM_COM1, com_buff, 300); // Link to reader services input routines

// Wait for input from either the keyboard or from COM 1
status = im_receive_input
        (IM_KEYBOARD_SELECT | IM_COM1_SELECT,
         IM_INFINITE_TIMEOUT,
         &source,
         input);

// Data is now available in the buffer input

if (status == IM_RW_SUCCESS)
    im_transmit_buffer(IM_COM1, strlen(input), input, 1000); // Transmit data with
// a 1-second timeout

im_unlink_comm(IM_COM1); // Unlink from reader services input routines
```

---

## ***Communications Routines***

You can use communications routines with the INT 14H BIOS extensions by following these application requirements:

- Do not link your application with the reader service input functions (do not call `im_link_comm`).
- Use either `im_receive_buffer` or `im_receive_buffer_noprot` to select communications with or without protocol.
- Use `im_cancel_rx_buffer` to clear the receive buffer.

---

### ***Example: Communications Routines***

```
// This example shows how input is requested from a single source. This function waits
// for input and then puts it into the specified buffer.
// In programmer mode, keyboard entry terminates when you press the Enter key. In desktop
// mode, keyboard entry terminates when you press each key.

IM_UCHAR      input[300];    // Input buffer (user sets the length)
IM_USHORT far num_chars;
IM_DECTYPE    symbol;

im_set_input_mode(IM_PROGRAMMER);    // Could be any mode

im_receive_buffer(IM_COM1, 300, input, 1000, &num_chars);    // Get serial input (timeout)
// is 1-second)
im_transmit_buffer(IM_COM1, strlen(input), input, 1000);    // Transmit data with a
// 1-second timeout
```



## ***Transmitting Serial Data***

---

With Intermec protocol handlers, you transmit serial data by calling the communications routines included with the PSK. These routines are `im_transmit_buffer`, `im_transmit_buffer_no_wait`, and `im_transmit_buffer_noprot`. These communications routines all use the INT 14H BIOS extensions.

You can transmit a maximum of 254 bytes in one record. Make the buffer size somewhat larger (300 bytes is typically used) to allow adequate memory for protocol characters that might also be transmitted. If the buffer is too small, you will overwrite other memory locations.

## ***Communications Port UART Modes***

---

If you turn off your JANUS reader while running a communications application that uses COM1 or COM2, the reader cannot save the UART FIFO control register. The reader uses the UART restore configuration setting to reset the FIFO control register when the reader is turned back on. You need to set a restore value if the default value, 0 hex, is not appropriate for your reader. You must set a restore value in these two cases:

- Your application is using COM1 without using an Intermec protocol handler.
- Your application is using COM2 and changes the reader's COM2 UART FIFO control register to use UART 16x550 mode. See the communications application's manual to determine if it uses UART 16x550 mode.

You can also reset the FIFO control register using software interrupts. For more information, see INT 78H, function 06H, in Chapter 3, "Software Interrupts."

## Display “Color”

---

You can set the reader display to various foreground and background shades. A SMARTMAP™ scheme compares and adjusts the foreground and background gray values on a character-by-character basis to produce adequate display contrast on monochrome LCD panels. With this scheme, commercially written color software packages can be used on a monochrome display with acceptable differentiation of colors using shades of gray.

The default color setting on a PC is white on black. However, the best default setting on a monochrome display is black on white. For this reason, setting a color to black actually sets white on black, and setting a color to white actually sets black on white.

To display colors other than just black and white, you should experiment with various color combinations to find an appropriate setting. The shade of a specific foreground color varies depending on the background color setting.

Borland C/C++ changes the foreground color by using `textcolor(int newcolor)` where *newcolor* is an integer between 0 and 15. Adding 128 to *newcolor* sets the most significant byte and makes the character blink. The background color is set using `textbackground(int newcolor)` where *newcolor* is an integer between 0 and 7. These colors are only applicable when using functions that do direct video output (such as `cprintf`).

Microsoft C/C++ changes the foreground color by using `_settextcolor(short index)` where *index* is an integer between 0 and 15. Adding 16 to *index* sets bit 4 and makes the character blink. The background color is set using `_setbkcolor(long index)` where *index* is an integer between 0 and 7. These colors are only applicable when using functions that do direct video output (such as `_outtext`).

## ***Advanced Power Management***

---

The reader power management subsystem provides Advanced Power Management (APM) compliant BIOS software functionality using the VLSI SCAMP II chip set.

The specific components of power management are:

- BIOS Power Management (PM) software with the APM software interface.
- Intermec Power Management (IPM) software.
- VLSI SCAMP chipset Power Management Unit (PMU) hardware (VL82C322).

APM is a layered, cooperative environment that allows applications, operating systems, and the system BIOS to work together toward the goal of reducing power consumption. The standardized flow of information and control across the layers facilitates interface requirements. The primary purpose of an APM implementation is to provide increased productivity and greater system availability by extending the life of system batteries without degrading performance.

---

### ***Power Management Software Layers***

Power management is provided by two software layers:

- System BIOS interface
- Application interface

The system BIOS interface is analogous to the power management methods implemented on current generation laptop systems, where automatic system functions temporarily shut down hardware components in order to prolong battery life.

The application interface improves power management by letting an application actively determine operational conditions and directly control hardware power consumption.

### ***System BIOS Interface***

The system BIOS is the lowest layer of power management software in the system. It is resident in the reader at all times. The system BIOS is capable of controlling power management functionality without any support from the operating system or application.


### ***Application Interface***

APM provides a cooperative interface between the system BIOS and other system or application software that makes the other software a partner in the power management process. Once this cooperative interface is established, the system BIOS informs its partner of significant power-related events and relies on its partner to actively participate in the power management process.


The application layer assists the power management function by providing information that only the application can easily ascertain. Applications are not required to support the power management function, but they can greatly increase its effectiveness. Under DOS in particular, the application is often in the best position to know when the reader is idle and awaiting input.

Some of the system BIOS functions can be called regardless of whether or not the cooperative power management interface has been established between the BIOS and the caller. However, some functions, particularly those related to notification of power events, do not operate until the cooperative interface is established. POWER.EXE provides a default cooperative connection to improve JANUS reader performance.

Figure 4-1 Power States



- Notes:
- ① (Turn ASIC clock on in < 1/2 clock period)
  - ② (Includes IRQs and NMI. The 82C322 PMU has 13 power management interrupt sources.)
  - ③ (82c322 hardware Activity monitor timeout.)



JPSK.005

---

## **The APM Power States**

APM supports four distinct power states: Ready, Standby, Suspend, and Off. Their relationships are depicted in Figure 4-1. Three of these states (Ready, Standby, and Off) apply both to individual system components and to the system as a whole. The Suspend state is a special low power condition that applies to the system as a whole, but not to the individual components.

Usually, your application only distinguishes between two apparent conditions: On and Off, where the indicator is the display. In the On condition, the display is active and the power management is in either the Ready or the Standby state. In the Off condition, the display is inactive, and power management is in either the Suspend or the Off state.

The system and devices change power states either by explicit command or automatically (based on APM parameters and system activity). The power capabilities of devices differ, and some devices may not be capable of achieving all states. Additionally, some devices may have unique, built-in power management that is invisible to the system, and therefore outside the scope of the APM specification.

### **Ready**

In the Ready state, the system or device is fully powered up and available. The APM definition of Ready does not differentiate between active and idle conditions; it only indicates that the system or device is fully powered up. The reader enters the Ready state when a device raises a hardware interrupt or accesses any controlled device.

### **Standby**

Standby is an intermediate system-dependent state that provides some power conservation. The reader enters the Standby state when the CPU is idle and there is no device activity (such as when an application is waiting for input). All data and operational parameters are preserved when the machine is in the Standby state. The CPU is powered but the clock runs very slowly (this does not affect the DOS time and date or any BIOS functions: it only conserves power).

### ***Suspend***

The Suspend state is the lowest level of power consumption available that preserves operational data and parameters. The reader enters the Suspend state by either the system BIOS or the software above the BIOS. The system BIOS might place the system into the Suspend state without notification if it detects a situation that requires an immediate response (such as the battery entering a critically low power state). When the system is in the Suspend state, computation is not performed until normal activity is resumed. Power is removed from the CPU. Resumption of activity does not occur until signaled by an external event such as pressing the **1/0** key.

### ***Off***

In the Off state, the unit is powered down and inactive. Data and operational parameters are not preserved (except for PC card drives that contain their own backup mechanisms and are preserved as long as they are intact). The reader enters the Off state when the operator selects storage mode (from the boot loader screen) or when all of the batteries are dead.

---

## ***Power State Transitions***

Figure 4-1 earlier in this chapter illustrates the methods and events used to transition between the indicated power states. States above the dotted line appear as On to the application, with the unit fully operational. States below the dotted line appear as Off to the application (the display is blank and a delay occurs when the unit is reactivated by pressing the **1/0** switch).

When the unit appears to be on, it might be in either the Ready or Standby state. In the Ready state, it is indeed on and fully powered. In the Standby state, the hardware is fully powered but the CPU clock is slowed, maintaining only memory refresh capability. To applications, the CPU clock appears to be stopped. The Standby state reduces battery current dramatically.

An exit from Standby occurs during any system activity that might require attention from the application. That is, not on BIOS clock ticks and not at the beginning of count gathering for bar code reading, although the end of the read generates an interrupt to direct the application to process the label.

When the unit appears to be Off, it is usually in the Suspend state. It is in the Off state only when both the main and backup batteries are dead or removed, or when placed into Storage mode from the bootstrap screen.

Figure 4-1 lists the events that control transitions between Ready and the Suspend or Off states. In normal operation, the unit transitions from Suspend to Ready when the 1/0 key is pressed and transitions back to Suspend on either an activity timeout or when the 1/0 key is again pressed.

While the reader is in the Suspend state, you can use the resume override key sequence to exit from Suspend and activate the boot screen. From the boot screen, you can select the following actions:

- Resume as long as the system state remains valid
- Reboot the reader, which transitions to On
- Select storage mode, which transitions to Off
- Use the other boot screen functions

Similar to an application, the CPU is in a Ready or Standby state while in the boot screen.

---

## ***Power State Cooperation***

APM provides an industry standard interface for cooperation among calling applications. The composite PM, BIOS, APM, and IPM provides two modes of operation:

- Transparent mode, where the BIOS, PMU, and PM cooperate to detect idle conditions and change power states by their set of rules.
- Nontransparent mode, where the currently operating application (client subsystem) cooperates in controlling the system power state and uses its knowledge of when it is waiting for activity. In this mode, the currently operating application can wait in a lower power state.

Basic power management capability is always present in the reader BIOS-PMU interaction. The reader reduces CPU power when it observes no system activity for a period of time, such as when the reader is sitting at the DOS prompt or waiting for operator input.



Basic power management uses the Standby and Auto-shutoff states. System activity is detected by monitoring for key press functions, display change activity, and all interrupts except the BIOS clock tick. In addition, the PMU hardware activity timeouts are set to change automatically to lower power states when there is no interrupt activity.

The Reader Wedge uses an IPM interface to control power management. For example, with IRL programs (which have no explicit PM interface), the Reader Wedge services know when the IRL program is waiting for input and that it can wait in a lower power mode. The Intermec configuration manager (IC.EXE) provides setup parameters for this level of power management.

Your application can explicitly control the power states by connecting to the APM interface with the interface connect function. This method provides the best use of the reader power since the application knows when it is idle and therefore can wait in a Standby or Suspend state depending upon response time requirements.

Applications that use the reader services interface have equally good power management without having to be explicitly concerned with power management functionality. The APM interface provides for polling by the application client to include power management information from the lower BIOS level software.

Finally, POWER.EXE (a Microsoft product) is an APM client that monitors system usage parameters to determine when an application is idle. POWER.EXE is a TSR program that provides better power management for off-the-shelf programs that have no APM knowledge. POWER.EXE also takes care of correcting the system date and time when the unit has been suspended overnight or longer. When the reader is shipped, POWER.EXE is installed and enabled.

The APM interface can only support one connected client at a time, so POWER.EXE must be disabled if an application wants to use the APM interface. You can disable POWER.EXE by placing the following command line in the AUTOEXEC.BAT file (or by executing the command at the DOS prompt, prior to loading an application):

```
POWER OFF
```

Programs that replace POWER.EXE must implement date correction algorithms when the reader is to be left suspended overnight or longer.

---

## ***IPM Interface Functionality***

The IPM interface is used by reader services and system functions to control power management state changes. It is transparent to application and operator controls. Both the IPM and APM interface cooperate to prevent the CPU from leaving the Ready state (except for critical Suspend transitions as discussed below).

The IPM interface provides Suspend and Resume functions for both normal and critical conditions:

- Normal Suspend
- Normal Resume
- Critical Suspend
- Critical Resume

### ***Normal Suspend***

The reader enters a normal Suspend transition when the front panel **1/0** key is pressed or the duration of the current activity exceeds the timeout parameter.

A normal Suspend only occurs when PM is enabled. Functions in process are completely restored following a normal Suspend.

### ***Normal Resume***

The reader enters a normal Resume transition when the front panel **1/0** key is pressed.

A normal Resume transition follows a normal Suspend transition. A normal Resume is not possible unless there has been a prior valid normal Suspend to save the system state. If the system state is not valid, a normal Resume forces a reboot. The operator can use the boot screen function to dump the system memory state (through the communications port) to a host prior to rebooting.

### ***Critical Suspend***

The reader enters a critical Suspend transition when the battery is removed, the main battery is low, or the front panel **1/0** key is pressed. The reader attempts to enter a normal Suspend transition before entering a critical Suspend transition.

Several warning periods occur prior to entering a low main battery state. Initially, the battery icon flashes as the battery begins to reach end of charge. Next the system emits warning beeps. Automatic shutoff with fully saved states occurs at a somewhat lower charge level. Certain system events (such as transmitting data using RF or a laser scanner) can add enough load to a low battery charge to cause an immediate transition to the low battery cutoff critical Suspend state.

A critical Suspend transition is always enabled. The application software must deal with the subsequent resume as effectively as possible. Functions in process might not be completely restored following a critical Suspend.

### ***Critical Resume***

The reader enters a critical Resume transition when the front panel **1/0** key is pressed or the battery is replaced.

A critical Resume transition follows a critical Suspend transition. A critical Resume is not possible unless there has been a prior valid critical Suspend to save the system state. If the system state is not valid, a critical Resume forces a reboot. The operator can use the boot screen function to dump the system memory state (through the communications port) to a host system prior to a reboot.

---

## ***APM Interface Functionality***

Programs that need to connect to and use the APM interface should observe the following suggested protocol:

- Turn off POWER.EXE (at the DOS command line) prior to connecting with the APM interface.
- Issue an APM installation check call. This call returns information on the current APM functionality (such as whether power management is currently enabled or disabled).
- Issue an APM interface connect call. If the return from this call shows an already connected client (such as POWER.EXE mentioned above), the application should terminate. The APM interface only allows one connected client.
- Issue an interface disconnect call, prior to exiting (for example, returning to the DOS prompt), so that another client can be connected.

**Note:** For an example of APM interface protocol as discussed above, see the application listing *FIFO.CPP* in Appendix B, “Sample Interrupt Programs.”

You must enable power management for the interface connect call to be successful, otherwise the CPU stays in the Ready state until the operator presses an 1/0 key to transition to the Suspend state. Certain system activities (such as file access to the PC card) temporarily disable PM to protect their integrity. Your application might have its own reasons to disable PM. You can use the enable/disable power management call to enable PM.

When PM is enabled, your application can initiate a get PM event call, and either use the result to change states or ignore the PM event call, in which case the unit stays in the Ready state (unless reader services is active to prompt state changes). A get PM event returns a battery status value that your application can use.

When your application is connected as an APM client, it is notified during get PM event calls when a system Suspend condition occurs. APM requires your client application to complete current processes, issue a set power state command, and enter the Suspend state (effectively turning the unit off) as soon as possible.

Certain system events, such as low battery, cannot wait for this process to occur and instead cause an immediate transition to Suspend. The resume following each Suspend includes, as the first PM event response, the fact of resume and the resume type: normal or critical. After a critical resume occurs, your application must continue to operate as effectively as possible.

You can use power state commands to transition from Ready to Standby or Suspend. The APM interface coordinates with IPM to allow transitions from Ready only when both interfaces allow it. This coordination also applies to CPU Busy and CPU Idle. Either interface can keep the CPU in Ready, and both must allow other states.

A transition to Suspend stops the time and date of the system clock. Upon each resume, the IPM interface restores the time function from the real-time clock. Upon resume in some situations, such as when the unit is suspended over midnight or when the date changes, the APM client must restore the DOS date function by using the real-time clock and date. POWER.EXE restores the date when it is active.

**Note:** For an example of how to enter the APM interface registers from the DOS command line and then connect to the APM interface, see the application listing *APMIF.C* in Appendix B, “Sample Interrupt Programs.”

## ***Special APM BIOS Calls***

---

APM requires a real mode interface and is implemented with an extension to INT 15. The system BIOS must operate in either real mode or virtual-86 mode on 80386 and later processors. Since the INT 15H processor instruction normally disables the interrupts, the system BIOS typically expects to be entered with interrupts disabled. However, the BIOS routines should not depend on any particular setting and should explicitly enable and disable interrupts as necessary. To avoid reentering INT 15H, an interrupt service routine (ISR) should not use any of the APM functions.

To better support the protected modes of 80286 and later processors, the system BIOS optionally supports a 16- and 32-bit protect mode interface directly callable from protected mode. First, you must initialize the protected mode interfaces using the real mode INT 15H AH = 53H. Systems not supporting APM return from this call with the carry flag (CY) set and the AH register equals 86H.

You must initialize 16- and 32-bit protected mode interfaces using the appropriate protected mode 16-bit interface connect or protected mode 32-bit interface connect functions.

If an error condition is detected when processing a system BIOS function, the function returns to the caller with the carry flag set and an error code in the AH register. The carry flag is cleared upon return from any successful call, and the content of the AH register is dependent on the particular call.

This interface adopts a convention for identifying a device class and specific subclasses within that class to use in direct device control. For example, a class might be all disk devices and the subclasses could be the physical unit numbers. APM calls take this parameter in a word-length register where the most significant byte (MSB) is the device class and the least significant byte (LSB) is the device subclass. This parameter is described in the individual interface descriptions.

The APM device class and subclass IDs are defined using BX = Device ID as follows:

| Device Class ID |                   | Device Subclass ID |  |
|-----------------|-------------------|--------------------|--|
| 00XXH           | System            | 00H                | System BIOS                                  |
|                 |                   | 01H                | All devices power managed by the system BIOS |
| 01XXH           | Display           | n/a                |  |
| 02XXH           | Secondary Storage | n/a                |  |
| 03XXH           | Parallel Ports    | n/a                |  |
| 04XXH           | Serial Ports      | n/a                |  |
| 0500H to FFFFH  | Reserved          | n/a                |  |

Where XXH indicates the physical device number (zero-based).

Where FFH indicates all devices in this class.

The following pages list the special APM system BIOS software interrupts that are unique to power management.

---

## ***APM Installation Check***

**Purpose:** This function determines if the system BIOS supports the APM functionality.

**Call With:** AH = 53H  
AL = 00H Do APM installation check  
BX = 0000H System BIOS

**Return Value:** If the function is successful:

Carry flag = Clear

AH = Major version number (in BCD format)

AL = Minor version number (in BCD format)

BH = ASCII P character

BL = ASCII M character

CX = Bit 0 = 1 if the BIOS supports 16-bit protected mode  
Bit 1 = 1 if the BIOS supports 32-bit protected mode  
Bit 2 = 1 if CPU Idle call slows processor clock speed  
Bit 3 = 1 if BIOS Power Management is disabled  
All other bits reserved

If the function is unsuccessful:

Carry flag = Set

AH = 86H APM is not present

**Notes:** The interpretation of bit 2 is documented under the CPU Busy call description.

This call is only available using the real mode INT 15H interface.



---

## ***CPU Busy***

**Purpose:** This function informs the system BIOS that the system is now busy and should continue at full speed. Some system implementations may only be able to slow the CPU clock rate and return in response to the CPU Idle call. The system BIOS usually restores the CPU clock rate to its normal rate when it recognizes increased system activity (typically interrupt driven), but it may be unable to do so when interrupts are hooked by external software and do not invoke BIOS routines.

You can ensure the system is running at full speed by using the CPU Busy function. Upon return from the APM Installation Check call, bit 2 of the CX register indicates if the system BIOS slowed the CPU clock rate during the CPU Idle call. You can use this bit to determine whether to call CPU Busy before executing code that should run at full speed.

Calling CPU Busy is discouraged when the system is already operating at full speed because of the unnecessary call overhead, but the operation is allowed and has no unexpected side effects.

**Call With:** AH = 53H

AL = 06H

**Return Value:** CY = 00H

**Notes:** This function is available in both the APM INT 15H and protect mode interface. Either APM or IPM busy can keep the CPU processing at full speed.

---

## ***CPU Idle***

**Purpose:** This function informs the system BIOS that the system is currently idle and that processing can be suspended until the next system event (typically an interrupt) occurs. This function allows the system BIOS to take some implementation-specific power saving action, such as stopping the CPU clock.

In cases where an interrupt causes the system to leave the idle state, the interrupt might have been serviced when the BIOS returns from the CPU Idle call. The calling application should not make any assumptions concerning interrupt servicing and should allow pending interrupts to be taken upon return from CPU Idle.

If interrupts are serviced from within the BIOS CPU Idle function, the interrupt handler must return to the BIOS when interrupt processing is completed. The caller cannot use knowledge of being in the idle state to regain control from an interrupt handler. For example, some system implementations can slow the processor CPU clock rate before waiting on an interrupt, and restore the normal clock rate after the interrupt is serviced but before returning from the idle call.

When the caller regains control, it should determine if there is actually any processing waiting to be performed and reissue the CPU Idle call if not. If the caller is a multitasking supervisor, it may be necessary to dispatch all of the applications (through calls to the supervisor), allowing them to check for incomplete activity.

**Call With:** AH = 53H

AL = 05H

**Return Value:** CY = 00H

**Notes:** This function is available in both the APM INT 15H and protect mode interface. Either the APM or IPM interface can keep the CPU in the busy state.

---

## ***Enable/Disable Power Management***

**Purpose:** This function enables or disables all APM automatic power down functionality. When disabled, the system BIOS does not automatically power down devices, enter the Standby state or Suspend state, or take power-saving steps in response to CPU Idle calls. In addition, many system BIOS functions are disabled and return the error 01H, indicating that power management functionality is disabled.

**Call With:**

AH = 53H

AL = 08H

BX = FFFFH Enable/disable all power management

CX = 00H Disable power management  
01H Enable power management

**Return Value:** If the function is successful:

Carry flag = Clear

If the function is unsuccessful:

Carry flag = Set

AH = Error code:  
01H Power management functionality disabled  
09H Unrecognized device ID  
0AH Parameter value in CX is out of range

**Notes:** This call is available in both the APM INT 15H and protect mode interfaces. Either APM or IPM can use this call to disable power management. Both APM and IPM must be enabled before enabling power management.

---

## Get PM Event

**Purpose:** This function returns the next pending PM event (or indicates that no PM events are pending).

**Call With:** AH = 53H

AL = 0BH

**Return Value:** If the function is successful:

Carry flag = Clear

BX = PM event code:

01H System Standby request notification  
02H System Suspend request notification  
03H Normal resume system notification  
04H Critical resume system notification  
05H Battery low notification

If the function is unsuccessful:

Carry flag = Set

AH = Error code:

03H Interface connection is not established  
80H No PM events are pending

**Notes:** Power events can occur when the system software is not immediately ready to process the event. In order to synchronize power events with other system software, the system BIOS withholds event notification until polled with the get PM event function. The cooperative PM software is only notified when it is ready to process the event.

The PM partner receives power event notification by periodically calling the get PM event function. Since power management events are not extremely time critical, a polling frequency of once or twice a second should be sufficient.

The 01H system Standby request notification informs the PM partner that the system BIOS wants to place the system in a Standby state. The system BIOS does not take any action at this time, but waits passively for the PM partner to call the system Standby function.

The 02H system Suspend request notification informs the PM partner that the system BIOS wants to place the system into a Suspend state. The system BIOS does not actually perform a Suspend at this time, but waits passively for the partner to call the Suspend system function.

A Resume system notification indicates that a critical system Suspend and Resume operation occurred without the cooperation of the PM partner. When a Suspend operation is scheduled to occur, the system BIOS normally notifies the partner through the Suspend system request, but does not actually perform the Suspend until the partner calls the Suspend system function.

In some emergency situations the system BIOS needs to Suspend the system immediately. In this situation, the system BIOS informs the partner that the system has resumed from such a Suspend through a Resume system notification. The partner must recover from the Suspend as best it can. Critical Suspend situations include power on and off, low battery, dead battery, and battery interlock.

The 05H battery low notification informs the PM partner that the system battery is running low.

This call is available in both the APM INT 15H and protect mode interfaces.

## *Get Power Status*

---

### ***Get Power Status***

**Purpose:** This function returns the system current power status.

**Call With:** AH = 53H

AL = 0AH

BX = 0001H

**Return Value:** If the function is successful:

Carry flag = Clear

BH = AC line status:

00H 0 indicates offline

01H 1 indicates online

FFH 255 indicates unknown

All other values reserved

BL = Battery status:

00H 0 indicates high

01H 1 indicates low

02H 2 indicates critical

03H 3 indicates charging

FFH 255 indicates unknown

All other values reserved

CL = Remaining battery life:

00H-64H Percent of full charge (0-100) in increments of 10

FFH 255 indicates unknown

If the function is unsuccessful:

Carry flag = Set

AH = 09H Unrecognized device ID

**Notes:** This call is available in both the APM INT 15H and protect mode interfaces.

---

## ***Interface Connect***

**Purpose:** This function establishes the cooperative interface between the caller and the system BIOS. Before the interface is established, the system BIOS provides its own power management functionality as implemented by the OEM. Once the interface is connected, the system BIOS and the caller coordinate PM activities according to this specification.

**Call With:** AH = 53H  
AL = 01H  
BX = 0000H System BIOS

**Return Value:** If the function is successful:

Carry flag = Clear

If the function is unsuccessful:

Carry flag = Set

AH = Error code:

02H Interface connection is already in effect

09H Unrecognized device ID

**Notes:** This call is only available using the APM INT 15H interface.

---

## ***Interface Disconnect***

**Purpose:** This function breaks the cooperative interaction between the system BIOS and the caller and in the process restores the system BIOS default functionality. Any protected mode connection set up by the protected mode 16-bit interface connect or protected mode 32-bit interface connect functions is also invalidated by this call.

Even though this call returns control of power management strategy to the system BIOS, the parameter values (such as timer values and enable and disable settings) in effect at the time of the disconnect remain in effect.

**Call With:** AH = 53H  
AL = 04H  
BX = 0000H System BIOS

**Return Value:** If the function is successful:  
Carry flag = Clear

If the function is unsuccessful:  
Carry flag = Set

AH = Error code:  
03H Interface is not connected  
09H Unrecognized device ID

**Notes:** This call is available in both the APM INT 15H and the protect mode interfaces.



---

## Protected Mode 16-Bit Interface Connect

**Purpose:** This function initializes the optional 16-bit protected mode interface between the caller and the system BIOS. This interface allows a protected mode caller to invoke the system BIOS functions without the need to first switch into real or virtual-86 mode. A caller that does not operate in protected mode might not need to use this call. This function establishes a 16-bit protected mode interface, but you must invoke this function in either real or virtual-86 mode using the INT 15H interface.

**Call With:** AH = 53H  
AL = 02H  
BX = 0000H System BIOS

**Return Value:** If the function is successful:

Carry flag = Clear

AX = PM 16-bit code segment (real mode segment base address)

BX = Offset of entry point

CX = PM 16-bit data segment (real mode segment base address)

If the function is unsuccessful:

Carry flag = Set

AH = Error code:

|     |   |
|-----|---|
| 05H | 16-bit protected mode interface already established |
| 06H | 16-bit protected mode interface not supported       |
| 09H | Unrecognized device ID                              |

**Notes:** The system BIOS 16-bit protected mode interface requires two consecutive selector and segment descriptors to use for a 16-bit code and data segment, respectively. The caller must initialize these descriptors using the segment base information returned by the BIOS.

### *Protected Mode 16-Bit Interface Connect*

The segment limit fields are set to 64K. These selectors can either be in the Global Descriptor Table (GDT) or Local Descriptor Table (LDT), but must be valid whenever the system BIOS is called in protected mode. The code segment descriptor must specify protection level 0 and must invoke the BIOS routines with CPL = 0 so they can execute privileged instructions.

The caller invokes the system BIOS using the 16-bit interface by making a far call to the initialized code segment selector with the offset returned in BX. The caller must supply a stack large enough for the BIOS and potential interrupt handlers to use. The caller's stack is active when interrupts are enabled in the BIOS routine; the BIOS does not switch stacks when interrupts are enabled, including nonmaskable interrupts (NMI). The BIOS 16-bit interface requires a call using a 16-bit stack.

When you call the system BIOS routines in protected mode, the current I/O permission bit map must permit access to any I/O ports that the BIOS might need.

The system BIOS rejects additional 16-bit protected mode connections when a connection has already been established.

This call is only available using the APM INT 15H interface.

---

## Protected Mode 32-Bit Interface Connect

**Purpose:** This function initializes the optional 32-bit protected mode interface between the caller and the system BIOS. This interface invokes the system BIOS functions without needing to switch into real or virtual-86 mode first. A caller that does not operate in protected mode might not need to use this call. This function establishes a 32-bit protected mode interface, but must be invoked in either real or virtual-86 mode using the INT 15H interface.

**Call With:** AH = 53H  
AL = 03H  
BX = 0000H System BIOS

**Return Value:** If the function is successful:

Carry flag = Clear

AX = PM 32-bit code segment (real mode segment base address)

BX = Offset of entry point

CX = PM 16-bit code segment (real mode segment base address)

DX = PM data segment (real mode segment base address)

If the function is unsuccessful:

Carry flag = Set

AH = Error code:

07H 32-bit protected mode interface already established

08H 32-bit protected mode interface not supported

09H Unrecognized device ID

### *Protected Mode 32-Bit Interface Connect*

**Notes:** The system BIOS 32-bit protected mode interface requires three consecutive selector/segment descriptors for use as 16- and 32-bit code and data segments, respectively. The system BIOS 32-bit interface needs both 16- and 32-bit code descriptors to call other BIOS routines in a 16-bit code segment if it becomes necessary. The caller must initialize these descriptors using the segment base information returned in the call from the BIOS.

The segment limit fields are set to 64K. These selectors can be either in the GDT or LDT, but must be valid whenever the system BIOS is called in protected mode. The code segment descriptors must specify protection level 0 and must invoke the BIOS routines with CPL = 0 so that they can execute privileged instructions.

The caller invokes the system BIOS using the 32-bit interface by making a far call to the initialized 32-bit code segment selector with the offset returned in BX. The caller must supply a stack large enough for the BIOS and potential interrupt handlers to use. The caller stack is active when interrupts are enabled in the BIOS routine; the BIOS does not switch stacks when interrupts are enabled, including NMI interrupts. The BIOS 32-bit entry point requires a call using a 32-bit stack.

When you call the system BIOS routines in protected mode, the current I/O permission bit map must permit access to the I/O ports the BIOS might need.

The system BIOS rejects additional 32-bit protected mode connections if a 32-bit protected mode connection has already been established.

This call is only available using the APM INT 15H interface.

---

## ***Restore System BIOS Power-On Defaults***

**Purpose:** This function directs the system BIOS to reinitialize all its power-on defaults.

**Call With:** AH = 53H

AL = 09H

BX = FFFFH

**Return Value:** If the function is successful:

Carry flag = Clear

If the function is unsuccessful:

Carry flag = Set

AH = Error code:

09H Unrecognized device ID

**Notes:** This call is available in both the APM INT 15H and protect mode interfaces.

## *Set Power State*

---

### **Set Power State**

**Purpose:** This function places the system or device specified in the power device ID into the requested state.

**Call With:**

- AH = 53H
- AL = 07H
- BX = Power device ID
- CX = System state ID
  - 0000H Ready (Not supported for system device ID 0001H)
  - 0001H Standby
  - 0002H Suspend
  - 0003H Off (Not supported for system device ID 0001H)
  - 0004H–FFFFH Reserved

**Return Value:** If the function is successful:

Carry flag = Clear

If the function is unsuccessful:

Carry flag = Set

AH = Error code:

- 01H Power management functionality is disabled
- 09H Unrecognized device ID
- 0AH Parameter value in CX is out of range
- 60H Cannot enter the requested state

**Notes:** This call is available in both the APM INT 15H and protect mode interfaces.

---

## Suspend System

**Purpose:** This function directs the system BIOS to place the system into the low-power Suspend state. The caller invokes this function in response to a Suspend system request notification from the system BIOS. First, the caller finishes any incomplete processing of its own, and then the caller invokes the Suspend system interrupt.

In addition to responding to system BIOS requests, the caller can initiate a Suspend operation. For example, if the caller determines that the system has been completely idle during a given time interval (for other than normal background processing such as servicing timer interrupts), it could request a system Suspend using this function.

Because the system BIOS does not return to the caller until the system is resumed from the Suspend state, there is no need to check for most resume notifications from the system BIOS. Upon return, and when safe to do so, the caller can notify any PM-aware applications of the resume status.

Since the system may have been suspended for a long period of time, the caller might need to update the date and time values.

**Call With:** AH = 53H  
AL = 07H  
BX = 0001H  
CX = 0002H

**Notes:** This call is available in both the APM INT 15H and protect mode interfaces.

---

## ***System Standby***

**Purpose:** This function commands the system BIOS to place the system into the Standby state. The caller invokes this function in response to a system standby request notification from the system BIOS after the caller has performed any processing of its own. The caller can also initiate a standby operation.

For example, if the caller determines that the system is idle and is not already in the Standby state, it could request a system standby using this function.

Typically, you exit the Standby state by raising an interrupt. Interrupts are serviced normally.

**Call With:** AH = 53H  
AL = 07H  
BX = 0001H  
CX = 0001H

**Notes:** This call is available in both the APM INT 15H and protect mode interfaces.



5

*Using the PSK With DCM*



*The Programmer's Software Kit Language Library includes three C language functions you can use for accessing a remote database from the JANUS reader.*

## ***Accessing a Database Server Through DCM***

---

You can easily write an application program to run on the JANUS reader that accesses a remote database server through Intermec data collection manager (DCM) software. DCM does not run on the reader. It runs on a separate PC or workstation and provides transparent access to the remote database. The database may or may not be on the same computer as DCM.

You need the following items to access a database server:

- The database table definition, including field types and field lengths
- Intermec DCM software version 4.3 or higher configured to access the database
- `im_setup_trx`, which sets up the protocol parameters for accessing the database server
- `im_standard_trx`, which packs and sends a transaction to the database
- `im_parse_host_response`, which reads the response from the host


**Note:** *These functions are only available in the C language library.*

## Defining a Database Transaction

---

DCM handles the actual translation of a packet of data from the reader into a database-usable packet, based on settings that you configure in DCM. Your application defines the variables for the data, calls the function to pack and transmit the data, and handles the response from the database.

You must understand how the data on the reader maps to the data in the database structure and design your application and the DCM configuration around this relationship. The following figure shows how the information in the reader relates to the information in the database.



For this chapter, the term *transaction* means a function call on the JANUS reader that sends a message to the database server and then receives and distributes the returned values. The transaction includes a transaction ID, data fields, and a database operation request. The database operation can be a read, a write, an update, or a delete. The return message is ACK, NAK, or data.

A read operation returns a status code and record information from the host that your application can process with `im_parse_host_response` (if pacing is off). The other database operations return only status codes.

To set up a reader to database transaction

1. Configure the database destination in DCM and map the fields in the JANUS reader to the database table.
2. Send a transaction to the database using `im_standard_trx`.
3. Check the return status codes from `im_standard_trx`.
4. If the transaction is a read operation, parse the returned records until the JANUS reader receives an ACK.
5. If needed, provide a standby file for transmitting transactions later if the transmit channel is unavailable.

The following sections explain each step.

---

## ***Configuring DCM***

Before writing your application on the JANUS reader, you need to configure DCM for the database transactions. Refer to the appropriate DCM user's manual for the database actions available and for detailed instructions on configuring DCM.

| Manual                          | Part Number |
|---------------------------------|-------------|
| <i>DCM for OS/2 Manual Kit</i>  | 057433      |
| <i>DCM for HP-UX Manual Kit</i> | 062223      |
| <i>DCM for SCO Manual Kit</i>   | 062765      |

To set up DCM to access a database

1. Define the database interface and network configuration.
2. Define the database action: read, insert (write), update, or delete.
3. Define the JANUS reader transaction fields and map the fields to the database table. For example, the second field in the JANUS reader transaction is numeric and corresponds to the third column in the database table.

---

## ***Sending a Transaction to the Database***

You use `im_setup_trx` and `im_standard_trx` for defining protocol parameters and sending a transaction to a database. You can use the default `im_setup_trx` protocol values, without calling `im_setup_trx`, or you can define your own values. The following table lists the default protocol values. For more information, see Chapter 2, “C Language Support.”

| <b>Description</b>                                       | <b>Default Value</b>                 |
|--|--------------------------------------|
| Communications port (COM1)                               | IM_COM1                              |
| Transmit timeout value (infinite)                        | IM_INFINITE_TIMEOUT                  |
| Receive timeout value (infinite)                         | IM_INFINITE_TIMEOUT                  |
| Read one record at a time (only affects read operations) | IM_DBPACE_ENABLE                     |
| Standby file and batch processing disabled               | <code>im_batch_enable</code> is off  |
| Do not ignore NAK during batch processing                | <code>im_dobest_enable</code> is off |
| System delimiter character (comma)                       | ,                                    |
| Field delimiter character (comma)                        | ,                                    |
| Maximum packet length                                    | 256 characters                       |
| No standby file ( <i>safety</i> = 0)                     | 0                                    |

**Note:** *Handshaking is always on when the JANUS reader accesses a host database.*

Your application handles two cases of database actions: database reads and other database transactions. A read operation returns data that your application must process. The data is either an ACK or NAK message from the database host or data fields that must be parsed. Database write, update, and delete operations return only an ACK or NAK message from the database host.

To set up a database write, update, or delete

1. If needed, use `im_setup_trx` to set up the protocol for the database server.
2. Use `im_standard_trx` to pack and transmit a record to the database.
3. Provide error trapping by checking the return status codes.

To set up a database read

1. If needed, use `im_setup_trx` to set up the protocol for the database server.
2. Use `im_standard_trx` to pack and transmit a record to the database.
3. Provide error trapping by checking the return status codes.
4. Use `im_parse_host_response` to parse the returned records until the end of the database records is reached.

## ***Checking the Return Status Codes***

---

The database functions provide many return codes to help you pinpoint an error. You must decide which errors to check for and how your application will handle each situation. In some situations your application may only need to verify the category of the error. In others, your application needs to verify the exact error condition.

For example, a database read operation may successfully read the database, but the data returned to the JANUS reader may overflow the receive buffer you defined. Your application can use one of the status code macros defined in Chapter 2, “C Language Support.” You can also test for the successful category by testing bit 4 in the return code. If bit 4 is set to 1 (mask with `0x0010`), you know that the database operated correctly and sent at least one record to the JANUS reader. However, you do not know that all of the data was received.

If your application needs to verify the exact error and provide a correction, you need to test for the specific status value. The following example shows two ways to test the return codes.

---

**Example**

```
* Checking return codes with macros and by value
*
status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszRead[i], 256,
                        pszInString, pszGetData, &chOperation);
if im_isgood(status)    //See if any data has been received.
{
    //Process received data.
    //Add your code here.
}

* Test for receive data and specific return code
status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszRead[i], 256,
                        pszInString, pszGetData, &chOperation);
if (status == IM_DCM_ACK_RCD)
{
    //Received data and successful parse.
    //Add your code here.
}
elseif (status == IM_DCM_TRUNCATED)
{
    //Received data but parse buffer too small
    //Add your code here.
}
elseif (status == IM_DCM_EXCESSFIELD)
{
    //Received data but too many fields
    //Add your code here.
}
}
```

The example referred to the symbolic name of the return code, such as `IM_DCM_ACK_RCD`. You can also check for the exact hex value. The following sections list the return code hex values for the DCM functions `im_parse_host_response`, `im_setup_trx`, and `im_standard_trx`, grouped as follows:

- By calling parameter
- In numerical order
- Symbolic return code with its hex value



---

## Return Codes Listed by Calling Parameter

The following two tables list the return codes arranged by the calling parameters and severity. The first table lists the return codes for the parameters that affect the standby file. The second table lists the return codes for accessing the remote database.

---

### *im\_standard\_trx* Return Codes for Manipulating the Standby File

| Request Type Parameter | Return Code | Description   |
|------------------------|-------------|---|
| IM_ERROR_RECORD        | 1A00        | Retrieved record from standby file  |
|                        | 5A07        | Standby file is empty   |
|                        | 9A08        | Standby file I/O error  |
|                        | 9A09        | Standby file is missing   |
| IM_ADVANCE_RECORD      | 1A00        | Retrieved record from standby file  |
|                        | 5A07        | Standby file is empty   |
|                        | 9A08        | Standby file I/O error  |
|                        | 9A09        | Standby file is missing   |
| IM_ZIP_RECORD          | 1A00        | All standby records sent successfully   |
|                        | 9A09        | Standby file is missing   |
|                        | 5A02        | NAK received. If <code>im_dobest_enable</code> is not set, then stop sending records. |
|                        | 9A03        | Transmit channel error  |
|                        | 9A04        | Receive channel timeout   |
|                        | 9A05        | Packet header error   |
|                        | 9A06        | Missing transaction ID  |

---

*im\_standard\_trx* Return Codes for Accessing the Remote Database

| Request Type Parameter | Return Code | Description   |
|------------------------|-------------|---|
| All                    | 1A00        | Transaction successful                                  |
|                        | 1A10        | Received message on Read operation                      |
|                        | 5A11        | Data was truncated                                      |
|                        | 5A12        | Too many fields   |
|                        | 1A01        | Transaction successful, ACK                             |
|                        | 5A02        | Transaction failed, NAK                                 |
|                        | 5A20        | Record stored in standby file successfully              |
|                        | 5A21        | Record stored in standby file, but upload standby error |
|                        | 9A03        | Transmit failed   |
|                        | 9A04        | Receive port timeout                                    |
|                        | 9A40        | Buffer overflow   |
|                        | 9A41        | Buffer overflow with upload standby error               |
|                        | 9A05        | Packet header error                                     |
|                        | 9A06        | Missing transaction ID                                  |
|                        | 9A08        | Standby file I/O error                                  |
|                        | 9A09        | Standby file is missing                                 |

---

*im\_parse\_host\_response Return Codes*

| Request Type Parameter | Return Code | Description              |
|------------------------|-------------|--------------------------|
| All                    | 1A10        | Received message         |
|                        | 5A11        | Data was truncated       |
|                        | 5A12        | Too many fields          |
|                        | 1A01        | Transaction success, ACK |
|                        | 5A02        | Transaction failed, NAK  |
|                        | 9A04        | Receive port timeout     |
|                        | 9A05        | Packet header error      |

---

*im\_setup\_trx Return Codes*

| Request Type Parameter | Return Code | Description  |
|------------------------|-------------|--|
| All                    | 1A00        | Protocol parameters set successfully   |
|                        | 9A08        | Standby file I/O error, check system errno value<br>Standby file format is wrong |

---

## ***Return Codes Listed in Numerical Order***

The following tables list the return codes for each DCM function in numerical order.

---

### *im\_standard\_trx Return Codes*

| Return code | Severity   | Description  |
|-------------|------------|--|
| 1A00        | 00 Success | Action successful  |
| 1A01        | 00 Success | Transaction successful, ACK received   |
| 1A10        | 00 Success | Received message on Read operation   |
| 5A02        | 01 Warning | Transaction failed, NAK received. If im_dobest_enable is not set, then stop sending records. |
| 5A07        | 01 Warning | Standby file is empty  |
| 5A11        | 01 Warning | Data was truncated   |
| 5A12        | 01 Warning | Too many fields  |
| 5A20        | 01 Warning | Record stored in standby file successfully   |
| 5A21        | 01 Warning | Record stored in standby file, but upload standby error                                      |
| 9A03        | 10 Error   | Transmit failed  |
| 9A04        | 10 Error   | Receive port timeout   |
| 9A05        | 10 Error   | Packet header error  |
| 9A06        | 10 Error   | Missing transaction ID   |
| 9A08        | 10 Error   | Standby file I/O error   |
| 9A09        | 10 Error   | Standby file is missing  |
| 9A40        | 10 Error   | Buffer overflow  |
| 9A41        | 10 Error   | Buffer overflow with upload standby error  |

---

*im\_parse\_host\_response Return Codes*

| Return code | Severity   | Description              |
|-------------|------------|--------------------------|
| 1A01        | 00 Success | Transaction success, ACK |
| 1A10        | 00 Success | Received message         |
| 5A02        | 01 Warning | Transaction failed, NAK  |
| 5A11        | 01 Warning | Data was truncated       |
| 5A12        | 01 Warning | Too many fields          |
| 9A04        | 10 Error   | Receive port timeout     |
| 9A05        | 10 Error   | Packet header error      |

---

*im\_setup\_trx Return Codes*

| Return code | Severity   | Description  |
|-------------|------------|--|
| 1A00        | 00 Success | Protocol parameters set successfully   |
| 9A08        | 10 Error   | Standby file I/O error, check system errno value<br>Standby file format is wrong |

---

## Symbolic Return Codes

This table lists the return codes for all three DCM functions.

| Return Code          | Hex Value | Description                      |
|----------------------|-----------|----------------------------------|
| IM_DCM_OK            | 1A00      | Execution success                |
| IM_DCM_ACK_RCD       | 1A01      | ACK received                     |
| IM_DCM_MSG_RCD       | 1A10      | Data received                    |
| IM_DCM_NAK_RCD       | 5A02      | NAK received                     |
| IM_DCM_NO_RECORD     | 5A07      | No more log records              |
| IM_DCM_TRUNCATED     | 5A11      | Received data truncated          |
| IM_DCM_EXCESSFIELD   | 5A12      | Fields overflow                  |
| IM_DCM_STANDBY       | 5A20      | Record logged                    |
| IM_DCM_STANDBY_TXERR | 5A21      | Logged but upload error          |
| IM_DCM_NOTRANSMIT    | 9A03      | Transmit fails                   |
| IM_DCM_TIMEOUT       | 9A04      | Receive timeout                  |
| IM_DCM_HEAD_ERR      | 9A05      | Packet header error              |
| IM_DCM_TRANSID_ERR   | 9A06      | Transaction ID is missing        |
| IM_DCM_NO_HANDLE     | 9A08      | Standby file is missing          |
| IM_DCM_FILE_ERR      | 9A09      | Standby file I/O error           |
| IM_DCM_FILLED        | 9A40      | Buffer overflow                  |
| IM_DCM_FILLED_TXERR  | 9A41      | Buffer overflow and upload error |

## Using a Standby File

---

The `im_setup_trx` function supports using a standby file to store records when the transmit channel is unavailable. For example, you may use the JANUS reader to collect inventory data from a warehouse. The reader stores the records until you set it in the communications dock and then transmits the standby records to a database. By default, the standby file is not activated, so your application program must handle activating and deactivating the standby file.

You activate the standby file by opening a file and passing the file handle as the *hsafety* parameter of `im_setup_trx`. You deactivate the standby file by passing 0 for the *hsafety* parameter. For more information on the `im_setup_trx` parameters, see Chapter 2, “C Language Support.”

Your application must open and close the standby file in low level file I/O `open()` with binary mode and readable/writeable mode. For example, you may open a file named `standby.txt` as follows:

```
handle = open("standby.txt", O_CREAT | O_BINARY | O_RDWR,  
S_IREAD | S_IWRITE);
```


When you pass the standby file handle the first time after creating the file, `im_setup_trx` initializes the standby file with the correct format for you.

## Standby File Structure

This section provides detailed file structure information for troubleshooting. Usually you do not need this level of detail. The PSK library functions and the following open statement create the correct file.

```
handle = open("standby.txt", O_CREAT | O_BINARY | O_RDWR,
S_IREAD | S_IWRITE);
```

The first 14 bytes of the standby file are the file header. The remainder of the file contains records. The following figure shows the header structure. The first 4 bytes of header is the read pointer and the next 4 bytes of header is the write pointer. The next 4 bytes are reserved for future use. The last 2 bytes of the header are two \$ characters that identify this file as a standby file.



JPSK.004

Each record starts with 2 bytes for length of the record. Each record is variable length and ends with a null character.

If you activate the standby file and the file length is zero, the standby file is initialized with a header but no records. If the file length is not zero (0), the file header is read.

Each record logged to the standby file is written at the byte specified by the write pointer. After the new record is written, the write pointer in the header is updated.

When the transmit channel is available again, the logged records are uploaded. As each record is read for uploading, the read pointer in the header is updated. When all the records have been sent, the read pointer reaches the write pointer. Then the file is reset to the initial state, which has only the 14 byte header in the file.



The standby file retains data between program runs. You can exit your application or reboot the reader without losing data. However, if you reboot the reader while an application is running, the standby file may contain corrupt data. In this case you need to delete the standby file so that the next application will run correctly.

To simplify error trapping, you do not need to use a standby file when you first design an application that uses DCM's database server. After you test the application design for the database server protocol and accessing the database, then put the standby file function into the program. In this way, you can avoid the confusion of deciphering too many error return codes.

## Sample Program

```
//*****im_setup_trx *****
//*****im_standard_trx *****
//*****im_parse_host_response *****
// This program demonstrates the PSK's DCM support functions.
//
// First, it discards any records left in the database server queue by a
// previous read transaction.
// Second, it deletes all records from the BONUS table.
// Third, it uses the batch capability to store 5 records in the
// standby file, and then write the 5 records to the database.
// Fourth, it writes the remaining records in the reader without batching them.
// Fifth, it reads records from the database without pacing and then with pacing.
// Sixth, it demonstrates how to discard records after reading the first
// 3 records.
//
// The program is divided into the following routines:
// DemoInit() - Initializes the database server
// DemoBatch() - Shows the batch process case
// DemoStandby() - Shows the standby file capability
// HandNoPace() - Reads records with handshaking and no pacing protocol
// HandPace() - Reads records with handshaking and pacing protocol
// HandDiscard() - Reads 3 records and then discards the rest of records.
//
// Note: You must load reader services and a protocol handler on the JANUS reader
// to enable send/receive buffer functions.
// Run these TSR's at DOS prompt before running this program:
// rservice
// phimec 1 ( 1 is COM1)
// On the DCM side, you need to set up database table access and the TSTDEL,
// TSTINS, TSTRD transactions.
//*****

#include <stdio.h>
#include <conio.h>
#include <stdlib.h>
#include <dos.h>
#include <string.h>
#include <fcntl.h>
```

## 2D JANUS PSK for C/C++ Reference Manual

```
#include <io.h>
#include <sys\stat.h>
#include "imgenic.h"
#include "im20lib.h"

typedef struct BonusType {
char *emp; //Mapped to BONUS table's NAME column
char *dept; //Mapped to BONUS table's DEPT column
char *salgrade; //Mapped to BONUS table's SALGRADE column
char *end;
} BONUSTYPE;

static BONUSTYPE EmpTable[]={
{"Steve Chan", "Network", "1", NULL},
{"Stuart Baine", "Software", "2", NULL},
{"Trixie Austin", "Hardware", "3", NULL},
{"Marcus Albrod", "Portable", "4", NULL},
{"Jeff Eastone", "Network", "5", NULL},
{"Roy Christoff", "Software", "6", NULL},
{"KK Luang", "Hardware", "7", NULL},
{"Joe Arant", "Portable", "8", NULL},
{"Matt Hartinger", "Network", "9", NULL},
{"Tom Dard", "Software", "10", NULL},
{"Ted Millen", "Hardware", "11", NULL},
{"Robert Chian", "Portable", "12", NULL},
{"Doug Kaatz", "Network", "13", NULL},
{"RuthAnn Hso", "Software", "14", NULL},
{"Will Powers", "Hardware", "15", NULL},
{"Kevin Cuffman", "Portable", "16", NULL},
{"C. K. Koonze", "Network", "17", NULL},
{"Ray Law", "Software", "18", NULL},
{"Mark Robinns", "Hardware", "19", NULL},
{"Cathy McCree", "Portable", "20", NULL},
{"Shar Leung", "Network", "21", NULL},
{"Jack Lincoln", "Software", "22", NULL},
{"Joe Schoening", "Hardware", "23", NULL},
{"Bill McDowell", "Portable", "24", NULL},
{"Sophia Renouard", "Network", "25", NULL},
{"Yong Qin Lee", "Software", "26", NULL},
{"Joe Waters", "Hardware", "27", NULL},
{"Paul Swann", "Portable", "28", NULL},
{"Mack Pickett", "Network", "29", NULL},
{"Raymond Wallice", "Software", "30", NULL},
{"Delanie Zerbi", "Hardware", "31", NULL},
{"Lisa Vanian", "Portable", "32", NULL},
{NULL, NULL, NULL, NULL}
};

static IM_COM_PORT iPort = IM_COM1; /* Uses communications port 1*/

IM_UCHAR chOperation = 'R'; /*'W', ' Operation char

#define FLDSIZE 16
static char pszEmployee[FLDSIZE+1]="\0"; //Buffer mapped to Employee
static char pszDepart[FLDSIZE+1]="\0"; //Buffer mapped to department
static char pszSalary[FLDSIZE+1]="\0"; //Buffer mapped to Salary grade
static char pszDummy[FLDSIZE+1]="\0"; //Buffer mapped to dummy
```

```

//data structure to get fields from packet.
static IM_DCMSTRN   pszGetData[] = {
    { pszEmployee, sizeof(pszEmployee)},
    { pszDepart,   sizeof(pszDepart)},
    { pszSalary,   sizeof(pszSalary)},
    { pszDummy,    sizeof(pszDummy)},
    { NULL, 0}
};

#define DEPT_NUM    4                //Number of dempartments

static char *pszReadSoftware[] ={"Software", NULL};
static char *pszReadHardware[] ={"Hardware", NULL};
static char *pszReadNetwork[] ={"Network", NULL};
static char *pszReadPortable[] ={"Portable", NULL};

static char **pszRead[DEPT_NUM + 1] = {
    pszReadNetwork,
    pszReadSoftware,
    pszReadHardware,
    pszReadPortable,
    NULL
};

static IM_UCHAR   pszInString[257];    // pointer to output string

static char       standby[]="standby.bin";    //Standby file name
static int        standby_fh = 0;

void DemoInit(void );
void DemoBatch(void );
void DemoStandby(void );
void HandNoPace(void);
void HandPace(void);
void HandDiscard(void);

/*****/

void main (void)
{

    //Always open standby file for use
    if ( (standby_fh = open(standby, O_CREAT | O_BINARY |O_RDWR, S_IREAD|S_IWRITE)) == -1)
    {
        printf("open file error\n");
        exit(1);
    }

    //Send IM_DBRQT_DISCARD to discard all records left over from database server
    DemoInit();

    //Use IM_BATCH_ENABLE to delete all records in BONUS table
    DemoBatch();

    //Use standby function to insert records to BONUS table
    DemoStandby();

    //Using handshaking with no pacing protocol
    //Read records that match dept criteria, using a FOR loop without pacing
    HandNoPace();
}

```

## 2D JANUS PSK for C/C++ Reference Manual

```
//Using handshaking with pacing protocol
//Read records that match dept criteria, using a FOR loop with pacing
HandPace();

//Using handshaking with pacing protocol
//Read 3 records that match dept criteria, and then discard the rest of records
HandDiscard();

}

//*****
// Initialize database access.
// First, read data from communications port until timeout occurs, which
// means no more data received.
// Use TSTRD with IM_DBRQT_DISCARD to discard any records left in
// the database.
//*****

void DemoInit(void)
{
IM_USHORT    status;
IM_USHORT    actual_length = 0;
IM_USHORT    iDBPrctl;           // handshake, pace, request type
IM_UCHAR     com_buff[257];      // Buffer for receiving

//Flush out all packets left from previous session.
im_cancel_rx_buffer(iPort);      //Clear buffer
//Read data until timeout occurs

do
{
    status = im_receive_buffer(iPort, sizeof(com_buff)-1, com_buff,
                               3000, &actual_length);
    if (status == 0x0600 && actual_length > 0)
        printf("%s\n", com_buff);
} while ( status != 0x4601);

iDBPrctl = IM_DBPACE_ENABLE;
//Set up communications port and protocol
status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrctl,
                     ',', ',', ',', 256, standby_fh);

if (status != IM_DCM_OK)
    printf("error: %x\n", status);

do
{
    //Send discard transaction to the database server.
    status = im_standard_trx(RedpszTid, IM_DBRQT_DISCARD, NULL, 256,
                             pszInString, pszGetData, &chOperation);

    if (status != IM_DCM_ACK_RCD && status != IM_DCM_NAK_RCD )
        printf("Init error: %x\n", status);
} while ( status != IM_DCM_NAK_RCD && status != IM_DCM_ACK_RCD);

printf("\nInit Complete!\n");
}
```

```

//Wait for 1 second (optional)
im_standby_wait(1000);

}

//*****
//Demonstrate batch process to clean up the database table.
// Log records into the standby file, and then flush them.
// Use TSTDEL to delete all records from BONUS table.
// Use IM_BATCH_ENABLE to log transactions, then process in batch mode
//*****

void DemoBatch(void)
{
BONUSTYPE      *pszBonus;
IM_USHORT      status;
IM_USHORT      del_status;
IM_USHORT      iDBPrtcl;           // handshake, pace, request type
IM_UCHAR       pszTid[8]="TSTDEL"; //delete transaction

//Turn on batch process
iDBPrtcl = IM_BATCH_ENABLE + IM_DBPACE_ENABLE;

status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrtcl,
                    ' ', NULL, ' ', 256, standby_fh);

if (status != IM_DCM_OK)
    printf("Batch setup error: %x\n", status);

//Send all records first
pszBonus = EmpTable;

while (pszBonus->emp != NULL)
{
    status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszBonus, 256,
                            pszInString, pszGetData, &chOperation);

    //It will receive IM_DCM_STANDBY, because IM_BATCH_ENABLE is on
    if (status != IM_DCM_STANDBY)
        printf("Standby error: %x\n", status);

    pszBonus++; //go to next record
}

//Flush standby records
do
{
    //Continue flushing standby records until receive IM_DCM_OK
    status = im_standard_trx(pszTid, IM_ZIP_RECORD, pszBonus, 256, pszInString,
                            pszGetData, &chOperation);

    //If the TSTDEL transaction deletes a record in table, then reader receives
    // ACK and im_standard_trx() continues sending logged records until the
    // standby file is empty. When the file is empty, the function returns
    // IM_DCM_OK.
    // If the database table has no records, then the DCM TSTDEL transaction sends

```

## 2D JANUS PSK for C/C++ Reference Manual

```
// NAK to the reader. im_standard_trx() returns IM_DCM_NAK_RCD and any records
// remain in the standby file. Use IM_ADVANCE_RECORD to discard any
// remaining records in the standby file.
// If IM_DOBEST_ENABLE is on, then do not check for IM_DCM_NAK_RCD.
// im_standard_trx() treats NAK the same as ACK and uploads the next record.
if (status == IM_DCM_NAK_RCD)
{
    printf("NAK: %s\n", pszInString);    //See which record is

    //Skip this TSTDEL transaction because no records in database table.
    del_status = im_standard_trx(pszTid, IM_ADVANCE_RECORD, pszBonus, 256,
                                pszInString, pszGetData, &chOperation);

    //If Error occurs, print it
    if (del_status != IM_DCM_OK)
        printf("%x\n", del_status);
}
}

while (status != IM_DCM_OK);
printf("\nDelete Complete!\n");
}

//*****
//Demonstrate standby functionality.
// Use TSTINS transaction to insert all records into the BONUS table
// using a standby file.
// Use batch process to log five transactions, then turn off batch process
// and send remaining transactions in normal mode. Upload all standby
// records before sending current record.
//*****

void DemoStandby(void)
{
    IM_USHORT    i;
    BONUSTYPE    *pszBonus;
    IM_USHORT    status;
    IM_USHORT    iDBPrctl;           // handshake, pace, request type
    IM_UCHAR     pszTid[8]="TSTINS"; //delete transaction.

    //Turn on Batch process
    iDBPrctl = IM_BATCH_ENABLE + IM_DBPACE_ENABLE;

    status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrctl,
                          ',', ',', 256, standby_fh);

    if (status != IM_DCM_OK)
        printf("error: %x\n", status);

    //Process 5 records in batch mode
    pszBonus = EmpTable;

    for (i= 0; i < 5; i++)
    {
        status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszBonus, 256,
                                pszInString, pszGetData, &chOperation);

        if (status != IM_DCM_STANDBY)
            printf("Standby error: %x\n", status);
    }
}
```

```

    pszBonus++;    //go to next records
}

//Turn off batch processing
iDBPrtcl = IM_DBPACE_ENABLE;
status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrtcl,
                    ',', NULL, ',', 256, standby_fh);

if (status != IM_DCM_OK)
    printf("error: %x\n", status);

//Sending the rest of records.
while (pszBonus->emp != NULL)
{
    status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszBonus, 256,
                            pszInString, pszGetData, &chOperation);

    if (status != IM_DCM_ACK_RCD)
        printf("Sending error: %x\n", status);

    pszBonus++;    //go to next record
}

//Flush standby records and make sure no records left in standby file
do
{
    status = im_standard_trx(pszTid, IM_ZIP_RECORD, pszBonus, 256,
                            pszInString, pszGetData, &chOperation);

    //See what is problem
    if (status != IM_DCM_OK)
        printf("Flush error: %x\n", status);
}
while (status != IM_DCM_OK);
printf("\nInsert Complete!\n");

//Wait for 5 seconds
im_standby_wait(5000);
}

//*****
// Demonstrate reading records without pacing protocol.
// TSTRD transaction reads records, without pacing protocol.
// It reads records by department, so it needs to loop thru 4 times.
//*****

void HandNoPace(void)
{
    IM_USHORT    i;
    IM_USHORT    status;
    IM_USHORT    iDBPrtcl;    // Handshake, No pace, request type
    IM_UCHAR     pszTid[16]="TSTRD";

    //Handshaking, no pacing
    iDBPrtcl = 0;

    //Set up protocol
    status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrtcl,
                        ',', ',', 256, standby_fh);

```

## 2D JANUS PSK for C/C++ Reference Manual

```
if (status != IM_DCM_OK)
    printf("error: %x\n", status);

//Read records with FOR loop. Each loop covers each department.
for (i = 0; i < DEPT_NUM; i++)
{
    status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszRead[i], 256,
        pszInString, pszGetData, &chOperation);

    if (status & 0x0010) //See if data has been received
    {
        do
        {
            //Display Salary Grade, Employee name, department on screen.
            printf("%s, %s, %s\n", pszGetData[2].pszField,
                pszGetData[0].pszField, pszGetData[1].pszField);

            //Get next record because protocol is no pace.
            status = im_parse_host_response( 256, pszInString, pszGetData,
                &chOperation);

        } while ((status & 0x0010) != 0); //End of records is ACK/NAK,
            // instead of data received.
    }

    //Returns ACK when no more records coming from database
    if (status != IM_DCM_ACK_RCD)
    {
        printf("NoPace: %x\n", status);
        printf("%s\n", pszInString);
    }
}

printf("\nRead No Pace Complete!\n");
}

//*****
// Demonstrate reading records with pacing protocol on.
// TSTRD transaction reads records with pacing protocol on.
// It reads records by department, so it needs to loop thru 4 times.
//*****

void HandPace(void)
{
    IM_USHORT    i;
    IM_USHORT    status;
    IM_USHORT    iDBPrctl; // handshake, pace, request type
    IM_UCHAR     pszTid[16]="TSTRD";

    //Handshaking and pacing.
    iDBPrctl = IM_DBPACE_ENABLE;

    //Set up protocol
    status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrctl,
        ',', ',', 256, standby_fh);

    if (status != IM_DCM_OK)
        printf("error: %x\n", status);
}
```



```

//Read records with FOR loop. Each loop covers each department.
for (i= 0; i < DEPT_NUM; i++)
{
    //Read first record back if record exists
    status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszRead[i], 256,
        pszInString, pszGetData, &chOperation);

    if ( status & 0x0010)    //data received
    {
        do
        {
            //Display Salary Grade, Employee name, Department on screen.
            printf("%s, %s, %s\n", pszGetData[2].pszField,
                pszGetData[0].pszField, pszGetData[1].pszField);

            //wait 2 seconds
            im_standby_wait(2000);

            //Ask for next records
            status = im_standard_trx(pszTid, IM_DBRQT_NEXTROW, NULL, 256,
                pszInString, pszGetData, &chOperation);

        } while ((status & 0x0010) != 0); //End of records is ACK/NAK,
            // instead of data received.
    }

    //Returns ACK when no more records coming from database
    if (status != IM_DCM_ACK_RCD)
    {
        printf("Pace: %x\n", status);
        printf("%s\n", pszInString);
    }
}
printf("\nRead Pace Complete!\n");
}

//*****
//Demonstrate discarding records with pacing protocol on.
//*****

void HandDiscard(void)
{
    IM_USHORT    i;
    IM_USHORT    j;
    IM_USHORT    status;
    IM_USHORT    iDBPrctl;           // handshake, pace, request type
    IM_UCHAR     pszTid[16]="TSTRD";
    IM_UCHAR     chPaceChar;

    //Handshaking and pacing.
    iDBPrctl = IM_DBPACE_ENABLE;

    //Set up protocol
    status = im_setup_trx(iPort, 240, IM_INFINITE_TIMEOUT, iDBPrctl,
        ',, ', 256, standby_fh);

    if (status != IM_DCM_OK)
        printf("error: %x\n", status);
}

```

## 2D JANUS PSK for C/C++ Reference Manual

```
//Read 3 records with FOR loop. Each loop covers a department.
for (i= 0; i < DEPT_NUM; i++)
{
    //Read first record in database if record exists
    status = im_standard_trx(pszTid, IM_DBRQT_DATA, pszRead[i], 256,
                            pszInString, pszGetData, &chOperation);

    //Initialize count so that after 3 records, we can discard the
    // rest of the records
    j = 0;
    if ( status & 0x0010)    //data received
    {
        do
        {
            j++;

            //Display Salary Grade, Employee name, department on screen.
            printf("%s, %s, %s\n", pszGetData[2].pszField,
                pszGetData[0].pszField, pszGetData[1].pszField);

            if (j > 2)
                chPaceChar = IM_DBRQT_DATA;    //'S' -Discard records
            else
                chPaceChar = IM_DBRQT_NEXTROW;    //'N' -next row

            //wait 2 seconds
            im_standby_wait(2000);

            //Ask for next record or discard rest of records
            status = im_standard_trx(pszTid, chPaceChar, NULL, 256,
                                    pszInString, pszGetData, &chOperation);

        } while ((status & 0x0010) != 0);    //End of records is ACK/NAK,
            // instead of data received.
    }

    if (status != IM_DCM_ACK_RCD)
    {
        printf("Discard: %x\n", status);
        printf("%s\n", pszInString);
    }
} //for

printf("\nRead Discard Complete!\n");
}
```



## *Status Codes*



*This appendix lists the status code hex values and error messages. Use the tables in this appendix to look up the meaning of a specific status code.*

## **Status Code Bit Values**

---

Most of the PSK functions return status codes. You can use the codes to test for error conditions that your application will act upon.

How you test for the status codes depends on the complexity of the function returning the status and your application needs. In some cases, you may use the status code macros discussed in “Status Code Macros” in Chapter 2 to check the severity level. In other cases, you may want to check the exact status code value.

Each status code is a 16-bit word structured as follows:

|    |    |    |    |    |   |   |   |   |   |   |   |   |   |   |
|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| 15 | 14 | 13 | 12 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| s  | s  | f  | f  | f  | f | f | m | m | m | m | m | m | m | m |

JPSK.002

where:

*s* is severity code:   00 = Success  
                           10 = Error  
                           01 = Warning  
                           11 = Fatal

*f* is the subsystem code, explained later in this appendix.

*m* is the message code that identifies the error or warning condition.

The status codes are IM\_USHORT (unsigned short) values.

The tables in this appendix list the hex value of the message codes.

## ***Status Codes Listed Numerically***

---

The following table lists the return codes and the error message text provided by `im_message` and `imMessage`. For each message, there is an associated status return code, subsystem, and severity.

Some messages are abbreviated to fit the display and to save memory on the JANUS reader. The table includes an easy-to-read version of the abbreviated messages.

---

### *Status Codes and Error Messages Listed in Numerical Order*

| Hex Code | Severity | Subsystem | Reader Message and Description                               |
|----------|----------|-----------|--|
| 0000     | Good     | NO        | Request successful   |
| 0001     | Good     | NO        | Prohibited   |
| 0100     | Good     | RS        | Rservice request success<br>Reader services successful       |
| 0103     | Good     | RS        | Rservice resume success<br>Reader services resume successful |
| 0200     | Good     | CM        | Request success<br>Request successful                        |
| 0201     | Good     | CM        | Read End Of Record<br>End of record reached                  |
| 0202     | Good     | CM        | Read End Of File<br>End of file reached                      |
| 0300     | Good     | SC        | Scan success<br>Scan successful                              |
| 0400     | Good     | DC        | Success<br>Successful command                                |
| 0401     | Good     | DC        | Symbology already enabled<br>Symbology is already enabled    |
| 0402     | Good     | DC        | Symbology not enabled<br>Symbology is not enabled            |
| 040A     | Good     | DC        | Good decode<br>Successful decode                             |
| 040B     | Good     | DC        | Intermediate row re-read<br>Intermediate row reread          |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 040C     | Good     | DC        | Intermediate decoded<br>Intermediate raw decoded   |
| 0421     | Good     | DC        | Default command symbology  |
| 0422     | Good     | DC        | Mixed ASCII format   |
| 0500     | Good     | RW        | RW success<br>Reader Wedge successful  |
| 0505     | Good     | RW        | No rdr cmds parsed<br>No reader commands parsed  |
| 0506     | Good     | RW        | Valid rdr cmds parsed<br>Valid reader commands parsed  |
| 0509     | Good     | RW        | Accumulating rdr cmd<br>Accumulating reader command  |
| 050A     | Good     | RW        | Rdr cmd override<br>Reader command override  |
| 050B     | Good     | RW        | Rdr cmd enter accum<br>Reader command enter accumulation   |
| 050C     | Good     | RW        | Rdr cmd exit accum<br>Reader command exit accumulation   |
| 050D     | Good     | RW        | Accumulate multi-read labels<br>Accumulating multiread labels                                    |
| 0510     | Good     | RW        | ENTER rdr cmd parsed<br>An Enter reader command was parsed                                       |
| 0513     | Good     | RW        | Protected field rdr cmd parsed<br>Protected field was parsed                                     |
| 0517     | Good     | RW        | Keycode label parsed<br>Keycode label was parsed   |
| 0518     | Good     | RW        | Isolated ENTER cmd parsed<br>An isolated Enter command was parsed                                |
| 0519     | Good     | RW        | Good rdr cmd on exit accum<br>A reader command was parsed successfully on exit from accumulation |
| 051A     | Good     | RW        | Good rdr cmd on ENTER<br>A reader command was parsed successfully when Enter was parsed          |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 051C     | Good     | RW        | Enter accum parsed<br>An Enter Accumulate has been parsed when accumulating |
| 051D     | Good     | RW        | Exit multi-read<br>A label terminating a multiple-read sequence was scanned |
| 051E     | Good     | RW        | Enter multi-read<br>A label beginning a multiple-read sequence was scanned  |
| 0521     | Good     | RW        | No comms status<br>No communications status to report                       |
| 0525     | Good     | RW        | Rdr cmds parsed<br>Reader commands forwarded to the application were parsed |
| 0600     | Good     | CU        | Comm success<br>Communications operation success                            |
| 0601     | Good     | CU        | Comm Buff done<br>Communications buffer done                                |
| 0800     | Good     | PM        | PM success<br>Power management successful                                   |
| 0A00     | Good     | TM        | Timer success<br>Timer operation successful                                 |
| 0B00     | Good     | BP        | Beep success<br>Beeper call successful                                      |
| 0E00     | Good     | IM        | String Extract Complete   |
| 0E01     | Good     | IM        | String Append complete  |
| 0E02     | Good     | IM        | Search string found   |
| 0E03     | Good     | IM        | String Copy complete  |
| 0E04     | Good     | IM        | Operation success<br>Successful operation                                   |
| 0F00     | Good     | LG        | Successful operation  |
| 1000     | Good     | KB        | Expanded keypad success<br>Expanded keyboard buffer successful              |
| 100A     | Good     | KB        | Expanded buffer enabled   |
| 100B     | Good     | KB        | Expanded buffer disabled  |
| 1100     | Good     | SS        | System Config success<br>System configuration successful                    |



---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 1200     | Good     | KP        | Keypad success<br>Successful keypad operation  |
| 1300     | Good     | DP        | Display success<br>Successful display operation  |
| 1A00     | Good     | EX        | Execution success<br>Transaction successful  |
| 1A01     | Good     | EX        | ACK received<br>Transaction successful, ACK received   |
| 1A10     | Good     | EX        | Data received<br>Received host message on Read operation                                     |
| 4200     | Warning  | CM        | Not all config items copied<br>Not all configuration items copied                            |
| 4201     | Warning  | CM        | Rdr Cmd terminated config cmd<br>Reader command terminated configuration command string      |
| 4202     | Warning  | CM        | Client should not be notified  |
| 4502     | Warning  | RW        | Input timeout  |
| 4503     | Warning  | RW        | No input data  |
| 450E     | Warning  | RW        | The app should be notified<br>The application should be notified                             |
| 4529     | Warning  | RW        | Input from source other than requested<br>Input from source is other than the ones requested |
| 452A     | Warning  | RW        | RWTSR already loaded   |
| 452B     | Warning  | RW        | Prepare for reboot command received  |
| 452C     | Warning  | RW        | Cancel reboot command received   |
| 4600     | Warning  | CU        | Warning buff canceled<br>Buffer canceled   |
| 4601     | Warning  | CU        | Comm Timeout warning<br>Communications timeout   |
| 4602     | Warning  | CU        | Comm had no client to cancel<br>Communications had no client to cancel                       |
| 4603     | Warning  | CU        | Comm Util no PH for config<br>No protocol handler to configure                               |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 4604     | Warning  | CU        | Prot handler not loaded<br>Protocol handler is not yet loaded                      |
| 4605     | Warning  | CU        | Prot handler already receiving<br>Protocol handler is already receiving            |
| 4606     | Warning  | CU        | PH not active for link request<br>Protocol handler is not active for link request  |
| 4A00     | Warning  | TM        | Timer not active<br>Timer not currently active                                     |
| 5001     | Warning  | KB        | Expanded buffer installed<br>Expanded keyboard buffer installed or disabled        |
| 5201     | Warning  | KP        | Backdoor Comms failed<br>Backdoor communications failure                           |
| 5A02     | Warning  | EX        | NAK received<br>Transaction failed, NAK received                                   |
| 5A07     | Warning  | EX        | No more log records<br>Standby file is empty                                       |
| 5A11     | Warning  | EX        | Received data truncated<br>Data was truncated                                      |
| 5A12     | Warning  | EX        | Fields overflow<br>Too many fields   |
| 5A20     | Warning  | EX        | Record logged<br>Record successfully stored in standby file                        |
| 5A21     | Warning  | EX        | Logged but upload error<br>Record stored in standby file, but upload standby error |
| 8100     | Error    | RS        | Rservice invalid request code<br>Invalid function code received                    |
| 8101     | Error    | RS        | Rservice not installed<br>Reader services is not installed                         |
| 8102     | Error    | RS        | Rservice resume failed<br>Reader services resume failed                            |
| 8103     | Error    | RS        | Rservice or App out of date<br>Reader services or application is out of date       |
| 8104     | Error    | RS        | RWTSR not connected<br>Reader Wedge TSR is not installed                           |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 8200     | Error    | CM        | Invalid Object  |
| 8201     | Error    | CM        | Invalid subfunction   |
| 8202     | Error    | CM        | Invalid Param length<br>Invalid parameter length                                    |
| 8203     | Error    | CM        | Invalid Param val<br>Invalid parameter value  |
| 8204     | Error    | CM        | Invalid Param 1 value<br>Invalid first parameter value                              |
| 8205     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and no check digit)   |
| 8206     | Error    | CM        | Invalid param 2 value<br>Invalid second parameter value                             |
| 8207     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and full ASCII)       |
| 8208     | Error    | CM        | Invalid Code 39 config<br>Invalid Code 39 configuration (HIBC and mixed full ASCII) |
| 8209     | Error    | CM        | Invalid Param 3 value<br>Invalid third parameter value                              |
| 820A     | Error    | CM        | Invalid Codabar cfg<br>Invalid Codabar configuration (ABC and discard start/stop)   |
| 820B     | Error    | CM        | Protocol not loaded   |
| 820C     | Error    | CM        | Invalid comm or protcl<br>Invalid port or protocol specified                        |
| 820D     | Error    | CM        | No end quote<br>No ending quote found   |
| 820E     | Error    | CM        | No dbl quote<br>No double quote (might be missing an opening quote)                 |
| 820F     | Error    | CM        | Invalid parser state  |
| 8210     | Error    | CM        | Invalid config cmd<br>Invalid configuration command                                 |
| 8211     | Error    | CM        | Client returned err<br>Client deemed configuration command invalid                  |
| 8212     | Error    | CM        | Invalid beep duration   |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 8213     | Error    | CM        | Invalid beep freq<br>Invalid beep frequency   |
| 8214     | Error    | CM        | Invalid beep vol<br>Invalid beep volume   |
| 8215     | Error    | CM        | Beep vol alrdy off<br>Beep volume already off   |
| 8216     | Error    | CM        | Beep vol alrdy on<br>Beep volume already on   |
| 8217     | Error    | CM        | Invalid beep specifier<br>Invalid beep specifier (must be "L" or "H")                             |
| 8218     | Error    | CM        | Inappropriate protcl<br>Inappropriate configuration for the current protocol                      |
| 8219     | Error    | CM        | BIOS rejected set config<br>BIOS rejected the set configuration command                           |
| 821A     | Error    | CM        | Bld string too small<br>Configuration command string object is too small                          |
| 821B     | Error    | CM        | Invalid Build cmd<br>Configuration ID is invalid  |
| 821C     | Error    | CM        | Invalid Build param<br>Invalid build parameter  |
| 821D     | Error    | CM        | No Build Func<br>No build function  |
| 821E     | Error    | CM        | No more build entries   |
| 821F     | Error    | CM        | No more WM bld entries<br>No more build entries in wedge lookup table                             |
| 8220     | Error    | CM        | No more WM bld entries<br>No more build entries in wedge lookup table for "build next" WM command |
| 8221     | Error    | CM        | No LUM key entries<br>No entries found in the LUM key table                                       |
| 8222     | Error    | CM        | WM entry not found<br>No match in lookup table for specified character                            |
| 8223     | Error    | CM        | Invalid Temp config<br>At least one parameter rejected by client (see JANUS.ERR)                  |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 8224     | Error    | CM        | Config Item not found<br>Configuration item is not found                                       |
| 8225     | Error    | CM        | File Open err<br>File open error   |
| 8226     | Error    | CM        | File Write err<br>File write error   |
| 8227     | Error    | CM        | File Read err<br>File read error   |
| 8228     | Error    | CM        | Read record too large<br>Record too large to read  |
| 8229     | Error    | CM        | Invalid Hex Char in esc seq<br>Invalid hex character found in the escape sequence              |
| 822A     | Error    | CM        | Invalid esc sequence<br>Invalid escape sequence  |
| 822B     | Error    | CM        | Read file not opened<br>Read attempted on a file that was not opened                           |
| 822C     | Error    | CM        | Write file not opened<br>Write attempted on a file that was not opened                         |
| 822D     | Error    | CM        | File close op fail<br>File close operation failed  |
| 822E     | Error    | CM        | Attempt close non-open file<br>Attempt made to close a file that was not opened                |
| 822F     | Error    | CM        | Invalid default config<br>Invalid default configuration  |
| 8230     | Error    | CM        | RF back not installd<br>RF back is not installed   |
| 8231     | Error    | CM        | RF driver not installd<br>RF protocol handler is not installed                                 |
| 8232     | Error    | CM        | Path (IMPATH) not found<br>Path specified by IMPATH is not found                               |
| 8233     | Error    | CM        | Bld BIOS val out of range<br>BIOS returned an invalid value during build                       |
| 8234     | Error    | CM        | Config Item not allowed by Prot<br>Configuration item is not allowed for the selected protocol |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 8235     | Error    | CM        | Config Item value out of range<br>Configuration item value is out of range for the selected protocol |
| 8236     | Error    | CM        | Invalid 4th param value<br>Invalid fourth parameter value  |
| 8237     | Error    | CM        | Invalid 5th param value<br>Invalid fifth parameter value   |
| 8238     | Error    | CM        | Invalid 6th param value<br>Invalid sixth parameter value   |
| 8239     | Error    | CM        | Can't open JANUS.ERR<br>Unable to open JANUS.ERR file  |
| 823A     | Error    | CM        | Radio.cfg has invalid checksum<br>File checksum is invalid   |
| 823B     | Error    | CM        | Invalid RF freq in RF config<br>Invalid RF frequency specified                                       |
| 823C     | Error    | CM        | Invalid RF channel in RF config<br>Invalid channel specified   |
| 823D     | Error    | CM        | CM_ENCODED_RF_DATA_S != CM_NUM_RF_CHANNELS<br>Structure mismatch                                     |
| 823E     | Error    | CM        | Allowed RF channels after unallowed channel<br>Specified RF channel is not allowed                   |
| 823F     | Error    | CM        | Ping cmd not allowed here<br>Ping command not allowed here   |
| 8240     | Error    | CM        | Ping cmd not xmitted, prot busy<br>Ping command not transmitted (protocol busy)                      |
| 8241     | Error    | CM        | Missing end of config cmd<br>Missing end of configuration command                                    |
| 8242     | Error    | CM        | RF freq doesn't match RF back type<br>RF frequency does not match the RF back                        |
| 8243     | Error    | CM        | Can't read RF back config data<br>Unable to read configuration data from the RF back                 |
| 8244     | Error    | CM        | Unallowed video display mode<br>Video display mode is not allowed                                    |
| 8245     | Error    | CM        | Cmd source not allowed<br>Command source is not allowed  |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 8246     | Error    | CM        | Invalid 7th param value<br>Invalid seventh parameter value               |
| 8300     | Error    | SC        | Scanner load err<br>Scanner load error                                   |
| 8301     | Error    | SC        | Insufficient timers<br>Not enough timers for the scanner to initialize   |
| 8302     | Error    | SC        | Insufficient memory<br>Insufficient memory for the scanner to initialize |
| 8303     | Error    | SC        | IPM connect failed<br>Scanner not connected to power management          |
| 8304     | Error    | SC        | Invalid Laser Timeout<br>Invalid laser timeout configuration             |
| 8305     | Error    | SC        | Counts obj integrity failed<br>Count object integrity check failed       |
| 8306     | Error    | SC        | Scanner vector table corrupt   |
| 8402     | Error    | DC        | Autodiscrim table full<br>Autodiscrimination table full                  |
| 8403     | Error    | DC        | Insufficient resources for decode  |
| 8404     | Error    | DC        | Decode init failure<br>Decode initialization failure due to scanner      |
| 8405     | Error    | DC        | No scanner<br>Decode initialization failure - no scanner present         |
| 8406     | Error    | DC        | Invalid decodes cmd<br>Invalid decodes command                           |
| 8407     | Error    | DC        | Symbology out of range<br>Invalid symbology specified                    |
| 840D     | Error    | DC        | Can't decode scan<br>Unable to decode scan                               |
| 840E     | Error    | DC        | Missing start/stop<br>Missing start/stop character                       |
| 840F     | Error    | DC        | Too few counts to decode   |
| 8410     | Error    | DC        | Invalid char<br>Invalid character found                                  |
| 8411     | Error    | DC        | Invalid acceleration   |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 8412     | Error    | DC        | Insufficient chars for valid label<br>Insufficient characters for valid label                                  |
| 8413     | Error    | DC        | Invalid check digit  |
| 8414     | Error    | DC        | Output string too short  |
| 8415     | Error    | DC        | No leading margin  |
| 8416     | Error    | DC        | Invalid start/stop   |
| 8417     | Error    | DC        | Attempted decode past end of buffer<br>Attempted decode past end of buffer (not enough counts for whole label) |
| 8418     | Error    | DC        | No trailing margin   |
| 8419     | Error    | DC        | Invalid UPC supplemental   |
| 841A     | Error    | DC        | Invalid parity   |
| 841B     | Error    | DC        | Guard char missing<br>Guard character missing  |
| 841C     | Error    | DC        | Invalid row number   |
| 841D     | Error    | DC        | Unable to scale counts   |
| 841E     | Error    | DC        | Invalid 2 of 5 label   |
| 841F     | Error    | DC        | Invalid 2 of 5 length  |
| 8420     | Error    | DC        | 2 of 5 label length exceeds maximum  |
| 8423     | Error    | DC        | No valid label region found  |
| 8424     | Error    | DC        | Ink spread exceeded threshold  |
| 8425     | Error    | DC        | Denominator of expression zero<br>Denominator of an expression is zero (divide by zero attempted)              |
| 8426     | Error    | DC        | ASCII conversion failed<br>Conversion to ASCII of full label failed  |
| 8501     | Error    | RW        | Input request err<br>Input request error   |
| 8504     | Error    | RW        | Illegal RW mode<br>Illegal reader commands parsed  |
| 8507     | Error    | RW        | Rdr cmd parsing err<br>Reader commands parsing error   |



---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description   |
|----------|----------|-----------|--|
| 8508     | Error    | RW        | Invalid config<br>Invalid configuration  |
| 850F     | Error    | RW        | Error in rdr cmd edit<br>Error in reader command edit  |
| 8511     | Error    | RW        | Unable to allocate memory for input  |
| 8512     | Error    | RW        | Prot handler not linked<br>Protocol handler not linked   |
| 8514     | Error    | RW        | Rdr cmd parsing err on exit accum<br>Reader command parsing error on exit accumulation   |
| 8515     | Error    | RW        | Application break detected   |
| 8516     | Error    | RW        | Invalid Rdr Wedge request<br>Invalid Reader Wedge request  |
| 851B     | Error    | RW        | Rdr cmd erroneously parsed<br>A reader command was incorrectly parsed when Enter was parsed  |
| 851F     | Error    | RW        | Label not accepted: App not requesting input<br>Label not accepted because the scan-ahead is not enabled and the application is not at an input statement. |
| 8520     | Error    | RW        | Link failed, no buffers<br>Reader Wedge link failed  |
| 8522     | Error    | RW        | Invalid port value for input request<br>Invalid port specified in input request  |
| 8523     | Error    | RW        | Xmit buffer busy or Comm Utility err returned<br>Communications error  |
| 8524     | Error    | RW        | Exit Accum with Comms Error<br>Communications error from an exit accumulation command  |
| 8526     | Error    | RW        | Invalid option in RW_DO<br>Invalid port specified in input request   |
| 8527     | Error    | RW        | No label symbology, no label input yet<br>No symbology code available  |
| 8528     | Error    | RW        | Bad parameter  |
| 8600     | Error    | CU        | Invalid config<br>Invalid configuration  |
| 8601     | Error    | CU        | Buffer length 0 error  |
| 8602     | Error    | CU        | Comm port in use   |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 8603     | Error    | CU        | Protocol error  |
| 8604     | Error    | CU        | Comm port error   |
| 8605     | Error    | CU        | Comm port busy  |
| 8606     | Error    | CU        | Service not supported<br>Communications request is not supported  |
| 8607     | Error    | CU        | Prot handler already loaded<br>Protocol handler already loaded  |
| 8608     | Error    | CU        | Prot buffer error<br>Protocol buffer error  |
| 8609     | Error    | CU        | Unknown service request   |
| 860A     | Error    | CU        | No data available   |
| 860B     | Error    | CU        | ComUtil not loaded<br>Communications utility is not loaded  |
| 860C     | Error    | CU        | Resume/Suspend failure  |
| 860D     | Error    | CU        | INT 14 already in use<br>Communications utility INT 14 is already in use  |
| 860E     | Error    | CU        | Incompatible rev PH or ComUtil<br>Incompatible revision between the protocol handler and the communications utility |
| 860F     | Error    | CU        | Invalid EOF char  |
| 8610     | Error    | CU        | Buffer must be > 256 bytes  |
| 8611     | Error    | CU        | Prot handler not active<br>Protocol handler is not active   |
| 8612     | Error    | CU        | Buff size too big   |
| 8613     | Error    | CU        | Re-entrant request for service  |
| 8614     | Error    | CU        | H/W I/O error<br>Hardware I/O error   |
| 86F0     | Error    | CU        | Non-supported Comm service<br>Non-supported communications service  |
| 8821     | Error    | PM        | Cannot change state   |
| 8822     | Error    | PM        | State mgr invalid cmd<br>Invalid state manager command  |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 8842     | Error    | PM        | IPM interface invalid cmd<br>Invalid IPM interface command                      |
| 8843     | Error    | PM        | Parameter out of range  |
| 8844     | Error    | PM        | Semaphore max value exceeded<br>Semaphore maximum value exceeded                |
| 8A00     | Error    | TM        | Invalid timer func cod<br>Invalid timer function code                           |
| 8A01     | Error    | TM        | No free timers available  |
| 8A02     | Error    | TM        | Illegal timer mode specified  |
| 8A03     | Error    | TM        | Timer not allocated   |
| 8A04     | Error    | TM        | Timer currently active  |
| 8A05     | Error    | TM        | Invalid timer delay specified   |
| 8A06     | Error    | TM        | Invalid timer id specified  |
| 8A07     | Error    | TM        | Timer Resume/Suspend failure  |
| 8A08     | Error    | TM        | Cannot process user request<br>Timer utility cannot safely process user request |
| 8B00     | Error    | BP        | Pitch out of range  |
| 8B01     | Error    | BP        | Duration out of range   |
| 8B02     | Error    | BP        | Vol out of range<br>Volume out of range   |
| 8B03     | Error    | BP        | Not seq or preem beep<br>Not a sequential or preemptive beep                    |
| 8B04     | Error    | BP        | Invalid battery flag  |
| 8B05     | Error    | BP        | No preem timer available<br>No preemptive timer available                       |
| 8B06     | Error    | BP        | No seq timer available<br>No sequential timer available                         |
| 8B07     | Error    | BP        | Sequence empty  |
| 8B08     | Error    | BP        | Beep sequence not started   |
| 8B09     | Error    | BP        | Error init beep list<br>Error initializing beep list                            |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                     |
|----------|----------|-----------|--|
| 8B0A     | Error    | BP        | Beep avail list empty<br>Beep available list empty |
| 8B0B     | Error    | BP        | Bad beep mgr reques<br>Bad beep manager request    |
| 8B0C     | Error    | BP        | Beep sequence full                                 |
| 8B0D     | Error    | BP        | Beep in suspend state<br>Beeper in suspend state   |
| 8B0E     | Error    | BP        | Beeper Resume/Suspend failure                      |
| 8E00     | Error    | IM        | Substring not found                                |
| 8E01     | Error    | IM        | Extract string empty                               |
| 8E02     | Error    | IM        | Extract string too long                            |
| 8E03     | Error    | IM        | Append string overflow                             |
| 8E04     | Error    | IM        | Search string not found                            |
| 8E05     | Error    | IM        | Search string empty                                |
| 8E06     | Error    | IM        | Search string too long                             |
| 8E07     | Error    | IM        | String copy too long                               |
| 8E08     | Error    | IM        | Invalid parameter                                  |
| 8E09     | Error    | IM        | Hex conversion length error                        |
| 8E0A     | Error    | IM        | Hex conversion overflow                            |
| 8E0B     | Error    | IM        | Invalid binary to ASCII radix                      |
| 8E0C     | Error    | IM        | Binary to ASCII field too small                    |
| 8F00     | Error    | LG        | Event queue empty                                  |
| 8F01     | Error    | LG        | Prohibited area disable                            |
| 8F02     | Error    | LG        | Reader service disable                             |
| 8F03     | Error    | LG        | Configuration management disable                   |
| 8F04     | Error    | LG        | Scanner disable                                    |
| 8F05     | Error    | LG        | Decodes disable                                    |
| 8F06     | Error    | LG        | Reader Wedge disable                               |
| 8F07     | Error    | LG        | Communications utility disable                     |
| 8F08     | Error    | LG        | Protocol handler disable                           |
| 8F09     | Error    | LG        | Power management disable                           |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 8F0A     | Error    | LG        | BIOS disable  |
| 8F0B     | Error    | LG        | Timer disable   |
| 8F0C     | Error    | LG        | Beeper disable  |
| 8F0D     | Error    | LG        | IRL desktop disable   |
| 8F0E     | Error    | LG        | Prompting configuration disable   |
| 8F0F     | Error    | LG        | Intermec library disabled   |
| 8F10     | Error    | LG        | Event logger disable  |
| 8F11     | Error    | LG        | Keyboard disable  |
| 8F12     | Error    | LG        | System configuration disable  |
| 8F13     | Error    | LG        | Keypad disable  |
| 8F14     | Error    | LG        | Display disable   |
| 8F15     | Error    | LG        | Communications manager disable  |
| 8F16     | Error    | LG        | Workbench disable   |
| 8F17     | Error    | LG        | Severity success disable  |
| 8F18     | Error    | LG        | Severity warning disable  |
| 8F19     | Error    | LG        | Severity error disable  |
| 8F1A     | Error    | LG        | Severity fatal disable  |
| 8F1B     | Error    | LG        | Wrong subsystem ID entered  |
| 8F1C     | Error    | LG        | Wrong severity ID entered   |
| 9002     | Error    | KB        | Can't disable not empty buffer<br>Cannot disable because buffer is not empty                |
| 9003     | Error    | KB        | Keypad buffer full<br>Keyboard buffer is full, entire string rejected                       |
| 9004     | Error    | KB        | Expanded buffer not installed<br>Expanded keyboard buffer not installed                     |
| 9005     | Error    | KB        | Invalid mode value was passed   |
| 9006     | Error    | KB        | Exp buffer flush not install<br>Expanded keyboard buffer flush failed                       |
| 9007     | Error    | KB        | Undefined message   |
| 9008     | Error    | KB        | 16.B3 err:Source str > dest bufr<br>Source string exceeds source or destination buffer size |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description  |
|----------|----------|-----------|---|
| 9009     | Error    | KB        | 16.B3 err:Unknown str descriptor<br>String descriptor type is unknown       |
| 900C     | Error    | KB        | Invalid option requested from int 16 B4xxh                                  |
| 9100     | Error    | SS        | Invalid service number  |
| 9101     | Error    | SS        | ASIC bit number out of range  |
| 9102     | Error    | SS        | Unknown ASIC I/O address  |
| 9103     | Error    | SS        | Undefined message code  |
| 9104     | Error    | SS        | Invalid COM Port id<br>Invalid communications port ID                       |
| 9105     | Error    | SS        | Invalid Args<br>Invalid Argument  |
| 9200     | Error    | KP        | Timeout mid. transaction<br>Timeout occurred in the middle of a transaction |
| 9201     | Error    | KP        | Timeout 1st transaction<br>Timeout occurred on the first transaction        |
| 9202     | Error    | KP        | Keypad busy   |
| 9203     | Error    | KP        | Forced transaction abort  |
| 9204     | Error    | KP        | Failed to process command   |
| 9205     | Error    | KP        | Invalid func number<br>Invalid function number                              |
| 9206     | Error    | KP        | Invalid keypad comms status<br>Invalid keypad communications status         |
| 9207     | Error    | KP        | Passed in wrong parameter   |
| 9208     | Error    | KP        | BIOS returned invalid value   |
| 9300     | Error    | DP        | Abs value out range<br>Absolute value out range                             |
| 9301     | Error    | DP        | Invalid display size mode   |
| 9302     | Error    | DP        | Display function undefined  |
| 9303     | Error    | DP        | Invalid backlight timeout value   |
| 9304     | Error    | DP        | Display BIOS returned an invalid status                                     |
| 9305     | Error    | DP        | Invalid viewport mode   |
| 9306     | Error    | DP        | Invalid scroll mode   |

---

*Status Codes and Error Messages Listed in Numerical Order (continued)*

| Hex Code | Severity | Subsystem | Reader Message and Description                       |
|----------|----------|-----------|--|
| 9307     | Error    | DP        | Invalid video mode                                   |
| 9308     | Error    | DP        | Invalid size mode                                    |
| 9309     | Error    | DP        | Invalid height mode<br>Invalid character height mode |
| 9A03     | Error    | EX        | Transmit fail  |
| 9A04     | Error    | EX        | Receive timeout                                      |
| 9A05     | Error    | EX        | Packet header error                                  |
| 9A06     | Error    | EX        | Transaction ID missing                               |
| 9A08     | Error    | EX        | Standby file missing                                 |
| 9A09     | Error    | EX        | Standby file I/O error                               |
| 9A40     | Error    | EX        | Buffer overflow<br>Host response buffer is too small |
| 9A41     | Error    | EX        | Buffer overflow and upload standby error             |

## ***Status Codes Listed by Subsystem***

---

The status codes in the following tables are organized by subsystems. To find a particular status code, identify the subsystem by looking at bits 8 through 13 and refer to that section:

| Code | Abbrev. | Name                     |
|------|---------|--------------------------|
| 0100 | RS      | Reader Services          |
| 0200 | CM      | Configuration Management |
| 0300 | SC      | Scanner                  |
| 0400 | DC      | Decodes                  |
| 0500 | RW      | Reader Wedge             |
| 0600 | CU      | Communications           |
| 0800 | PM      | Power Management         |
| 0A00 | TM      | Timer                    |
| 0B00 | BP      | Beep                     |
| 0E00 | IM      | Intermec Library         |
| 0F00 | LG      | Event Logger             |
| 1000 | KB      | Keyboard Buffer          |
| 1100 | SS      | System Configuration     |
| 1200 | KP      | Keypad Services          |
| 1300 | DP      | Display                  |
| 1A00 | EX      | DCM Support              |





---

## ***Subsystem 0100 RS (Reader Services)***

| Hex Code | Message                                       |
|----------|---|
| 0100     | Reader service successful                     |
| 0103     | Reader services resume successful             |
| 8100     | Invalid function Hex code received            |
| 8101     | Reader services is not installed              |
| 8102     | Reader services resume failed                 |
| 8103     | Reader services or application is out of date |
| 8104     | Reader Wedge TSR is not installed             |

---

## ***Subsystem 0200 CM (Configuration Management)***

| Hex Code | Message  |
|----------|--|
| 0200     | Request successful   |
| 0201     | End of record encountered                                  |
| 0202     | End of file encountered                                    |
| 4200     | Not all configuration items copied                         |
| 4201     | Reader command terminated configuration command string     |
| 4292     | Client should not be notified                              |
| 8200     | Invalid object   |
| 8201     | Invalid subfunction  |
| 8202     | Invalid parameter length                                   |
| 8203     | Invalid parameter value                                    |
| 8204     | Invalid first parameter                                    |
| 8205     | Invalid Code 39 configuration (HIBC and no check digit)    |
| 8206     | Invalid second parameter                                   |
| 8207     | Invalid Code 39 configuration (HIBC and full ASCII)        |
| 8208     | Invalid Code 39 configuration (HIBC and mixed full ASCII)  |
| 8209     | Invalid third parameter                                    |
| 820A     | Invalid Codabar configuration (ABC and discard start/stop) |
| 820B     | Protocol not loaded  |
| 820C     | Invalid port or protocol specified                         |
| 820D     | No ending quote found                                      |
| 820E     | No double quote (might be missing an opening quote)        |
| 820F     | Invalid parser state                                       |
| 8210     | Invalid configuration command                              |
| 8211     | Client deemed configuration command invalid                |
| 8212     | Invalid beep duration                                      |
| 8213     | Invalid beep frequency                                     |
| 8214     | Invalid beep volume  |
| 8215     | Beep volume already off                                    |
| 8216     | Beep volume already extra loud                             |
| 8217     | Invalid beep specifier (must be "L" or "H")                |

---

*Subsystem 0200 CM (Configuration Management) (continued)*

| Hex Code | Message   |
|----------|---|
| 8218     | Inappropriate configuration for the current protocol                    |
| 8219     | BIOS rejected the set configuration command                             |
| 821A     | Configuration command string object is too small                        |
| 821B     | Configuration ID is invalid   |
| 821C     | Invalid build parameter   |
| 821D     | No build function   |
| 821E     | No more build entries   |
| 821F     | No more build entries in wedge lookup table                             |
| 8220     | No more build entries in wedge lookup table for "build next" WM command |
| 8221     | No entries found in the LUM key table                                   |
| 8222     | No match in lookup table for specified character                        |
| 8223     | At least one parameter rejected by client (see JANUS.ERR)               |
| 8224     | Configuration item is not found   |
| 8225     | File open error   |
| 8226     | File write error  |
| 8227     | File read error   |
| 8228     | Record too large to be read   |
| 8229     | Invalid hex character found in the escape sequence                      |
| 822A     | Invalid escape sequence   |
| 822B     | Read attempted on a file that was not opened                            |
| 822C     | Write attempted on a file that was not opened                           |
| 822D     | File close operation failed   |
| 822E     | Attempt made to close a file that is not open                           |
| 822F     | Invalid default configuration   |
| 8230     | RF back is not installed  |
| 8231     | RF protocol handler is not installed                                    |
| 8232     | Path specified by IMPATH is not found                                   |
| 8233     | BIOS returned an invalid value during build                             |
| 8234     | Configuration item is not allowed for the selected protocol             |

---

*Subsystem 0200 CM (Configuration Management) (continued)*

| Hex Code | Message  |
|----------|--|
| 8235     | Configuration item value is out of range for the selected protocol |
| 8236     | Invalid fourth parameter value                                     |
| 8237     | Invalid fifth parameter value                                      |
| 8238     | Invalid sixth parameter value                                      |
| 8239     | Unable to open JANUS.ERR   |
| 823A     | File checksum invalid  |
| 823B     | Invalid RF frequency   |
| 823C     | Invalid channel is specified                                       |
| 823D     | Structure mismatch   |
| 823E     | Specified RF channel is not allowed                                |
| 823F     | Ping command not allowed here                                      |
| 8240     | Ping command not transmitted (protocol busy)                       |
| 8241     | Missing end of configuration command                               |
| 8242     | RF frequency does not match the RF back type                       |
| 8243     | Unable to read configuration data from the RF back                 |
| 8244     | Video display mode is not allowed                                  |
| 8245     | Command source is not allowed                                      |



---

## ***Subsystem 0300 SC (Scanner)***

| Hex Code | Message   |
|----------|---|
| 0300     | Scan successful                                   |
| 8300     | Scanner load error                                |
| 8301     | Not enough timers for the scanner to initialize   |
| 8302     | Insufficient memory for the scanner to initialize |
| 8303     | Scanner cannot connect to power management        |
| 8304     | Invalid laser timeout configuration               |
| 8305     | Counts object integrity check failed              |
| 8306     | Scanner vector table is corrupt                   |

---

## ***Subsystem 0400 DC (Decodes)***

| Hex Code | Message   |
|----------|---|
| 0400     | Successful command  |
| 0401     | Symbology is already enabled  |
| 0402     | Symbology is not enabled  |
| 040A     | Successful decode   |
| 040B     | Intermediate row reread   |
| 040C     | Intermediate row decoded  |
| 0421     | Default command symbology   |
| 0422     | Mixed ASCII format  |
| 8402     | Autodiscrimination table full   |
| 8403     | Insufficient resources for decode   |
| 8404     | Decode initialization failure due to scanner                                |
| 8405     | Decode initialization failure—no scanner                                    |
| 8406     | Invalid decodes command   |
| 8407     | Invalid symbology specified   |
| 840D     | Unable to decode scan   |
| 840E     | Missing start/stop character  |
| 840F     | Too few counts to decode  |
| 8410     | Invalid character found   |
| 8411     | Invalid acceleration  |
| 8412     | Insufficient characters for valid label                                     |
| 8413     | Invalid check digit   |
| 8414     | Output string too short   |
| 8415     | No leading margin   |
| 8416     | Invalid start/stop  |
| 8417     | Attempted decode past end of buffer (not enough counts for the whole label) |
| 8418     | No trailing margin  |
| 8419     | Invalid UPC supplemental  |
| 841A     | Invalid parity  |
| 841B     | Guard character missing   |



---

*Subsystem 0400 DC (Decodes) (continued)*

| Hex Code | Message                                  |
|----------|--|
| 841C     | Invalid row number                       |
| 841D     | Unable to scale counts                   |
| 841E     | Invalid 2 of 5 label                     |
| 841F     | Invalid 2 of 5 length                    |
| 8420     | 2 of 5 label length exceeds maximum      |
| 8423     | No valid label region found              |
| 8424     | Ink spread exceeded threshold            |
| 8425     | Denominator of an expression is zero     |
| 8426     | Conversion to ASCII of full label failed |

---

## ***Subsystem 0500 RW (Reader Wedge)***

| Hex Code | Message  |
|----------|--|
| 0500     | Reader Wedge successful  |
| 0505     | No reader commands parsed  |
| 0506     | Valid reader commands parsed                                       |
| 0509     | Accumulating reader command  |
| 050A     | Reader command override  |
| 050B     | Reader command enter accumulation                                  |
| 050C     | Reader command exit accumulation                                   |
| 050D     | Accumulating multiple-read labels                                  |
| 0510     | An Enter reader command was parsed                                 |
| 0513     | Protected field has been parsed                                    |
| 0517     | Keycode label has been parsed                                      |
| 0518     | An isolated Enter command was parsed                               |
| 0519     | A successful reader command parse on exit from accumulation        |
| 051A     | A reader command has been successfully parsed when Enter is parsed |
| 051C     | An Enter Accumulate has been parsed when accumulating              |
| 051D     | A label terminating a multiple-read sequence has been scanned      |
| 051E     | A label beginning a multiple-read sequence has been scanned        |
| 0521     | No communications status to report                                 |
| 0525     | Reader commands forwarded to the application have been parsed      |
| 4502     | Input timeout  |
| 4503     | No input data  |
| 450E     | The application should be notified                                 |
| 4529     | Input from the source is other than the ones requested             |
| 452A     | RWTSR is already loaded  |
| 452B     | Prepare for reboot command received                                |
| 452C     | Cancel reboot command received                                     |
| 8501     | Input request error  |
| 8504     | Illegal reader commands parsed                                     |
| 8507     | Reader commands parsing error                                      |
| 8508     | Invalid configuration error  |



---

*Subsystem 0500 RW (Reader Wedge) (continued)*

| Hex Code | Message   |
|----------|---|
| 850F     | Error in reader command edit  |
| 8511     | Unable to allocate memory for input   |
| 8512     | Protocol handler is not linked  |
| 8514     | Reader command parse error on exit accumulation   |
| 8515     | Application break detected  |
| 8516     | Invalid Reader Wedge request  |
| 851B     | A reader command has been erroneously parsed when Enter is parsed                                     |
| 851F     | Label not accepted because the scan-ahead is not enabled and application is not at an input statement |
| 8520     | Reader Wedge link failed  |
| 8522     | Invalid port specified in input request   |
| 8523     | Communications error  |
| 8524     | Communications error from an exit accumulation command  |
| 8526     | Library coding error  |
| 8527     | No symbology code available   |
| 8528     | Bad parameter   |

---

## ***Subsystem 0600 CU (Communications)***

| Hex Code | Message   |
|----------|---|
| 0600     | Communications operation success  |
| 0601     | Communications buffer done  |
| 4600     | Buffer canceled   |
| 4601     | Communications timeout  |
| 4602     | Communications had no client to cancel  |
| 4603     | No protocol handler to configure  |
| 4604     | Protocol handler is not yet loaded  |
| 4605     | Protocol handler already receiving  |
| 4606     | Protocol handler not active for link request                                      |
| 8600     | Invalid configuration   |
| 8601     | Buffer length zero error  |
| 8602     | Communications port is in use   |
| 8603     | Protocol error  |
| 8604     | Communications port error   |
| 8605     | Communications port is busy   |
| 8606     | Communications request is not supported   |
| 8607     | Protocol handler already loaded   |
| 8608     | Protocol buffer error   |
| 8609     | Unknown service request   |
| 860A     | No data available   |
| 860B     | Communications utility is not loaded  |
| 860C     | Resume/suspend failure  |
| 860D     | Communications utility INT 14 is already in use                                   |
| 860E     | Incompatible revision between the protocol handler and the communications utility |
| 860F     | Invalid end of file character   |
| 8610     | Buffer must be 256 bytes or greater   |
| 8611     | Protocol handler not active   |
| 8612     | Buffer size is too big  |



---

*Subsystem 0600 CU (Communications) (continued)*

| Hex Code | Message                            |
|----------|------------------------------------|
| 8613     | Reentrant request for service      |
| 8614     | Hardware I/O error                 |
| 86F0     | Unsupported communications service |

---

## ***Subsystem 0800 PM (Power Management)***

| Hex Code | Message                       |
|----------|-------------------------------|
| 0800     | Power management success      |
| 8821     | Cannot change state           |
| 8822     | Invalid state manager command |
| 8842     | Invalid IPM interface command |
| 8843     | Parameter out of range        |
| 8844     | Semaphore maximum exceeded    |

---

## ***Subsystem 0A00 TM (Timer)***

| Hex Code | Message  |
|----------|--|
| 0A00     | Timer operation success                          |
| 4A00     | Timer not currently active                       |
| 8A00     | Invalid timer function code                      |
| 8A01     | No free timers available                         |
| 8A02     | Illegal timer mode specified                     |
| 8A03     | Timer not allocated                              |
| 8A04     | Timer is currently active                        |
| 8A05     | Invalid timer delay specified                    |
| 8A06     | Invalid timer ID specified                       |
| 8A07     | Timer resume/suspend failure                     |
| 8A08     | Timer utility cannot safely process user request |

## ***Subsystem 0B00 BP (Beep)***

| Hex Code | Message                               |
|----------|---------------------------------------|
| 0B00     | Beeper call success                   |
| 8B00     | Pitch out of range                    |
| 8B01     | Duration out of range                 |
| 8B02     | Volume out of range                   |
| 8B03     | Not a sequential or a preemptive beep |
| 8B04     | Invalid battery flag                  |
| 8B05     | No preemptive timer available         |
| 8B06     | No sequential timer available         |
| 8B07     | Sequence empty                        |
| 8B08     | Beep sequence not started             |
| 8B09     | Error initializing beep list          |
| 8B0A     | Beep available list empty             |
| 8B0B     | Bad beep manager request              |
| 8B0C     | Beep sequence full                    |
| 8B0D     | Beeper in suspend state               |
| 8B0E     | Beeper resume/suspend failure         |

---

## ***Subsystem 0E00 IM (Intermec Library)***

| Hex Code | Message                         |
|----------|---------------------------------|
| 0E00     | String extract complete         |
| 0E01     | String append complete          |
| 0E02     | String search found             |
| 0E03     | String copy complete            |
| 0E04     | Successful operation            |
| 8E00     | Substring not found             |
| 8E01     | String extract empty            |
| 8E02     | String extract too long         |
| 8E03     | String append overflow          |
| 8E04     | String search not found         |
| 8E05     | String search empty             |
| 8E06     | String search too long          |
| 8E07     | String copy too long            |
| 8E08     | Invalid parameter               |
| 8E09     | Hex conversion length error     |
| 8E0A     | Hex conversion overflow         |
| 8E0B     | Invalid binary to ASCII radix   |
| 8E0C     | Binary to ASCII field too small |

---

## ***Subsystem 0F00 LG (Event Logger)***

| Hex Code | Message                          |
|----------|----------------------------------|
| 0F00     | Successful logger operation      |
| 8F00     | Event queue empty                |
| 8F01     | Prohibited area disable          |
| 8F02     | Reader service disable           |
| 8F03     | Configuration management disable |
| 8F04     | Scanner disable                  |
| 8F05     | Decodes disable                  |
| 8F06     | Reader Wedge disable             |
| 8F07     | Communications utility disable   |
| 8F08     | Protocol handler disable         |
| 8F09     | Power management disable         |
| 8F0A     | BIOS disable                     |
| 8F0B     | Timer disable                    |
| 8F0C     | Beeper disable                   |
| 8F0D     | IRL desktop disable              |
| 8F0E     | Prompting configuration disable  |
| 8F0F     | Intermec library disabled        |
| 8F10     | Event logger disable             |
| 8F11     | Keyboard disable                 |
| 8F12     | System configuration disable     |
| 8F13     | Keypad disable                   |
| 8F14     | Display disable                  |
| 8F15     | Communications manager disable   |
| 8F16     | Workbench disable                |
| 8F17     | Severity success disable         |
| 8F18     | Severity warning disable         |
| 8F19     | Severity error disable           |
| 8F1A     | Severity fatal disable           |
| 8F1B     | Wrong subsystem ID entered       |
| 8F1C     | Wrong severity ID entered        |



---

## ***Subsystem 1000 KB (Keyboard Buffer)***

| Hex Code | Message   |
|----------|---|
| 1000     | Expanded keyboard buffer success                        |
| 100A     | Expanded buffer enabled                                 |
| 100B     | Expanded buffer disabled                                |
| 5001     | Expanded keyboard buffer installed or disabled          |
| 9002     | Cannot disable because buffer is not empty              |
| 9003     | Keyboard buffer is full (entire string rejected)        |
| 9004     | Expanded keyboard buffer not installed                  |
| 9005     | Invalid mode value was passed                           |
| 9006     | Expanded keyboard buffer flush not successful           |
| 9007     | Undefined message                                       |
| 9008     | Source string exceeds source or destination buffer size |
| 9009     | String descriptor type is unknown                       |
| 900C     | Invalid option requested from INT 16 B4xxh              |

---

## ***Subsystem 1100 SS (System Configuration)***

| Hex Code | Message                         |
|----------|---------------------------------|
| 1100     | System configuration successful |
| 9100     | Invalid service number          |
| 9101     | ASIC bit number is out of range |
| 9102     | Unknown ASIC I/O address        |
| 9103     | Undefined message code          |
| 9104     | Invalid communications port ID  |
| 9105     | Invalid argument                |

---

## ***Subsystem 1200 KP (Keypad Services)***

| Hex Code | Message   |
|----------|---|
| 1200     | Successful keypad operation                     |
| 5201     | Backdoor communications failure                 |
| 9200     | Timeout occurred in the middle of a transaction |
| 9201     | Timeout occurred on the first transaction       |
| 9202     | Keypad busy                                     |
| 9203     | Forced transaction abort                        |
| 9204     | Failed to process a command                     |
| 9205     | Invalid function number                         |
| 9206     | Invalid keypad communications status            |
| 9207     | Wrong parameter passed in                       |
| 9208     | BIOS returned an invalid value                  |

---

## ***Subsystem 1300 DP (Display)***

| Hex Code | Message                                 |
|----------|---|
| 1300     | Successful display operation            |
| 9300     | Absolute value out of range             |
| 9301     | Invalid display size mode               |
| 9302     | Display function undefined              |
| 9303     | Invalid backlight timeout value         |
| 9304     | Display BIOS returned an invalid status |
| 9305     | Invalid viewport mode                   |
| 9306     | Invalid scroll mode                     |
| 9307     | Invalid video mode                      |
| 9308     | Invalid size mode                       |
| 9309     | Invalid character height mode           |

---

## ***Subsystem 1A00 EX (DCM Support)***

| Hex Code | Message                          |
|----------|----------------------------------|
| 1A00     | Execution success                |
| 1A01     | ACK received                     |
| 1A10     | Data received                    |
| 5A02     | NAK received                     |
| 5A07     | No more log records              |
| 5A11     | Received data truncated          |
| 5A12     | Fields overflow                  |
| 5A20     | Record logged                    |
| 5A21     | Logged but upload error          |
| 9A03     | Transmit fails                   |
| 9A04     | Receive timeout                  |
| 9A05     | Packet header error              |
| 9A06     | Transaction ID is missing        |
| 9A08     | Standby file is missing          |
| 9A09     | Standby file I/O error           |
| 9A40     | Buffer overflow                  |
| 9A41     | Buffer overflow and upload error |





## *Sample Interrupt Programs*





*This appendix lists C language programs that demonstrate how to use interrupts.*

## ***Using the Sample Programs***

---

The sample programs in this appendix demonstrate how to use software interrupts in place of the Intermec PSK functions. It is much easier to write programs that use the PSK functions than to write programs that directly call the software interrupts. For more information on using software interrupts, see Chapter 3, "Software Interrupts."

**Note:** *Do not run programs that use **PSK library functions** on your PC. If you attempt to run these programs, you will receive an error message and the program will not run.*



### **Caution**

***Do not run programs that use Intermec-specific interrupt extensions on your PC. If you attempt to run these programs, they will cause your PC to lock up and possibly corrupt your system BIOS.***

### **Conseil**

***N'exécutez pas de programmes utilisant des extensions d'interruption spécifiques à Intermec sur votre PC. Si vous tentez de les exécuter sans le Simulator, ces programmes risquent de verrouiller votre PC et d'altérer le BIOS de votre système.***

*apmif.c*

---

## ***apmif.c***

```
/* apmif.c
 *
 * This program is an APM interface test module. It allows entry of the APM
 * interface registers from the MS-DOS command line, and then it makes an APM call.
 * The results displayed are the register contents returned from the call.
 *
 * Compiler: Borland C++ 3.11
 */

typedef unsigned char uchar;
typedef unsigned int  uint;

#include <stdio.h>
#include <ctype.h>
#include <string.h>

uint tohex(char*);
void get_data(char**);
void call_APM(void);
void print_IV(void);

uint AX_REG, BX_REG, CX_REG, DX_REG, CARRY;

void main(int argc, char **argv){

    AX_REG = 0x5300;           //check for pm enabled
    BX_REG = 0x0;
    CX_REG = 0x0;
    DX_REG = 0x0;
    call_APM();

    if (BX_REG != 0x504D){           //504D = PM, means apm implemented
        printf("APM not supported.\n\n");
        return;
    }

    if ((CX_REG & 0x0008) != 0)      //check for pm disabled
        printf("PM is disabled.\n\n");

    AX_REG = 0x5301;           // connect as apm client
    BX_REG = 0x0;
    CX_REG = 0x0;
    DX_REG = 0x0;
    call_APM();

    if (CARRY != 0){
        printf("APM client already connected.\n\n");
    }
    else{
        printf("Successful connect.\n\n");
    }

    if (argc == 1)                // if no arguments, prompt for them
        printf("Enter AX BX CX...\n\n");

    get_data(argv);
}
```

```

//display register values entered

printf("i AX=%0.4X BX=%0.4X\ni CX=%0.4X DX=%0.4X\n",
       AX_REG,BX_REG,CX_REG,DX_REG);

call_APM();           //do the apm call
/* have to call standby twice to make it work (so it won't skip activity)*/
if ((AX_REG == 0x5307)&&(CX_REG == 0x0001))
    call_APM();

//display the register values returned

printf("o AX=%0.4X BX=%0.4X\no CX=%0.4X DX=%0.4X\n",
       AX_REG,BX_REG,CX_REG,DX_REG);

printf("carry=%0.4X\n\n",CARRY);

if (AX_REG == 0x530B){ //if get pm event and standby, do it
    if ((BX_REG & 0x01) != 0x0){
        AX_REG = 0x5307;
        BX_REG = 0x0001;
        CX_REG = 0x0001;
        call_APM();
        call_APM();
    }
}
}

void call_APM(){ /* the call apm interface routine */
asm{
    push ax
    push bx
    push cx
    push dx
    mov ax,AX_REG
    mov bx,BX_REG
    mov cx,CX_REG
    mov dx,DX_REG
    int 15h
    mov AX_REG,ax
    mov BX_REG,bx
    mov CX_REG,cx
    mov DX_REG,dx
    pop dx
    pop cx
    pop bx
    pop ax
} /* end asm */
asm mov CARRY,0
asm jnc a
asm inc CARRY
a:
}

void get_data (char **dos_arg){ /* get the register values from user entry */
char *regval;
char charbuff[10];

regval = *dos_arg++;
if (*dos_arg == 0) {

```

*apmif.c*

```
        printf("Enter AX value in hex:");
        fflush(stdin);
        regval=charbuff;
        gets (regval);
    }
    else
    regval = *dos_arg++;

    AX_REG = tohex(regval);

    if (*dos_arg == 0) {
        printf("Enter BX value in hex:");
        fflush(stdin);
        regval=charbuff;
        gets (regval);
    }
    else
    regval = *dos_arg++;

    BX_REG = tohex(regval);

    if (*dos_arg == 0) {
        printf("Enter CX value in hex:");
        fflush(stdin);
        regval=charbuff;
        gets (regval);
    }
    else
    regval = *dos_arg++;

    CX_REG = tohex(regval);

    if (*dos_arg == 0) {
        DX_REG = 0;
    }
    else {
        regval = *dos_arg++;
        DX_REG = tohex(regval);
    }
}

uint tohex(char *string){ /* convert ascii characters to hex */
    uint    ctr;
    uint    num;
    uint    value = 0;
    uint    stop;

    stop=strlen(string);
    for (ctr = 0; ctr < stop; ctr++){
        value <<= 4;
        num = string[ctr];
        num -= '0';
        num = (num > 9) ? (num - ('A' - ':')) : num;
        num = (num > 15) ? (num - ('a' - 'A')) : num;
        value += num;
    } /* end for */

    return value;
}
```

**appbreak.cpp**

```

/* appbreak.cpp
 *
 * This program demonstrates application break control using interrupts.
 *
 * The operator presses application break to exit program. The application break sequence
 * is as follows:
 *
 *     Start the Appbreak program:
 *     1/0          turn off Janus
 *     F3+2+left arrow  at the same time
 *     1           by itself
 *     1/0          turn Janus back on
 *
 * Written: Aug. 30, 1993
 * Last Modified: Aug. 30, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "dos.h"
#include "stdio.h"
#include "stdlib.h"
#include "conio.h"
#include "im20lib.h"

#define KEY_Int      0x7e          // keyboard interrupt
#define BREAK_REQ    0xff          // break requested
#define TRANS_OK     0x00          // successful KSCPU transaction
#define VALID_SERVICE 0x00          // valid service call to 0x7e
#define ESC          0x1b          // escape key
#define FOREVER      1            // endless loop control

typedef struct {
    IM_UCHAR  status;              // KSCPU comm status
    IM_UCHAR  request;            // request made or not?
} RESP_BUFF;

RESP_BUFF  rbuff;                // KSCPU response buffer

// Prototypes
IM_UINT  Chk_App_Break(RESP_BUFF *);

void main()
{
    clrscr();
    printf("%s", "\n\rDo appl. break or\n\rpress ESC\n\r");

    while(FOREVER)
    {
        if(VALID_SERVICE == Chk_App_Break(&rbuff))
        {
            if(rbuff.status == TRANS_OK)
            {
                if(rbuff.request == BREAK_REQ)
                {
                    printf("%s", "\n\rAppl. Break detected!\n\r");
                    exit(0);
                }
            }
        }
    }
}

```

*appbreak.cpp*

```
    } // end VALID_SERVICE
    if(kbhit())
        if(getch() == ESC) // just in case
            {
                printf("%s", "\n\rEscape was pressed!\n\r");
                exit(0);
            }
    }

// Check for application break request
IM_UINT Chk_App_Break(RESP_BUFF *rbuff)
{
    _ES = FP_SEG((RESP_BUFF *) rbuff); // far pointer to response buffer
    _BX = FP_OFF((RESP_BUFF *) rbuff); // far pointer to response buffer

    _AH = 0x01; // check app break function

    geninterrupt(KEY_Int);

    return(_AH);
}
```

---

***backlite.cpp***

```
/* backlite.cpp
 *
 * This program demonstrates how to toggle the back light.
 *
 * Written: Aug. 12, 1993
 * Last Modified: Aug. 19, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "dos.h"

#define LCD_Int    0x79           // LCD size mode manager interrupt

void main()
{
    _AH = 0x01;                  // back light function
    _AL = 0x02;                  // toggle back light state

    geninterrupt(LCD_Int);
}
```

*close.cpp*

---

## ***close.cpp***

```
/* close.cpp
 *
 * This program demonstrates how to close COM2 on the 2D JANUS.
 *
 * Written: Feb. 10, 1999
 * Last Modified: Feb. 10, 1999
 * Author: Peter J. Girodat
 * Compiler: Borland C++ 3.1
 */

#include <dos.h>
#include <stdio.h>
#include <stdlib.h>

#define RS_VECTOR          0x7D          /* Interrupt 7DH Reader Services */
#define RS_ASIC_RESET     0x0C          /* Function 0CH ASIC Reset */
#define RS_CLOSE_COM2     0x0D          /* Function 0DH Close COM2 */
#define RS_ALL_SUCESS     0x0100       /* Reader Service sucessful */
#define RS_INVALID_REQUEST 0x8100      /* Invalid function Hex code received */

void main()
{
    _AH = RS_CLOSE_COM2;                // AH = Function 0DH
    _AL = 0;

    geninterrupt(RS_VECTOR);

    if (_AX == RS_ALL_SUCESS)
        printf ("COM2 CLOSED\n");
    else if (_AX == RS_INVALID_REQUEST)
        printf ("JANUS 1D Reader\n");
}
```



---

## ***contrast.cpp***

```
/* contrast.cpp
 *
 * This program demonstrates contrast control using interrupts. It increases the
 * contrast by one step each time the space bar is pressed. It accepts a parameter
 * in the range of 0 - 31 from the command line and sets the contrast to that level.
 *
 * Written: Aug. 24, 1993
 * Last Modified: Aug. 24, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "stdio.h"
#include "string.h"
#include "dos.h"
#include "conio.h"
#include "stdlib.h"
#include "im20lib.h"

// Defines
#define FOREVER 1
#define LCD_Int 0x79 // LCD interrupt
#define LCD_CONTRAST 0 // contrast function
#define ESC 0x1b
#define ZERO '0'
#define PERIOD '.'

// Prototypes
IM_UCHAR Step_Contrast(IM_UCHAR);
IM_UCHAR Set_Contrast(IM_UCHAR);
IM_UCHAR Get_Contrast(void);

void main(int argc, char *argv[])
{
    IM_UCHAR ch, level;

    if(argc == 1)
    {
        clrscr(); // no command line parameters
        printf("%s", "\n\rPress 0 to decrease\n\rperiod to increase\n\rESC to quit");
    }
    else
    {
        Set_Contrast(atoi(argv[1]));
        exit(0);
    }

    // main processing loop, exit loop on ESC key
    while(FOREVER)
    {
        if(kbhit())
        {
            ch = getch();
            switch(ch)
            {
                case ESC:
                    clrscr();
                    exit(0);
            }
        }
    }
}
```

*contrast.cpp*

```
        case ZERO:
            Step_Contrast(--(level = Get_Contrast()));
            break;
        case PERIOD:
            Step_Contrast(++(level = Get_Contrast()));
            break;
    };
} // end main loop
}

// Get the current contrast level
IM_UCHAR Get_Contrast()
{
    _AH = LCD_CONTRAST;
    _AL = 3; // current contrast

    geninterrupt(LCD_Int);

    return(_AL);
}

// Step the contrast one level by call with 0 parameter or set by
// supplying a value
IM_UCHAR Step_Contrast(IM_UCHAR step)
{
    static IM_UCHAR once, level;

    if(!once)
    {
        once = 1;
        level = Get_Contrast(); // allow Get_Contrast() only once
    }

    if(step != 0) level = step; // use step value if provided
    if(level >= 31) level = 0; // keep level within bounds (not below zero -
    // unsigned)

    if(step == 0) level++;

    return(Set_Contrast(level));
}

// Set the contrast to the requested level
IM_UCHAR Set_Contrast(IM_UCHAR level)
{
    _AH = LCD_CONTRAST;
    _AL = 1; // set contrast to value function
    _BL = level;

    geninterrupt(LCD_Int);

    return(_AL);
}
```

**ctlkey.cpp**

```

/* ctlkey.cpp
 *
 * This program demonstrates Ctrl key control by using interrupts to enable/disable
 * the Ctrl key.
 *
 * Written: Sept. 1, 1993
 * Last Modified: Sept. 1, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "dos.h"
#include "stdlib.h"
#include "conio.h"
#include "stdio.h"
#include "im20lib.h"

#define KEYPAD_Int 0x7e           // key pad interrupt
#define KP_CTL 0x08             // keypad ctl key function
#define KP_OFF 0x00             // function is off
#define KP_ON 0x01              // function is on
#define KP_STATUS 0x02          // get status
#define KP_ENABLED 0xff         // function is enabled
#define VALID_SERVICE 0x00      // valid function call
#define TRANS_OK 0x00           // func transaction executed ok

typedef struct {
    IM_UCHAR status;           // KSCPU comm status
    IM_UCHAR kp_status;       // 0xff if function already enabled
    IM_UINT padding;          // work space
} RESP_BUFF;

RESP_BUFF rbuff;

// Prototypes
IM_UINT KP_Func(IM_UCHAR, IM_UCHAR, RESP_BUFF *);

void main()
{
    clrscr();

    if(VALID_SERVICE == KP_Func(KP_CTL, KP_STATUS, &rbuff)) // get current status of click
        if(TRANS_OK == rbuff.status)
            if(rbuff.kp_status == KP_ENABLED) // if it is on...
                {
                    KP_Func(KP_CTL, KP_OFF, &rbuff); // turn it off
                    printf("%s", "\n\rControl Key DISABLED\n\r\n\rPress a key...");
                }
            else
                {
                    KP_Func(KP_CTL, KP_ON, &rbuff); // else, turn it on
                    printf("%s", "\n\rControl key ENABLED\n\r\n\rPress a key...");
                }

    while(!kbhit()); // wait for a keypress
    getch();
    clrscr();
    exit(0);
}

```

*ctlkey.cpp*

```
// Execute requested keypad function
IM_UINT KP_Func(IM_UCHAR func, IM_UCHAR subfunc, RESP_BUFF *resp)
{
    _ES = FP_SEG(resp);
    _BX = FP_OFF(resp);

    _AH = func;                // keypad function
    _AL = subfunc;            // subfunction

    geninterrupt(KEYPAD_Int);

    return(_AH);
}
```

---

## exstat.cpp

```

/* exstat.cpp
 *
 * This program demonstrates JANUS extended protocol status reporting using interrupts.
 * This program also demonstrates program control of the JANUS viewport using interrupts.
 *
 * NOTE: For units with Radio Frequency (RF), this program is known to function properly
 * only with Version 1.24 firmware.
 * Written: July 25, 1994
 *
 * Last Modified: July 25, 1994
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "stdio.h"
#include "string.h"
#include "dos.h"
#include "conio.h"
#include "stdlib.h"
#include "im20lib.h"

// Defines
#define COM_Int 0x14 // Communications interrupt
#define LCD_Int 0x79 // LCD size mode manager interrupt
#define ESC 0x1b // char 27, Escape
#define SPACE ' ' // blank space
#define ZERO '0' // zero == set viewport to origin 0,0
#define TRUE 1
#define FOREVER TRUE
#define VP_ACROSS 5 // number of viewport steps across
#define VP_DOWN 4 // number of viewport steps down
#define VP_STEPSIZE 15 // columns to move viewport right
#define OK 0x600 // ok status
#define ERR_NO_HANDLER 0x8611 // no protocol handler loaded
#define ERR_BAD_VER 0x860e // old firmware - requires 1.24 or later

// Global Variables
IM_UINT vm_mode; // saves original video mode
IM_UINT vm_params; // saves original video parameters
IM_UINT vp = 0; // viewport position
IM_UINT vp_vert = 1; // viewport vertical control
IM_COMM_STATUS_BUFFER_s sb0, sb3; // define buffers to hold status

// Prototypes
IM_UINT Set_Video_Mode(void);
IM_UINT Get_Ext_Status(IM_UINT, IM_COMM_STATUS_BUFFER_s *);
IM_UINT VP_Move(IM_UINT, IM_UINT);
void Display_Status(IM_UINT, IM_COMM_STATUS_BUFFER_s *, IM_UINT);
void Move_V viewport(void);
void err_msg(IM_UINT);

void main()
{
IM_UCHAR ch;
IM_UINT status0, status3;

Set_Video_Mode();

sb0.status_structure_version = STATUS_STRUCT_VERSION;

```

## *exstat.cpp*

```
sb3.status_structure_version = STATUS_STRUCT_VERSION;
status0 = Get_Ext_Status(0, &sb0); // status for port 0
status3 = Get_Ext_Status(3, &sb3); // status for port 3

clrscr();

VP_Move(0, 0);

printf("%s", "\n\rPress the space bar to\n\r");
printf("%s", "move the viewport \n\r or ESC to quit");

ch = 0x00;
while(ch != SPACE && ch != ESC)
    if(kbhit()) ch = getch();

clrscr();

VP_Move(0, 0);

Display_Status(0, &sb0, status0);
printf("%s", "\r\n\n");
Display_Status(3, &sb3, status3);

VP_Move(0, 0);

// Loop for moving the viewport to display the data
while(FOREVER)
{
    ch = getch();

    if(ch == SPACE)
        Move_Viewport();

    if(ch == ZERO) // just handy to have
        VP_Move(0, 0);

    if(ch == ESC)
        break;
}

clrscr();

VP_Move(0, 0);
}

// Display a status buffer on the 80x25 screen
void Display_Status(IM_UINT port, IM_COMM_STATUS_BUFFER_s *sb, IM_UINT status)
{
    static IM_UCHAR *prot[] =
    {
        "User Defined",
        "Pt to Pt",
        "Polling Mode D",
        "Multi Drop",
        "Reserved1",
        "XModem",
        "Reserved2",
        "Dos Protocol",
        "Reserved3",
        "None",
        "No RF Protocol",
        "RF Protocol"
    }
}
```

```

};

if(sb->handler_type != IM_RF_BACK_PH && status == OK) // if not the rf handler
{
    printf("Port: %ld Protocol Handler Ver. %s\n\r", port, sb->handler_ver);
    printf("Baud= %6lu Parity= %1X Stop Bits= %1X Data Bits= %1X\n\r",
        sb->specific.serial.baud_rate, sb->specific.serial.parity,
        sb->specific.serial.stop_bits, sb->specific.serial.data_bits);
    printf("Modem Status= %2X Port Status= %2X Active Protocol= %s\n\r",
        sb->specific.serial.modem_status, sb->specific.serial.port_status,
        prot[sb->specific.serial.active_prot]);
    printf("LRC= %s Interchar Delay= %2X Turnaround Delay= %d\n\r",
        sb->specific.serial.lrc_enabled == 0 ? "No " : "Yes",
        sb->specific.serial.interchar_delay,
        sb->specific.serial.turnaround_delay);
    printf("POL char = %3X SEL char = %2X RES char = %2X\n\r",
        sb->specific.serial.pol_char, sb->specific.serial.sel_char,
        sb->specific.serial.res_char);
    printf("REQ char = %3X AFF char = %2X NEG char = %2X SOM char= %2X\n\r",
        sb->specific.serial.req_char, sb->specific.serial.aff_char,
        sb->specific.serial.neg_char, sb->specific.serial.som_char);
    printf("TXEOM len = %3X TXEOM char1 = %2X TXEOM char2= %2X\n\r",
        sb->specific.serial.txeom_len, sb->specific.serial.txeom_char_1,
        sb->specific.serial.txeom_char_2);
    printf("RXEOM len = %3X RXEOM char1 = %2X RXEOM char2= %2X\n\r",
        sb->specific.serial.rxeom_len, sb->specific.serial.rxeom_char_1,
        sb->specific.serial.rxeom_char_2);
    printf("Flow Cntrl= %3X MultiDrop Addr= %2X MultiDrop Enabled= %s\n\r",
        sb->specific.serial.flow_ctrl, sb->specific.serial.multi_drop_addr,
        sb->specific.serial.multi_drop_enabled == 0 ? "No " : "Yes");
    printf("EOF length= %3d EOF char = %2X\n\r",
        sb->specific.serial.eof_length, sb->specific.serial.eof_char);
    printf("Recv Buff Avail= %s Xmit Buff Avail=%s Protocol Mode= %s",
        sb->specific.serial.have_recv_client_buffer == 0 ? "No " : "Yes",
        sb->specific.serial.have_xmit_client_buffer == 0 ? "No " : "Yes",
        sb->specific.serial.protocol_mode == 0 ? "Use Protocol" : "No Protocol");
}
else
    if(sb->handler_type != IM_RF_BACK_PH && status != OK) err_msg(status);

if(sb->handler_type == IM_RF_BACK_PH && status == OK) // it is the rf handler
{
    printf("\n\rPort: %ld Protocol Handler Ver. %s\n\r",
        port, sb->handler_ver);
    printf("\n\rRF Back Ver= %ld.%ld",
        sb->specific.rf.RF_back_major_version,
        sb->specific.rf.RF_back_minor_version);
    printf("\n\rConnected= %s",
        sb->specific.rf.net_connect_status == 0 ? "No" : "Yes");
    printf("\n\rProt Enabled= %s Address= %d",
        sb->specific.rf.RF_protocol_enabled == 0 ? "No" : "Yes",
        sb->specific.rf.RH_device_address);
    printf("\n\rHost Addr= %d Channel= %d Net ID= %d",
        sb->specific.rf.RT_host_address,
        sb->specific.rf.RV_channel_select, sb->specific.rf.RW_network_ID);
}
else
    if(sb->handler_type == IM_RF_BACK_PH && status != OK) err_msg(status);
}

// Get the protocol's extended status for the specified port
IM_UINT Get_Ext_Status(IM_UINT port, IM_COMM_STATUS_BUFFER_s *sb)

```

## exstat.cpp

```
{
    _ES = FP_SEG((IM_COMM_STATUS_BUFFER_s far *) sb);    // pointer to buffer
    _BX = FP_OFF((IM_COMM_STATUS_BUFFER_s far *) sb);
    _CX = sizeof(IM_COMM_STATUS_BUFFER_s);    // buffer length
    _DX = port;    // port id
    _AH = 0x71;    // extended status function

    geninterrupt(COM_Int);

    return(_AX);
}

// Move the viewport around when spacebar is pressed
void Move_Viewport()
{
    vp++;
    if(vp % VP_ACROSS)
    {
        VP_Move(vp_vert == 1 ? 0 : 12, vp * VP_STEPSIZE);    // right
    }
    else
    {
        VP_Move(12 * vp_vert, 0);    // up or down
        vp = 0;
        vp_vert = (vp_vert == 1 ? 0 : 1);
    }
}

// Set the video mode to 20x16
IM_UINT Set_Video_Mode()
{
    _AH = 0x02;    // function 2 of int 79h
    _AL = 0x03;    // get current video mode

    geninterrupt(LCD_Int);    // LCD display size mode manager interrupt

    vm_mode = _AL;    // save the current video mode
    vm_params = _BX;    // save original video parameters

    _AH = 0x02;    // function 2 of int 79h
    _AL = 0x00;    // set mode to 80x25

    geninterrupt(LCD_Int);    // LCD display size mode manager interrupt

    return(_AL);    // return status, _AL = 0 if good, 0xFF if failed
}

// Return the video mode to its original status
void Reset_Video_Mode()
{
    _BX = vm_params;    // restore the original video parameters
    _AH = 0x02;    // function 2 of int 79h
    _AL = vm_mode;    // restore the original video mode

    geninterrupt(LCD_Int);    // LCD display size mode manager interrupt
}

// Executes the viewport move interrupt
IM_UINT VP_Move(IM_UINT row, IM_UINT col)
{
    _AL = 0x01;    // relative viewport move
    _AH = 0x03;    // viewport move function
}
```



```
    _BX = row;
    _CX = col;

geninterrupt(LCD_Int);

    return(_AX);
}

// Display error messages
void err_msg(IM_UINT status)
{
    switch(status) {
        case ERR_NO_HANDLER:
            printf("\n\r%s\n\r", "ERROR- No protocol handler loaded!");
            break;
        case ERR_BAD_VER:
            printf("\n\r%s\n\r", "ERROR- Incompatible revision level!");
            break;
    }
}
```

*fifo.cpp*

---

## ***fifo.cpp***

```
/* fifo.cpp
 *
 * This program demonstrates the use of the UART restore interrupt and APM
 * interface protocol. This function is only necessary if your program is
 * communicating using the FIFO Control Register (FCR) in 16550 mode of the UART,
 * you are not using one of the INTERMEC protocol handlers, and power management
 * is active. Since the UART restore function depends on power management, this
 * program also demonstrates the use of the PM interface.
 *
 * This program doesn't actually do any communications or set the 16550
 * mode. Instead, it illustrates how to reset the FCR (a write only register)
 * after someone turns off the reader's power.
 *
 * Pressing the 1/0 key on the Janus gives no warning to your program thru
 * power management. PM only notifies you upon power up and by then the
 * UART has been reset.
 *
 * Written: July 28, 1994
 * Last Modified: Aug. 1, 1994
 * Author: Ray Rogers
 * Compiler: Borland C++ Ver 3.1 Small Memory Model
 */

#include "dos.h"
#include "stdio.h"
#include "conio.h"

#define PM_Int          0x15          // power mgmt interrupt
#define TRUE           1
#define FALSE          0
#define NORMAL_RESUME  0x03
#define CRITICAL_RESUME 0x04
#define CARRY           0x01          // carry flag mask
#define ESC             0x1b          // escape key
#define UART_Int       0x78          // int used to control UART
#define RESTORE         0x06          // restore function

// Function Prototypes
void PM_Connect(void);
void PM_Check(void);
void PM_Disconnect(void);
void Set_FIFO(void);
void Store_UART(void);
void Restore_UART(void);
int PM_Event(void);

unsigned char FCR; // FIFO ctrl register value

void main(void)
{
    PM_Check();

    PM_Connect();

    Set_FIFO();

    Store_UART();
}
```

```

while(TRUE)                                // main processing loop
{
    if(PM_Event())
        Restore_UART();

    /*
    ** Do communications here
    */

    if(kbhit())
        if(getch() == ESC) break;          // exit program on escape

    } // end main loop

    PM_Disconnect();
}

//APM installation check
void PM_Check()
{
    _AX = 0x5300;
    _BX = 0x0000;

geninterrupt(PM_Int);
}

// Connect this program to Power Management
void PM_Connect()
{
    _AX = 0x5301;                            // register as a PM partner
    _BX = 0x0000;

    geninterrupt(PM_Int);
}

// Disconnect this program from Power Management
void PM_Disconnect()
{
    _AX = 0x5304;                            // resign as a PM partner
    _BX = 0x0000;

    geninterrupt(PM_Int);
}

// Poll PM event status
int PM_Event()
{
    int event;

    _AX = 0x530b;                            // ask for event status

    geninterrupt(PM_Int);

    if(_FLAGS & CARRY)                        // if carry flag set function failed
        return(FALSE);

    event = _BX;                              // status returned in bx

    if(event == NORMAL_RESUME || event == CRITICAL_RESUME)
        return(TRUE);
    else
        return(FALSE);
}

```

## *fifo.cpp*

```
}  
// Prepare the FIFO register value  
void Set_FIFO()  
{  
    FCR = 0x80; // set FIFO trigger to 8 bytes  
}  
  
// Store the readable UART registers so that they can be restored  
// if necessary  
void Store_UART()  
{  
    _AX = 0x0600; // get UART cfg and save  
    _BL = 0x01;  
  
    geninterrupt(UART_Int);  
  
    _AX = 0x0606; // save FCR value  
    _BL = 0x01;  
    _BH = FCR;  
  
    geninterrupt(UART_Int);  
  
// NOTE: In a real program it would be wise to use a return value here  
}  
  
// Restore the all UART settings including FCR after power returns  
void Restore_UART()  
{  
    _AX = 0x0604; // restore UART settings  
    _BL = 0x01;  
  
    geninterrupt(UART_Int);  
}
```

**jbeep.cpp**

```

/* jbeep.cpp
 *
 * This program demonstrates sound control using interrupts.
 * Usage is: JBEEP volume pitch duration off_time
 *           JBEEP 3 (Loud) 1000 (Hz) 500 (ms) 20 (ms)
 *
 * Written: Aug. 20, 1993
 * Last Modified: Sept. 9, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "stdio.h"
#include "string.h"
#include "dos.h"
#include "conio.h"
#include "stdlib.h"
#include "im20lib.h"

// Defines
#define SOUND_Int 0x7c // sound generation interrupt

typedef struct // beeper sound structure
{
    IM_UCHAR volume;
    IM_UINT pitch;
    IM_UINT duration;
    IM_UINT off_time;
} IM_BEEP_PARAMS;

// Prototypes
IM_UINT Make_Noise(IM_UCHAR, IM_UINT, IM_UINT, IM_UINT);

void main(int argc, char *argv[])
{
    Make_Noise(argc > 1 ? atoi(argv[1]) : 5, // default volume
               argc > 2 ? atoi(argv[2]) : 1000, // default pitch
               argc > 3 ? atoi(argv[3]) : 200, // default duration
               argc > 4 ? atoi(argv[4]) : 20); // default off_time
}

IM_UINT Make_Noise(IM_UCHAR volume, IM_UINT pitch, IM_UINT duration, IM_UINT off_time)
{
    static IM_BEEP_PARAMS Beeper; // beeper sound structure
    Beeper.volume = volume; // loud
    Beeper.pitch = pitch; // HZ
    Beeper.duration = duration; // ms
    Beeper.off_time = off_time; // ms
    _ES = FP_SEG((IM_BEEP_PARAMS far *) &Beeper); // points to beeper structure
    _BX = FP_OFF((IM_BEEP_PARAMS far *) &Beeper); // points to beeper structure

    _CX = _DX = 0; // to be safe
    _AX = 0x64; // sound function

    geninterrupt(SOUND_Int); // generate the noise

    return(_AX);
}

```

*jboot.cpp*

---

## ***jboot.cpp***

```
/* jboot.cpp
 *
 * This program demonstrates warm boot control by using interrupts to enable/disable
 * the warm boot capability.
 *
 * Written: Aug. 25, 1993
 * Last Modified: Aug. 25, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1

#include "stdio.h"
#include "string.h"
#include "dos.h"
#include "conio.h"
#include "stdlib.h"
#include "im20lib.h"

// Defines
#define KEY_Int 0x16 // keyboard interrupt
#define STATUS 2 // get boot status
#define ENABLE 1 // enable boot
#define DISABLE 0 // disable boot
#define PROHIBITED 0x0000 // warm boot prohibited status

// Prototypes
IM_UINT Set_Boot(IM_UCHAR);

void main()
{
IM_UINT resp;

clrscr();
resp = Set_Boot(STATUS); // get the current boot status

if(resp == PROHIBITED) // if boot is currently prohibited
{
Set_Boot(ENABLE);
printf("%s", "\n\rWarm boot enabled...\n\r");
}
else
{
Set_Boot(DISABLE);
printf("%s", "\n\rWarm boot disabled...\n\r");
}

exit(0);
}

// Sets the boot control to enable or disable
IM_UINT Set_Boot(IM_UCHAR status)
{
_AH = 0xB7; // Ctrl-Alt-Del function
_AL = status;
geninterrupt(KEY_Int);

return(_AX);
}
```

---

**keybuff.cpp**

```

/* keybuff.cpp
 *
 * This program demonstrates keyboard buffer control using interrupts. It enables,
 * disables, and tests the expanded keyboard buffer.
 *
 * From the command line, enter:
 *   keybuff enable   or
 *   keybuff disable or
 *   keybuff test
 *
 * Written: Sept. 1, 1993
 * Last Modified: Sept. 1, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "dos.h"
#include "stdlib.h"
#include "string.h"
#include "conio.h"
#include "stdio.h"
#include "im20lib.h"

#define KEY_Int 0x16           // keyboard interrupt
#define KB_BUFF 0xb4          // buffer enable/disable function
#define KB_INSERT 0xb5        // insert string into buffer
#define KB_FLUSH 0xb6         // flush the buffer
#define KB_OFF 0x02           // function is off
#define KB_ON 0x01            // function is on
#define KB_OK 0x00            // function completed ok
#define KB_NO_BUFF 0x01       // buffer is enabled
#define KB_BUFF_FULL 0x02     // buffer is full
#define TRUE 0x00

// Prototypes
IM_UINT KB_Func(IM_UCHAR, IM_UCHAR);
IM_UINT KB_Test(void);

void main(int argc, char *argv[])
{
    IM_UINT resp;

    clrscr();

    if(argc == 1)              // no command line arguments
    {
        printf("%s", "\n\rUsage: keybuff [enable | disable | test]");
        exit(0);
    }

    KB_Func(KB_FLUSH, 0);     // no effect if buffer not there

    if(TRUE == strcmp("enable", strlwr(argv[1])))
    {
        KB_Func(KB_BUFF, KB_ON);
        printf("%s", "\n\rBuffer Enabled\n\r");
    }
}

```

## *keybuff.cpp*

```
if(TRUE == strcmp("disable", strlwr(argv[1])))
{
    KB_Func(KB_BUFF, KB_OFF);
    printf("%s", "\n\rBuffer Disabled\n\r");
}

if(TRUE == strcmp("test", strlwr(argv[1])))
{
    if((resp = KB_Test()) != KB_OK)
        if(resp == KB_NO_BUFF)
            printf("%s", "\n\rNo buffer installed!\n\r");
        else
            if(resp == KB_BUFF_FULL)
                printf("%s", "\n\rBuffer is full!\n\r");
}

    exit(0);
}

// Execute requested keyboard buffer function
IM_UINT KB_Func(IM_UCHAR func, IM_UCHAR subfunc)
{
    _AH = func; // keypad function
    _AL = subfunc; // subfunction

    geninterrupt(KEY_Int);

    return(_AL);
}

// Test the keyboard bffer
IM_UINT KB_Test()
{
    static char work[] = "This is a test of the keyboard buffer string insertion function";

    _ES = FP_SEG(work); // address of inserted string
    _BX = FP_OFF(work);

    _CX = strlen(work); // length of inserted string

    _AH = KB_INSERT; // insert function
    _AL = 0x02; // ASCII mode, no scancode translation

    geninterrupt(KEY_Int);

    return(_AL);
}
```



---

**keyclick.cpp**

```

/* keyclick.cpp
 *
 * This program demonstrates key click control using interrupts. It toggles the
 * state of the key click.
 *
.* Written: Aug. 31, 1993
.* Last Modified: Sept. 1, 1993
.* Author: Ray Rogers
.* Compiler: Borland C++ 3.1
*/

#include "dos.h"
#include "stdlib.h"
#include "conio.h"
#include "stdio.h"
#include "im20lib.h"

#define KEYPAD_Int 0x7e // keypad interrupt
#define KP_CLICK 0x05 // keypad click function
#define KP_OFF 0x00 // function is off
#define KP_ON 0x01 // function is on
#define KP_STATUS 0x02 // get status
#define KP_ENABLED 0xff // function is enabled
#define VALID_SERVICE 0x00 // valid function call
#define TRANS_OK 0x00 // func transaction executed ok

typedef struct {
    IM_UCHAR status; // KSCPU comm status
    IM_UCHAR kp_status; // 0xff if function already enabled
    IM_UINT padding; // work space
} RESP_BUFF;

RESP_BUFF rbuff;

// Prototypes
IM_UINT KP_Func(IM_UCHAR, IM_UCHAR, RESP_BUFF *);

void main()
{
    clrscr();

    if(VALID_SERVICE == KP_Func(KP_CLICK, KP_STATUS, &rbuff)) // get current status of
                                                                // click
    {
        if(TRANS_OK == rbuff.status)
            if(rbuff.kp_status == KP_ENABLED) // if it is on...
            {
                KP_Func(KP_CLICK, KP_OFF, &rbuff); // turn it off
                printf("%s", "\n\rKey click DISABLED\n\r\n\rPress a key...");
            }
            else
            {
                KP_Func(KP_CLICK, KP_ON, &rbuff); // else, turn it on
                printf("%s", "\n\rKey click ENABLED\n\r\n\rPress a key...");
            }
    }

    while(!kbhit()); // wait for a keypress
    getch();
    clrscr();
    exit(0);
}

```

*keyclick.cpp*

```
}  
// Execute requested keypad function  
IM_UINT KP_Func(IM_UCHAR func, IM_UCHAR subfunc, RESP_BUFF *resp)  
{  
    _ES = FP_SEG(resp);  
    _BX = FP_OFF(resp);  
  
    _AH = func;           // keypad function  
    _AL = subfunc;       // subfunction  
  
    geninterrupt(KEYPAD_Int);  
  
    return(_AH);  
}
```

---

## keystat.cpp

```

/* keystat.cpp
 *
 * This program demonstrates how to use the keyboard scanner and map table access using
 * interrupts.
 *
 * Written: Aug. 31, 1993
 * Last Modified: Aug. 31, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "dos.h"
#include "stdio.h"
#include "stdlib.h"
#include "conio.h"
#include "im20lib.h"

#define KEY_Int 0x7e // keyboard interrupt
#define ESC 0x1b // escape key
#define FOREVER 1 // endless loop control
#define SCAN_VER 0x03 // keypad scanner version function
#define MAP_ID 0x04 // map table ID function
#define VALID_SERVICE 0x00 // valid function call
#define TRANS_OK 0x00 // function executed ok
#define TABLE_VALID 0xff // valid keypad table

typedef struct {
    IM_UCHAR status; // KSCPU comm status
    IM_UCHAR minor; // minor revision
    IM_UCHAR major; // major revision
    IM_UINT padding; // work space
} scanner_buff; // keypad scanner version

typedef struct {
    IM_UCHAR status; // KSCPU comm status
    IM_UCHAR kp_number; // keypad number
    IM_UCHAR tabl_valid; // table validation, 0xff = pass
    IM_UINT chksum; // crc checksum
    IM_UINT padding; // work space
} map_table_buff; // map table ID buffer

typedef union {
    scanner_buff scan;
    map_table_buff map;
} RESP_BUFF;

RESP_BUFF rbuff; // KSCPU response buffer

// Prototypes
IM_UINT KP_Info(IM_UCHAR, RESP_BUFF *);

void main()
{
    clrscr();

```

## *keystat.cpp*

```
if(VALID_SERVICE == KP_Info(SCAN_VER, &rbuff))
{
    if(rbuff.scan.status == TRANS_OK)
    {
        printf("\n\rKeyPad Rev.= %d.%2d", rbuff.scan.major, rbuff.scan.minor);
    }
} // end VALID_SERVICE

if(VALID_SERVICE == KP_Info(MAP_ID, &rbuff))
{
    if(rbuff.map.status == TRANS_OK)
    {
        printf("\n\rMap ID= %X", rbuff.map.kp_number);
        printf("\n\rValid Table= %s",
            rbuff.map.tabl_valid == TABLE_VALID ? "Yes" : "No ");
        printf("\n\rCheck sum= %4X", rbuff.map.chksum);
    }
} // end VALID_SERVICE

printf("%s", "\n\r\n\rPress any key...");
while(!kbhit()); // wait for key press
getch();
clrscr();

exit(0);
}

// Do keypad functions
IM_UINT KP_Info(IM_UCHAR func, RESP_BUFF *rbuff)
{
    _ES = FP_SEG((RESP_BUFF *) rbuff); // far pointer to response buffer
    _BX = FP_OFF((RESP_BUFF *) rbuff); // far pointer to response buffer

    _AH = func; // scanner version or map ID function

    geninterrupt(KEY_Int);

    return(_AH);
}
```

---

**numpad.cpp**

```

/* numpad.cpp
 *
 * This program demonstrates key click control using interrupts. It toggles the
 * modality of the keypad.
 *
 * Written: Sept. 1, 1993
 * Last Modified: Sept. 1, 1993
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1
 */

#include "dos.h"
#include "stdlib.h"
#include "conio.h"
#include "stdio.h"
#include "im20lib.h"

#define KEYPAD_Int 0x7e // keypad interrupt
#define KP_NUMPAD 0x06 // keypad numpad function
#define KP_OFF 0x00 // function is off
#define KP_ON_NUM_ON 0x01 // pad enabled, numlock is on
#define KP_ON_NUM_OFF 0x02 // pad enabled, numlock is off
#define KP_STATUS 0x03 // get status
#define KP_ENABLED 0xff // function is enabled
#define VALID_SERVICE 0x00 // valid function call
#define TRANS_OK 0x00 // func transaction executed ok
#define ESC 0x1b // ESC key
#define FOREVER 1 // endless loop

typedef struct {
    IM_UCHAR status; // KSCPU comm status
    IM_UCHAR pad_status; // 0xff if function already enabled
    IM_UCHAR permit_status; // 0xff if switching modality from keypad
    // permitted
    IM_UINT padding; // work space
} RESP_BUFF;

RESP_BUFF rbuff;

// Prototypes
IM_UINT KP_Func(IM_UCHAR, IM_UCHAR, RESP_BUFF *);

void main()
{
    IM_UCHAR ch;

    clrscr();

    printf("%s", "\n\rCurrent NumPad Status:");

    if(VALID_SERVICE == KP_Func(KP_NUMPAD, KP_STATUS, &rbuff)) // get curr. status of
                                                                //click
    if(TRANS_OK == rbuff.status)
        if(rbuff.pad_status == KP_ENABLED) // if it is on...
            printf("%s", "\n\rNUMPAD ENABLED - \n\rPC KB 102 codes in use\n\r\n\r");
        else
            printf("%s", "\n\rNUMPAD DISABLED - \n\rQWERTY codes in use\n\r\n\r");
            printf("%s", "Choose New Setting:\n\r1. Disable Numpad\n\r");
            printf("%s", "\r2. Enable, NumLk On\n\r3. Enable, NumLk Off\n\r");
}

```

## *numpad.cpp*

```
    KP_Func(KP_NUMPAD, KP_OFF, &rbuffer); // make sure we can get menu choice
    ch = ' ';
    while(ch != ESC)
    {
        ch = getch();

        switch(ch)
        {
            case '1':
                KP_Func(KP_NUMPAD, KP_OFF, &rbuffer);
                ch = ESC;
                break;
            case '2':
                KP_Func(KP_NUMPAD, KP_ON_NUM_ON, &rbuffer);
                ch = ESC;
                break;
            case '3':
                KP_Func(KP_NUMPAD, KP_ON_NUM_OFF, &rbuffer);
                ch = ESC;
                break;
        }
    };

    clrscr();
    exit(0);
}

// Execute requested keypad function
IM_UINT KP_Func(IM_UCHAR func, IM_UCHAR subfunc, RESP_BUFF *resp)
{
    _ES = FP_SEG(resp);
    _BX = FP_OFF(resp);

    _AH = func; // keypad function
    _AL = subfunc; // subfunction
    _CL = 0x01; // keypad mode switching permitted

    geninterrupt(KEYPAD_Int);

    return(_AH);
}
```

---

## **open.cpp**

```
/* open.cpp
 *
 * This program demonstrates how to open COM2 on the 2D JANUS.
 *
 * Written: Feb. 10, 1999
 * Last Modified: Feb. 10, 1999
 * Author: Peter J. Girodat
 * Compiler: Borland C++ 3.1
 */

#include <dos.h>
#include <stdio.h>
#include <stdlib.h>

#define RS_VECTOR          0x7D      /* Interrupt 7DH Reader Services */
#define RS_ASIC_RESET     0x0C      /* Function 0CH ASIC Reset */
#define RS_CLOSE_COM2     0x0D      /* Function 0DH Close COM2 */
#define RS_ALL_SUCESS     0x0100    /* Reader Service sucessful */
#define RS_INVALID_REQUEST 0x8100   /* Invalid function Hex code received */

void main()
{
    _AH = RS_ASIC_RESET;           // AH = Function 0CH
    _AL = 0;

    geninterrupt(RS_VECTOR);

    if (_AX == RS_ALL_SUCESS)
        printf ("COM2 OPEN\n");
    else if (_AX == RS_INVALID_REQUEST)
        printf ("JANUS 1D Reader\n");
}
```

*phterm.cpp*

---

## ***phterm.cpp***

```
/* phterm.cpp
 *
 * This program demonstrates how to use interrupts and protocol. It requires a
 * Janus running PHIMEC.EXE and a connection to something else using an INTERMEC
 * protocol.
 *
 * Written: Aug. 12, 1993 as PHCOMM, derived PHTERM Feb. 28, 1994
 * Last Modified: March 1, 1994
 * Author: Ray Rogers
 * Compiler: Borland C++ 3.1, small model
 */

#include "stdio.h"
#include "string.h"
#include "dos.h"
#include "conio.h"
#include "stdlib.h"
#include "im20lib.h"

// Defines
#define COM_Int 0x14 // Communications interrupt
#define LCD_Int 0x79 // LCD size mode manager interrupt
#define SOUND_Int 0x7c // sound generation interrupt
#define VIDEO_Int 0x10 // video interrupt
#define ESC 0x1b // char 27, Escape
#define TXBUFFSIZE 512 // transmit buffer size
#define RXBUFFSIZE 512 // receive buffer size
#define COM_PORT 3 // default to com port 0 for Janus
#define LOUD 3 // loud volume for beep
#define NORMAL 2 // normal volume for beep
#define LOW 1 // low volume for beep
#define BOOL IM_UINT
#define TRUE 1
#define FOREVER TRUE

typedef struct // beeper sound structure
{
    IM_UCHAR volume;
    IM_UINT pitch;
    IM_UINT duration;
    IM_UINT off_time;
} IM_BEEP_PARAMS;

// struct for window control on JANUS
typedef struct
{
    IM_UCHAR ur; // upper row
    IM_UCHAR uc; // upper column
    IM_UCHAR lr; // lower row
    IM_UCHAR lc; // lower column
    IM_UCHAR cr; // current row, relative to this window
    IM_UCHAR cc; // current column, relative to this window
} JANUS_WINDOW;

// Global Variables
IM_UINT vm_mode; // saves original video mode
IM_UINT vm_params; // saves original video parameters
IM_COM_DATA_BUFFER s_struct; // send structure
IM_COM_DATA_BUFFER r_struct; // receive structure
```



```

IM_UCHAR s_buff[TXBUFSIZE];           // send buffer
IM_UCHAR r_buff[RXBUFSIZE];          // receive buffer
JANUS_WINDOW iw = {0, 0, 0, 19, 0, 0}; // input window
JANUS_WINDOW ow = {3, 0, 14, 19, 0, 0}; // output window

// Prototypes
IM_UINT Ck_RX_Buffer_Status(IM_UINT portid);
IM_UINT TX_Buffer(IM_UINT portid);
IM_UINT RX_Buffer(IM_UINT portid);
IM_UINT Set_Video_Mode(void);
IM_UINT Make_Noise(IM_UCHAR, IM_UINT, IM_UINT, IM_UINT);
IM_UINT Get_Input(void);
void Reset_Video_Mode(void);
void Cancel_TX(IM_UINT port);
void Cancel_RX(IM_UINT port);
void Pos_Cursor(JANUS_WINDOW *, IM_UINT, IM_UINT);
void Shift_Left(IM_UINT);
void Blank_Input(void);
void Ck_y(JANUS_WINDOW *);

void main()
{
    if(Set_Video_Mode())                // set video mode, sound beep and exit on failure
    {
        Make_Noise(LOUD, 2000, 200, 20); // loud, high pitch
        Make_Noise(NORMAL, 500, 250, 20); // normal, low pitch
        exit(1);
    }

    Pos_Cursor(&ow, 0, -1);
    printf("%s", "_____");
    ow.cr = 0;
    Pos_Cursor(&iw, 0, 0);

    r_buff[0] = '\0';
    RX_Buffer(COM_PORT);                // read the comm line

    // main processing loop, exit loop on ESC key
    while(FOREVER)
    {
        if(Get_Input() == ESC)          // get input from keyboard or comm line
            break;

        TX_Buffer(COM_PORT);            // end main loop
    }

    Reset_Video_Mode();                 // return video mode to original settings
    Cancel_TX(COM_PORT);                // shut down interface to protocol handler
    Cancel_RX(COM_PORT);

    Make_Noise(LOUD, 1000, 200, 20);    // loud, high pitch
    Make_Noise(NORMAL, 250, 250, 20);   // normal, low pitch

    exit(0);
}

// Prepare input line for new input by clearing out the old
void Blank_Input()
{
    Pos_Cursor(&iw, 0, 0);
    printf("%s", " ");
    Pos_Cursor(&iw, 0, 0);
}

```

## *phterm.cpp*

```
}

// Cancel the RX buffer
void Cancel_RX(IM_UINT port)
{
    _DX = port;
    _AH = 0x84;

    geninterrupt(COM_Int);
}

// Cancel the TX buffer
void Cancel_TX(IM_UINT port)
{
    _DX = port;
    _AH = 0x85;

    geninterrupt(COM_Int);
}

//Check the receive buffer is a misnomer for this function since it actually instructs
//the protocol handler to receive a packet. After that, you must check
//protocol_xfer_status periodically to see if anything has been received yet.
IM_UINT Ck_RX_Buffer_Status(IM_UINT port)
{
    r_struct.command = IM_CU_RECV_AGAIN;           // set the cmd to receive
    *(r_struct.data_ptr) = '\0';
    r_struct.comm_length = 0;

    _DX = port;                                 // select the com port
    _AH = 0x17;                                 // check com port receive buffer status function

    geninterrupt(COM_Int);

    return(r_struct.protocol_xfer_status);
}

// Check the row position that is about to be used for displaying a line
// received from the comm port. If it is the bottom of the screen, scroll
// the window to make room.
void Ck_y(JANUS_WINDOW *jw)
{
    if(jw->ur+jw->cr > jw->lr)
    {
        jw->cr--;
        _AH = 0x06;                             // video scroll function
        _AL = 1;                                 // number of lines to scroll
        _CH = jw->ur;                             // upper left row
        _CL = jw->uc;                             // upper left column
        _DH = jw->lr;                             // lower right row
        _DL = jw->lc;                             // lower right col
        _BH = 0x07;                             // normal video mode

        geninterrupt(VIDEO_Int);
    }
}

// Position the cursor outside the defined text window
void Pos_Cursor(JANUS_WINDOW *jw, IM_UINT loc, IM_UINT row)
{
    jw->cr = row;
    jw->cc = loc;
}
```

```

    _DH = jw->ur+row;          // row
    _DL = jw->uc+loc;         // column
    _BH = 0;                  // page
    _AH = 0x02;              // position cursor function
    geninterrupt(VIDEO_Int); // video
}

// Get the next input string from the keyboard while watching for input from the comm line
IM_UINT Get_Input()
{
    IM_UINT x, ch;

    ch = x = 0;
    iw.cc = 0;
    while(ch != ESC && ch != '\r') // keybd input ends with CR or ESC
    {
        if(kbhit())
        {
            ch = getch(); // use getch(), then printf() because JANUS

            if(ch == '\r')
                Blank_Input(); // clears input line for clean start
            else
                if(iw.uc+iw.cc >= iw.lc)
                    Shift_Left(x); // input exceeds line length, scroll left
                else
                    Pos_Cursor(&iw, iw.cc, 0);

            printf("%c", ch); // doesn't like getche() or cputs()
            if(ch == '\b') // backspace is the only supported editing key
            {
                x--;
                iw.cc--;
            }
            else
            {
                iw.cc++;
                s_buff[x++] = ch;
            }
        }

        if(r_struct.protocol_xfer_status == 0x0601) // 0x0601 is comm buffer done from
                                                    // last recv request
        {
            *(r_struct.data_ptr + r_struct.comm_length) = '\0'; // add null to receive
            Ck_y(&ow); // buffer
            Pos_Cursor(&ow, 0, ow.cr);
            ow.cr++;
            printf("%s\n\r", r_buff); // print buffer contents
            Pos_Cursor(&iw, 0, 0);
            Ck_RX_Buffer_Status(COM_PORT); // issue request for next packet
        }
    }

    strcpy(&s_buff[x], "\n"); // add a line feed and a null character
    return(ch);
}

// read the receive buffer
IM_UINT RX_Buffer(IM_UINT port)
{
    r_struct.command = IM_CU_RECEIVE; // set the cmd to receive
}

```

## *phterm.cpp*

```
    r_struct.user_length = RXBUFFSIZE;
    r_struct.data_ptr = (IM_UCHAR far *) r_buff;
    r_struct.protocol_mode = IM_USE_PROTOCOL;
    _ES = FP_SEG((IM_COM_DATA_BUFFER far *) &r_struct);
    _BX = FP_OFF((IM_COM_DATA_BUFFER far *) &r_struct);

    _DX = port;                // select the com port
    _AH = 0x60;                // receive buffer

    geninterrupt(COM_Int);

    return(r_struct.protocol_xfer_status);
}

// transmit the transmit buffer
IM_UINT TX_Buffer(IM_UINT port)
{
    s_struct.command = IM_CU_TRANSMIT; // set the cmd to transmit
    s_struct.data_ptr = (IM_UCHAR far *) s_buff;
    s_struct.user_length = strlen((IM_UCHAR far *) s_buff);
    s_struct.protocol_mode = IM_USE_PROTOCOL;

    _ES = FP_SEG((IM_COM_DATA_BUFFER far *) &s_struct);
    _BX = FP_OFF((IM_COM_DATA_BUFFER far *) &s_struct);

    _DX = port;                // select the com port
    _AH = 0x50;                // transmit buffer

    geninterrupt(COM_Int);

    return(s_struct.protocol_xfer_status);
}

// Make a noise to indicate a failure condition of some kind has occurred
IM_UINT Make_Noise(IM_UCHAR volume, IM_UINT pitch, IM_UINT duration, IM_UINT off_time)
{
    static IM_BEEP_PARAMS Beeper; // beeper sound structure
    Beeper.volume = volume;       // loud
    Beeper.pitch = pitch;         // HZ
    Beeper.duration = duration;   // ms
    Beeper.off_time = off_time;   // ms

    _ES = FP_SEG((IM_BEEP_PARAMS far *) &Beeper); // points to beeper structure
    _BX = FP_OFF((IM_BEEP_PARAMS far *) &Beeper); // points to beeper structure

    _CX = _DX = 0;                // to be safe
    _AX = 0x64;                   // sound function

    geninterrupt(SOUND_Int);      // generate the noise

    return(_AX);
}

// Set the video mode to 20x16
IM_UINT Set_Video_Mode()
{
    _AH = 0x02;                   // function 2 of int 79h
    _AL = 0x03;                   // get current video mode

    geninterrupt(LCD_Int);        // LCD display size mode manager interrupt

    vm_mode = _AH;                // save the current video mode
    vm_params = _BX;              // save original video parameters
}
```

```
    _AH = 0x02;           // function 2 of int 79h
    _AL = 0x01;           // set mode to 20x16

    geninterrupt(LCD_Int); // LCD display size mode manager interrupt
    return(_AL);           // return status, _AL = 0 if good, 0xFF if failed
}

// Return the video mode to its original status
void Reset_Video_Mode()
{
    _BX = vm_params;      // restore the original video parameters
    _AH = 0x02;           // function 2 of int 79h
    _AL = 0x00;
    _BH = vm_mode;        // restore the original video mode

    geninterrupt(LCD_Int); // LCD display size mode manager interrupt
}

// When input exceeds line length, scroll the line left
void Shift_Left(IM_UINT x)
{
    s_buff[x] = ' ';
    s_buff[x+1] = '\0';
    Pos_Cursor(&iw, 0, 0);
    printf("%s", s_buff+x-iw.lc+1);
    Pos_Cursor(&iw, iw.lc-1, 0);
}
```

*pl220ver.cpp*

---

## ***pl220ver.cpp***

```
/* pl220ver.cpp
 *
 * This program demonstrates how to display the Symbol PL220 Decoder
 * firmware revision level using interrupts.
 *
 * Written: Jan. 11, 1999
 * Last Modified: Feb. 25, 1999
 * Author: Peter J. Girodat
 * Compiler: Borland C++ 3.1
 */

#include <dos.h>
#include <stdio.h>
#include <stdlib.h>

#define RS_VECTOR          0x7D      /* Interrupt 7DH Reader Services */
#define RS_PL220_VER      0x0A      /* Function 0AH PL 220 Version */
#define RS_ALL_SUCESS    0x0100     /* Reader Service sucessful */
#define RS_INVALID_REQUEST 0x8100   /* Invalid function Hex code received */

void main()
{
    char pl220_version[16];

    _ES = FP_SEG((void*)pl220_version); // ES:BX Far pointer to pl220_version
    _BX = FP_OFF((void*)pl220_version);
    _AH = RS_PL220_VER;                // AH = Function 0AH
    _AL = 0;

    geninterrupt(RS_VECTOR);

    if (_AX == RS_ALL_SUCESS)
        printf ("%s\n",pl220_version);
    else if (_AX == RS_INVALID_REQUEST)
        printf ("JANUS 1D Reader\n");
}
```

---

**vp\_cur.cpp**

```
/* vp_cur.cpp
.*
.* This program demonstrates how to enable and disable the viewport follows cursor
.* function.
.*
.* Written: Sept. 23, 1993
.* Last Modified: September 23, 1993
.* Author: Ray Rogers
.* Everett, WA.
.* Borland C++ 3.1, small model
*/

#include "string.h"
#include "dos.h"
#include "stdio.h"
#include "im20lib.h"

#define KEY_Int 0x7e
#define OFF 0x11 //vp does not follow cursor
#define ON 0x10 //vp follows cursor

//Prototypes
IM_UINT VP_Set(IM_UINT);

void main(int argc, char *argv[])
{
    if(argc > 1)
    {
        if(strcmp(strupr(argv[1]), "OFF") == 0)
            VP_Set(OFF);
        else
            VP_Set(ON); //default is vp follows
    }
    else
        printf("\n\rUsage: vp_cur[on | off]\n\r");
}

//enable/disable viewport follows cursor
IM_UINT VP_Set(IM_UINT func)
{
    _AH = func;
    geninterrupt(KEY_Int);
    return(_AX);
}
```







***Index***



**A**

About This Manual, xiv  
 Advanced Power Management, 4-11  
 APM  
   BIOS calls, 4-22  
   described, 4-11  
   interface, 4-20

**B**

Backlight  
   im\_backlight\_off, 2-18  
   im\_backlight\_on, 2-19  
   im\_backlight\_toggle, 2-20  
 Battery, im\_power\_status, 2-91  
 BFT  
   im\_get\_reboot\_flag, 2-48  
   im\_ready\_for\_reboot, 2-97  
 BIOS calls  
   APM, 4-22  
   APM Installation Check, 4-24  
   CPU Busy, 4-25  
   CPU Idle, 4-26  
   Enable/Disable Power Management, 4-27  
   Get PM Event, 4-28  
   Get Power Status, 4-30  
   Interface Connect, 4-31  
   Interface Disconnect, 4-32  
   Protected Mode 16-Bit Interface Connect, 4-33  
   Protected Mode 32-Bit Interface Connect, 4-35  
   Restore System BIOS Power-On  
     Defaults, 4-37  
   Set Power State, 4-38  
   Suspend System, 4-39  
   System Standby, 4-40  
 Borland C/C++  
   build procedure, 2-3  
   compiler, 2-3  
 Break, im\_appl\_break\_status, 2-16  
 Build procedure  
   Borland C/C++, 2-3  
   Borland C/C++ sample, 2-3

Build procedure (continued)

  Microsoft C/C++, 2-4  
   Microsoft C/C++ sample, 2-4

**C**

C language certified functions, 2-11  
 C language functions, 2-13  
   im\_appl\_break\_status, 2-16  
   im\_backlight\_off, 2-18  
   im\_backlight\_on, 2-19  
   im\_backlight\_toggle, 2-20  
   im\_cancel\_rx\_buffer, 2-21  
   im\_cancel\_tx\_buffer, 2-22  
   im\_clear\_abort\_callback, 2-23  
   im\_command, 2-24  
   im\_cursor\_to\_viewport, 2-26  
   im\_decrease\_contrast, 2-27  
   im\_get\_config\_info, 2-29  
   im\_get\_contrast, 2-31  
   im\_get\_control\_key, 2-32  
   im\_get\_display\_mode, 2-34  
   im\_get\_display\_type, 2-36  
   im\_get\_follow\_cursor, 2-37  
   im\_get\_input\_mode, 2-39  
   im\_get\_keyclick, 2-41  
   im\_get\_label\_symbology, 2-43  
   im\_get\_length, 2-45  
   im\_get\_postamble, 2-46  
   im\_get\_preamble, 2-47  
   im\_get\_reboot\_flag, 2-48  
   im\_get\_viewport\_lock, 2-51  
   im\_get\_warm\_boot, 2-53  
   im\_increase\_contrast, 2-55  
   im\_input\_status, 2-57  
   im\_irl\_a, 2-59  
   im\_irl\_k, 2-63  
   im\_irl\_n, 2-66  
   im\_irl\_v, 2-69  
   im\_irl\_y, 2-74  
   IM\_ISERROR, 2-79  
   IM\_ISGOOD, 2-80  
   IM\_ISSUCCESS, 2-81  
   IM\_ISWARN, 2-82

C language functions (continued)

- im\_link\_comm, 2-83
- im\_number\_pad\_off, 2-86
- im\_number\_pad\_on, 2-87
- im\_parse\_host\_response, 2-89
- im\_power\_status, 2-91
- im\_protocol\_extended\_status, 2-94
- im\_ready\_for\_reboot, 2-97
- im\_receive\_buffer, 2-98
- im\_receive\_buffer\_no\_wait, 2-101
- im\_receive\_buffer\_noprot, 2-104
- im\_receive\_byte, 2-107
- im\_receive\_input, 2-109
- im\_rs\_installed, 2-113
- im\_rx\_check\_status, 2-114
- im\_serial\_protocol\_control, 2-115
- im\_set\_abort\_callback, 2-118
- im\_set\_contrast, 2-122
- im\_set\_control\_key, 2-124
- im\_set\_display\_mode, 2-125
- im\_set\_follow\_cursor, 2-128
- im\_set\_input\_mode, 2-129
- im\_set\_keyclick, 2-131
- im\_set\_viewport\_lock, 2-132
- im\_set\_warm\_boot, 2-133
- im\_setup\_trx, 2-134
- im\_sound, 2-137
- im\_standard\_trx, 2-139
- im\_standby\_wait, 2-142
- im\_transmit\_buffer, 2-143
- im\_transmit\_buffer\_no\_wait, 2-145
- im\_transmit\_buffer\_noprot, 2-148
- im\_transmit\_byte, 2-151
- im\_unlink\_comm, 2-153
- im\_viewport\_end, 2-154
- im\_viewport\_getxy, 2-155
- im\_viewport\_home, 2-156
- im\_viewport\_move, 2-157
- im\_viewport\_page\_down, 2-159
- im\_viewport\_page\_up, 2-160
- im\_viewport\_setxy, 2-161
- im\_viewport\_to\_cursor, 2-165

C macros, 2-6

Caution, 1-5, 1-7, 2-13, 3-6, B-3

Certified functions, 2-11

Color, 4-10

Command, im\_command, 2-24

Communications

- receiving serial data, 4-6

- transmitting serial data, 4-9

- UART modes, 4-9

- using INT 14H extensions, 4-8

Compiler

- Borland C/C++, 2-3

- Microsoft C/C++, 2-4

Configuration, im\_get\_config\_info, 2-29

Contrast

- im\_decrease\_contrast, 2-27

- im\_get\_contrast, 2-31

- im\_increase\_contrast, 2-55

- im\_set\_contrast, 2-122

Control key

- im\_get\_control\_key, 2-32

- im\_set\_control\_key, 2-124

Conventions, manual, xv

Cursor

- im\_cursor\_to\_viewport, 2-26

- im\_get\_follow\_cursor, 2-37

- im\_get\_viewport\_lock, 2-51

- im\_set\_follow\_cursor, 2-128

- im\_set\_viewport\_lock, 2-132

- im\_viewport\_to\_cursor, 2-165

## D

Database

- accessing through DCM, 5-3

- defining a transaction, 5-4

- delete, 5-6

- im\_parse\_host\_response, 2-89

- im\_setup\_trx, 2-134

- im\_standard\_trx, 2-139

- read, 5-7

- sample program, 5-17

- setting up a reader to database

  - transaction, 5-5

- standby file, 5-15

- status codes, 5-7

  - by calling parameter, 5-9

  - in numerical order, 5-12

- symbolic return codes, 5-14

## Database (continued)

- update, 5-6
- write, 5-6

## DCM, 5-3, 5-6, 5-7, 5-14

- configuring, 5-5
- im\_parse\_host\_response, 2-89
- im\_setup\_trx, 2-134
- sample program, 5-17
- standby file, 5-15
- symbolic return codes, 5-14

## Debugging, using Turbo Debugger, 2-5

## Defined terms, xv

## Desktop mode, 2-40, 2-130, 4-4

## Disk, PSK, 1-8

## Display

- color, 4-10
- im\_get\_display\_mode, 2-34
- im\_get\_display\_type, 2-36
- im\_set\_display\_mode, 2-125

**E**

## Examples

- communications, 4-8
- input modes, 4-5
- multiple inputs, 4-7

## Examples, C

- apmif.c, B-4
- appbreak.cpp, B-7
- backlite.cpp, B-9
- close.cpp, B-10
- contrast.cpp, B-11
- ctlkey.cpp, B-13
- database transaction, 5-17
- exstat.cpp, B-15
- fifo.cpp, B-20
- im\_appl\_break\_status, 2-17
- im\_backlight\_off, 2-18
- im\_backlight\_on, 2-19
- im\_backlight\_toggle, 2-20
- im\_command, 2-25
- im\_decrease\_contrast, 2-28
- im\_get\_config\_info, 2-30
- im\_get\_control\_key, 2-33
- im\_get\_display\_type, 2-36
- im\_get\_follow\_cursor, 2-38

## Examples, C (continued)

- im\_get\_keyclick, 2-42
- im\_get\_label\_symbology, 2-44
- im\_get\_postamble, 2-46
- im\_get\_preamble, 2-47
- im\_get\_reboot\_flag, 2-49
- im\_get\_viewport\_lock, 2-52
- im\_get\_warm\_boot, 2-54
- im\_increase\_contrast, 2-56
- im\_input\_status, 2-58
- im\_irl\_a, 2-62
- im\_irl\_k, 2-65
- im\_irl\_n, 2-68
- im\_irl\_v, 2-73
- im\_irl\_y, 2-76
- IM\_ISERROR, 2-79
- IM\_ISGOOD, 2-80
- IM\_ISSUCCESS, 2-81
- IM\_ISWARN, 2-82
- im\_number\_pad\_off, 2-86
- im\_number\_pad\_on, 2-88
- im\_power\_status, 2-92
- im\_protocol\_extended\_status, 2-94
- im\_ready\_for\_reboot, 2-97
- im\_receive\_buffer, 2-99
- im\_receive\_buffer\_no\_protocol, 2-105
- im\_receive\_buffer\_no\_wait, 2-102
- im\_receive\_byte, 2-107
- im\_receive\_input, 2-110
- im\_rs\_installed, 2-113
- im\_serial\_protocol\_control, 2-116
- im\_set\_abort\_callback, 2-120
- im\_set\_contrast, 2-123
- im\_sound, 2-138
- im\_transmit\_buffer, 2-144
- im\_transmit\_buffer\_no\_wait, 2-146
- im\_transmit\_buffer\_noprot, 2-149
- im\_transmit\_byte, 2-152
- im\_viewport\_setxy, 2-162
- jbeep.cpp, B-23
- jboot.cpp, B-24
- keybuff.cpp, B-25
- keyclick.cpp, B-27
- keystat.cpp, B-29
- numpad.cpp, B-31

Examples, C (continued)

- open.cpp, B-33
- phterm.cpp, B-34
- pl220ver.cpp, B-40
- vp\_cur.cpp, B-41

**F, H**

Function libraries, supported languages, 1-6

Functions, listed by category, 2-14

Hexadecimal numbers, convention for, xvi

**I**

IM\_ISERROR, 2-6

IM\_ISGOOD, 2-6

IM\_ISSUCCESS, 2-6

IM\_ISWARN, 2-6

im\_parse\_host\_response, status codes, 5-11, 5-13

im\_setup\_trx, status codes, 5-11, 5-13

im\_standard\_trx, status codes, 5-9, 5-10, 5-12

Input modes, 4-3

- about, 4-4

- Desktop mode, 4-4

- Programmer mode, 4-4

- Wedge mode, 4-3

Installing Programmer's Software Kit, 1-8

Interrupts, 1-7

- about, 3-3

- definitions, 3-6

- INT 14H Function 17H, 3-7

- INT 14H Function 50H, 3-8

- INT 14H Function 60H, 3-9

- INT 14H Function 71H, 3-10

- INT 14H Function 84H, 3-11

- INT 14H Function 85H, 3-12

- INT 16H Function B4H, 3-13

- INT 16H Function B5H, 3-14

- INT 16H Function B6H, 3-15

- INT 16H Function B7H, 3-16

- INT 78H Function 06H, 3-17

- INT 79H Function 00H, 3-21

- INT 79H Function 01H, 3-22

- INT 79H Function 02H, 3-24

- INT 79H Function 03H, 3-26

- INT 7CH Function 64H, 3-29

- INT 7DH Function 08H, 3-30

Interrupts (continued)

- INT 7DH Function 0AH, 3-35

- INT 7DH Function 0CH, 3-36

- INT 7DH Function 0DH, 3-37

- INT 7EH Function 01H, 3-38

- INT 7EH Function 03H, 3-40

- INT 7EH Function 04H, 3-41

- INT 7EH Function 05H, 3-42

- INT 7EH Function 06H, 3-43

- INT 7EH Function 08H, 3-45

- INT 7EH Function 10H, 3-46

- INT 7EH Function 11H, 3-47

- programming, 3-6

- sample programs, B-3

- table of, 3-4

IPM interface, 4-18

- Critical Resume, 4-19

- Critical Suspend, 4-19

- Normal Resume, 4-18

- Normal Suspend, 4-18

IRL Command

- A, 2-59

- K, 2-63

- N, 2-66

- V, 2-69

- Y, 2-74

**J, K, L**

JANUS reader, about, 1-3

Keyboard, using, xvi

Keypad, using, xvi

Label, im\_get\_label\_symbology, 2-43

Libraries, PSK Language Libraries disk, 1-8

LOADSYMB.EXE, 4-4

**M**

Macros, status codes, 2-6

Manuals, other Intermec, xvii

Microsoft C/C++

- build procedure, 2-4

- compiler, 2-4

Mode

- Desktop, 2-40, 2-130

- im\_get\_input\_mode, 2-39

- im\_set\_input\_mode, 2-129

## Mode (continued)

- input, 4-3
- Programmer, 2-39, 2-129
- Wedge, 2-39, 2-129

## Multiple inputs, 4-6

**N, O**

## Nontransparent mode, 4-16

## Number pad

- im\_number\_pad\_off, 2-86
- im\_number\_pad\_on, 2-87

## Off power state, 4-15

**P**

## PHIMEC.EXE, 2-7

## PHPCSTD.EXE, 2-7

## Postamble, im\_get\_postamble, 2-46

## Power management

- application interface, 4-12
- BIOS calls, 4-22
- components, 4-11
- power states, 4-14
  - diagram, 4-13
  - Off, 4-15
  - Ready, 4-14
  - Standby, 4-14
  - Suspend, 4-15
- software layers, 4-11
- system BIOS interface, 4-12

## Power states

- cooperation, 4-16
- diagram, 4-13
- nontransparent mode, 4-16
- transitions, 4-15
- transparent mode, 4-16

## POWER.EXE, 4-17, 4-20, 4-21

## Preamble, im\_get\_preamble, 2-47

## Programmer mode, 2-39, 2-129, 4-4

## Protocol

- handlers, 2-7
- im\_protocol\_extended\_status, 2-94
- im\_serial\_protocol\_control, 2-115

**R**

## Reader

- about, 1-3
- Desktop mode, 4-4
- display color, 4-10
- input modes, 4-3, 4-4
- Programmer mode, 4-4
- Virtual Wedge, 1-4
- Wedge mode, 4-3

## Reader services, 4-3

- allowing multiple inputs, 4-6
- im\_rs\_installed, 2-113
- using function libraries, 1-5
- using software interrupts, 1-5

## Reader Wedge, 2-8

## Ready power state, 4-14

## Receive buffer

- im\_cancel\_rx\_buffer, 2-21
- im\_receive\_buffer, 2-98
- im\_receive\_buffer\_no\_wait, 2-101
- im\_receive\_buffer\_noprot, 2-104
- im\_receive\_byte, 2-107
- im\_receive\_input, 2-109
- im\_rx\_check\_status, 2-114

## Receiving serial data, 4-6

## Remote debugging with Borland C/C++, 2-5

## RSERVICE.EXE, 4-3, 4-4

## Run, caution, 1-5, 1-7, 2-13, 3-6, B-3

## Runtime requirements

- described, 2-7
- specific functions, 2-9

## RWTSR.EXE, 2-8

**S**

## Sample interrupt programs, B-3

## Software interrupts, 1-7

- definitions, 3-6
- programming, 3-6
- sample programs, B-3

## Software Interrupts, about, 3-3

## Sound, im\_sound, 2-137

Standby

- file, 5-15, 5-16
- im\_standby\_wait, 2-142
- power state, 4-14

Status code macros

- IM\_ISERROR, 2-79
- IM\_ISGOOD, 2-80
- IM\_ISSUCCESS, 2-81
- IM\_ISWARN, 2-82

Status codes, 2-6, A-1

- bit values, A-3
- database, 5-7
  - by calling parameter, 5-9
  - in numerical order, 5-12
  - symbolic return codes, 5-14

listed by subsystem, A-22

listed numerically, A-4

Subsystem

- Beep, A-36
- Communications, A-32, A-33
- Configuration management, A-24, A-25
- DCM support, A-43
- Decodes, A-28, A-29
- Display, A-42
- Event logger, A-38
- Intermec library, A-37
- Keyboard, A-39
- Keypad, A-41
- Power management, A-34
- Reader services, A-23
- Reader Wedge, A-30, A-31
- Scanner, A-27
- System configuration, A-40
- Timer, A-35

Suspend power state, 4-15

**T**

TDREMOTE.EXE, 2-5

Terms and conventions, xv

Transaction

- defining a database, 5-4
- sample program, 5-17
- sending to database, 5-6

Transmit buffer

- im\_cancel\_tx\_buffer, 2-22
- im\_transmit\_buffer, 2-143
- im\_transmit\_buffer\_no\_wait, 2-145
- im\_transmit\_buffer\_noprot, 2-148
- im\_transmit\_byte, 2-151

Transmitting serial data, 4-9

Transparent mode, 4-16

Turbo Debugger, 2-5

**U, V, W**

UART

- modes, 4-9
- restoring configurations, 3-17

Viewport

- im\_cursor\_to\_viewport, 2-26
- im\_get\_follow\_cursor, 2-37
- im\_get\_viewport\_lock, 2-51
- im\_set\_follow\_cursor, 2-128
- im\_set\_viewport\_lock, 2-132
- im\_viewport\_end, 2-154
- im\_viewport\_getxy, 2-155
- im\_viewport\_home, 2-156
- im\_viewport\_move, 2-157
- im\_viewport\_page\_down, 2-159
- im\_viewport\_page\_up, 2-160
- im\_viewport\_setxy, 2-161
- im\_viewport\_to\_cursor, 2-165

Virtual Wedge, 1-4

Warm boot

- im\_get\_warm\_boot, 2-53
- im\_set\_warm\_boot, 2-133

Warranty information, xiii

Wedge mode, 2-39, 2-129, 4-3