

Installation Instructions

*P/N 1-960343-02
Edition 2
September 1998*

EasyCoder 501/601 Industrial Interface Kit

The logo for Intermec, featuring a red triangle pointing to the right, followed by the word "ntermec" in a bold, lowercase, sans-serif font.

A **UNOVA** Company

EasyCoder 501/601 – Installation Instructions

INDUSTRIAL INTERFACE KIT


Introduction

Note:
Illustrations show an EasyCoder 501.
The principles for fitting this optional
equipment in an EasyCoder 601 are
exactly the same.

The Industrial Interface Board adds one serial communication port ("uart3") and one connector with four IN and four OUT ports to the standard serial communication port ("uart1:").

The IN/OUT ports provide an interface between the printer and various types of external equipment, such as gates, conveyor belts, wrappers etc. The input and output signals can be read or initiated by means of *Intermec Fingerprint* instructions. Thereby the printer can be used to control the external devices – or be controlled by them – according to the program.

The printer's firmware detects when an Industrial Interface Board is installed and adds communication and buffer setup options for the communication port "uart3:".



When an Industrial Interface Board is fitted, the following types of interfaces become available:

"uart1:"	<i>Fitted on printer's CPU board.</i>
RS 232C	<i>Standard. Selected by strap.</i>
RS 422 or 20 mA CL	<i>Option. Additional circuits required.</i>
"uart3:"	<i>Fitted on Industrial Interface Board.</i>
RS 232C	
IN/OUT connector	<i>Fitted on Industrial Interface Board.</i>
4 input channels	<i>The software can read the status of four different input signals.</i>
4 output channels	<i>The software can set four different signals to either open or closed contact and also read their status.</i>

The Industrial Interface Kit consists of:

- 1 Interface board assy.
- 2 Screws MRX-Z 3 × 6 FZB (not intended for *EasyCoder 501/601*)
- This Installation Instruction

EasyCoder 501/601
Industrial Interface Kit
Installation Instructions
Edition 2, September 1998
Part No. 1-960343-02


EasyCoder 501/601 – Installation Instructions

INDUSTRIAL INTERFACE KIT, cont'd.


Step-by-Step Installation Instructions

The only tool required is a Torx #T10 screwdriver.

- Turn off the power and remove the power cord.
- Remove the communication cable from communication port "uart1:".



- Open the right hand door.
- Remove the eight Torx screws that hold the cover over the left part of the printer (see illustration below).
- Remove the cover.




Continued!

EasyCoder 501/601 – Installation Instructions

INDUSTRIAL INTERFACE KIT, cont'd.

Step-by-Step Installation Instructions, cont'd.

- ❑ Remove the existing cover plate.
- ❑ Make sure that the CPU board is strapped and equipped for the desired type of communication on "uart1:" (see the *EasyCoder 501* or *EasyCoder 601* Technical Manual). Once the interface board has been fitted, it will be difficult to access the rear part of the CPU board.
- ❑ Fit the required straps on the Industrial Interface Board as described on page 5.
- ❑ Connect the cable from the interface board to connector **P-4** at the bottom rear corner of the CPU board. Be careful so the interface board and the CPU board do not come in contact with each other, which possibly may cause damage or short-circuiting.
- ❑ Fit the interface board assembly to the printer's rear plate from the inside as illustrated below using the same screws that held the removed cover plate.




Continued!

EasyCoder 501/601 – Installation Instructions

INDUSTRIAL INTERFACE KIT, cont'd.


Step-by-Step Installation Instructions, cont'd.

- ❑ Reassemble the printer in reverse order.
- ❑ Connect the communication cables to their respective connectors. Please refer to page 6 for pinout descriptions.
- ❑ Connect the power cord and turn on the power.
- ❑ If you intend to use the communication port "uart3:" (RS 232C), set up its communication and buffer parameters as described in the *EasyCoder 501* or *EasyCoder 601* Technical Manual.



INDUSTRIAL INTERFACE KIT, cont'd.

Straps



Communication Port "uart3:"

RS 232C:

There are no straps for controlling the RS 232C interface on "uart3:".

External +5V:

External +5V (max. 200 mA) can be made available on pin 16 by fitting a strap on **P-1**.

Be careful not to enable this option unintentionally, which may cause harm to the connected terminal, computer or other device.

In/Out Connector

In/Out port 201-204:

One relay for each port switches the OUT signal to open or closed as PORTOUT ON/OFF statements are executed in the program.

Four straps, **P-2**, **P-6**, **P-7** and **P-8**, control the relation between relay and output signal on output ports **201–204** respectively:

PORTOUT stmt	Strap between pins	OUT signal
PORTOUT (<nexp>) ON	1-2 (upper position)	Open
PORTOUT (<nexp>) ON	2-3 (lower position)	Closed
PORTOUT (<nexp>) OFF	1-2 (upper position)	Closed
PORTOUT (<nexp>) OFF	2-3 (lower position)	Open

EasyCoder 501/601 – Installation Instructions

INDUSTRIAL INTERFACE KIT, cont'd.

Connector Configuration

"uart3:" is a DB25 female connector.

The In/Out connector is a DB15 female connector.

The mounting holes are connected to chassis ground.


Pin	"uart3:" DB25 female	Remarks	Pin	In/Out connector DB15 female	Remarks	
1	GNDC	Cable shield	1	OUT 201	See example on next page	
2	TXDB	Transmitted data from printer	2	OUT 201		
3	RXDB	Received data to printer	3	OUT 202		
4	RTSB	RTS from printer	4	OUT 202		
5	CTSB	CTS to printer	5	OUT 203		
6	DRSB	DSR to printer	6	OUT 203		
7	GNDI	Signal ground	7	OUT 204		
8	–	not used	8	OUT 204		
9	–	not used	9	IN 101		See example on next page
10	–	not used	10	IN 101		
11	–	not used	11	IN 102		
12	–	not used	12	IN 102		
13	–	not used	13	IN 103		
14	–	not used	14	IN 104		
15	–	not used	15	IN 103/104		
16	+5VEXT	+ 5V max 200 mA*	OUT signals are controlled by means of PORTOUT (<nexp> ON OFF statements. IN and OUT signals are read by means of PORTIN (<nexp>) functions. Also see <i>Intermec Fingerprint 6.13 Programmer's Manual</i> .			
17	–	not used				
18	–	not used				
19	–	not used				
20	DTRB	DTR permanently high				
21	–	not used				
22	–	not used				
23	–	not used				
24	–	not used				
25	–	not used				
*/. If strap fitted on P-1						

EasyCoder 501/601 – Installation Instructions

INDUSTRIAL INTERFACE KIT, cont'd.


Connector Configuration, cont'd.

Example of an IN port




Signal	Min.	Typical	Max.
Input Voltage High	10V	24V	40V
Input Voltage Low	-1V	0V	1V

Example of an OUT port



Max AC Load Breaking Capacity	
Current	max. 1 A
Switching power	max. 100VA AC
Switching voltage	max. 100V AC

Max. DC Load Breaking Capacity



EasyCoder 501/601 – Installation Instructions

NOTES

Information in this manual is subject to change without prior notice and does not represent a commitment on the part of Intermec Printer AB.

© Copyright Intermec PTC AB, 1998. All rights reserved. Published in Sweden.

*EasyCoder and Fingerprint are registered trademarks of Intemec Technologies Corp.
Torx is a registered trademark of Camcar Division of Textron Inc.*
