

## Installation Instructions

*P/N 1-960452-04  
Edition 5  
January 2001*

# EasyCoder XP- & F-Series Industrial Interface Board

 **intermec**  
Technologies Corporation

---

A **UNOVA** Company

# Description

## Application of Use

The Industrial Interface Board is an optional device for EasyCoder 501 XP, EasyCoder 601 XP, EasyCoder F2, and EasyCoder F4, that provides the printer with two extra interfaces. The printer must be fitted with the Intermec Fingerprint v7.xx firmware.

## Serial Interface

This interface contains one serial communication channel ("uart2:") adapted for one of the following alternatives:

- RS-232
- RS-422 non isolated
- RS-422 isolated
- RS-485

The type of serial interface is selected by fitting various socket-mounted driver circuits and straps.

## Industrial Interface

This interface contains 8 IN and 8 OUT digital ports with optocouplers, plus 4 OUT ports with relays.

The status of the ports can be read by means of PORTIN functions and the OUT ports can be set by means of PORTOUT ON/OFF statements (see Intermec Fingerprint v7.xx Reference Manual.) Thus, it is possible to design Intermec Fingerprint programs which control not only the printer but also various external devices in for example a production line. The digital IN ports can read the status of various sensors and the program can switch control lamps on or off, open or close gates, and start or stop conveyor belts accordingly using the relays and the digital OUT ports.

## Installation Kit

The Industrial Interface Board Kit contains:

- One Industrial Interface Board fitted for either RS-232, RS-422 non isolated, or RS-422 isolated on the serial port.
- One cover plate (for EasyCoder XP-series printers only.)
- One flat cable (for EasyCoder F-series printers only.)
- This Installation Instructions booklet.

*Information in this manual is subject to change without prior notice and does not represent a commitment on the part of Intermec Printer AB.*

© Copyright Intermec Printer AB, 2001. All rights reserved. Published in Sweden.

*EasyCoder, EasyLAN, Fingerprint, and LabelShop are registered trademarks of Intermec Technologies Corp. The word Intermec, the Intermec logo, InterDriver, and PrintSet are trademarks of Intermec Technologies Corp.*

*Centronics is a registered trademark of Genicom Corporation.*

*Torx is a registered trademark of Camcar Division of Textron Inc.*

*EasyCoder XP- & F-Series  
Industrial Interface Board  
Installation Instructions  
Edition 5, January 2001  
Part No. 1-960452-04*

# Installation


## EasyCoder 501 XP and 601 XP

- Switch off the power and disconnect the power cord.


### **Warning!**

*The electronics compartment contains high voltage components and wires. Do not open the electronics compartment before the printer is safely disconnected from any AC supply.*

- Open the right-hand door.
- Remove the four #T10 Torx screws along the lower edge of the cover over the electronics compartment.
- Remove the four #T10 Torx screws that hold the upper edge of the same cover.




- Remove the cover and put it aside on a soft cloth or similar to avoid scratches.
- Remove the four #T10 Torx screws that hold the interface cover plate above the parallel interface connector on the printer's rear plate. Remove the cover plate.




- Save the cover plate for possible later use. Keep the screws.

## EasyCoder 501 XP and 601 XP, cont.

- If necessary, fit or remove circuits and straps to adapt the Industrial Interface Board for the desired type of serial interface as described in Chapter 3, “*Serial Port Configuration*” later in this booklet.
- Insert the Industrial Interface Board with the components side facing right, as seen from behind. Check that the board fits into the two square cut-outs on the left side of the slot.




- Attach the Industrial Interface Board to the printer's rear plate by means of two of the screws left over when you removed the original cover plate.
- Using the remaining two screws, attach the narrow cover plate included in the delivery so it covers the right side of the slot.
- Connect the cable running from **P81** on the CPU board to connector **P1** on the Industrial Interface Board.



## EasyCoder 501 XP and 601 XP, cont.

- Put back the cover over the electronics compartment. Press firmly to compress the leaf springs along the front and rear edges of the electronics compartment.
- Connect the power cord.
- Now you have two new interface connectors on the printer's rear plate in addition to the standard serial interface "uart1:" and the standard partallel interface "centronics:". Connect the interface cables and switch on the power.
- If you intend to use the serial interface ("uart2:"), enter the Setup Mode to set the proper baud rate, character length, parity, number of stop bits, flowcontrol, new line, and buffer size parameters.




## EasyCoder F2 and F4

- Open the electronics compartment by removing the front/left-hand cover, which is held by three #T20 Torx screws from the media compartment side of the center section.


**Warning!**

*Switch off the power and disconnect the power cord. The electronics compartment contains high voltage components and wires. Do not open the electronics compartment before the printer is safely disconnected from any AC supply.*



#T20 Torx screws (x3)


- Remove the two #T10 Torx screws that hold the interface cover plate on the printer's rear plate. Remove the cover plate.




- Save the cover plate for possible later use. Keep the screws.

### EasyCoder F2 and F4, cont.

- If necessary, fit or remove circuits and straps to adapt the Industrial Interface Board for the desired type of serial interface as described in Chapter 3, “Serial Port Configuration” later in this booklet.
- Insert the interface board with the components side facing right, as seen from behind.
- Attach the interface board to the printer’s rear plate by means of the two screws left over when you removed the original cover plate.




- Connect the flat cable included in the kit between connector **P81** on the CPU board and connector **P1** on the interface board (also see the next page.)




## EasyCoder F2 and F4, cont.

- Make sure that the cable between CPU board and interface board runs as illustrated below.



- Put back the front/left-hand cover.
- Connect the power cord.
- Now you have two new interface connectors on the printer's rear plate in addition to the standard interfaces "uart1:" and "usb1:". Connect the interface cables and switch on the power.
- If you intend to use the serial interface ("uart2:"), enter the Setup Mode to set the proper baud rate, character length, parity, number of stop bits, flowcontrol, new line, and buffer size parameters.



# Serial Port Configuration

## Introduction

The serial communication port "uart2:" can be configured for **one** of four different types of serial communication:


- RS-232
- RS-422 non isolated
- RS-422 isolated
- RS-485

By fitting or removing certain circuits and straps, the desired type of interface can be selected. This is either done at factory or by the customer. There can only be one driver circuit and its corresponding straps fitted at a time.


### Caution!

*When fitting circuits yourself, do it before connecting the interface board and make sure that the circuits are not fitted upside down (see front end markings in the illustrations in this chapter.) Also take care so all "legs" of the circuits fit into their respective slots in the socket and are not bent. Also, take proper precautions so as to protect the board and circuits from electrostatic discharges.*


## RS-232




### RS-422 Non Isolated



### RS-422 Isolated



# RS-485



## Connector Configuration

The serial interface for "uart2:" uses a female DB-25pin connector.

| Pin   | Signal Name | Description   |
|-------|-------------|---|
| 1     |             | Not connected                                       |
| 2     | TxD         | RS-232 Transmitter                                  |
| 3     | RxD         | RS-232 Receiver                                     |
| 4     | RTS         | RS-232 Request To Send                              |
| 5     | CTS         | RS-232 Clear To Send                                |
| 6     | DSR         | RS-232 Data Set Ready                               |
| 7     | GND         | Ground  |
| 8-14  |             | Not connected                                       |
| 15    | +RS422RI    | +RS-422 Receive                                     |
| 16    | +5V         | 5 Volt for external use (max. 200 mA) <sup>1/</sup> |
| 17    | -RS422RI    | - RS-422 Receive                                    |
| 18    |             | Not connected                                       |
| 19    | +RS422DO    | + RS-422 Transmit/+ RS-485                          |
| 20    | DTR         | RS-232 Data Terminal Ready                          |
| 21    | -RS422DO    | - RS-422 Transmit/- RS-485                          |
| 22    | RI          | RS-232 Ring Indicator                               |
| 23    | Shield      | Optional shield for RS-422 and RS-485               |
| 24-25 |             | Not connected                                       |

<sup>1/</sup>. The external 5V is automatically switched off at overload.

# Industrial Interface Configuration

## Introduction

The Industrial Interface provides:

- 8 digital IN ports with opto-couplers (Opto In)
- 8 digital OUT ports with opto-couplers (Opto Out)
- 4 OUT ports with relays (Relay Out)

The Industrial Interface has no straps or circuits to be fitted or removed. All signals are available on a female DB-44pin connector and the various ports are controlled by the Intermecc Fingerprint instructions PORTIN and PORTOUT ON/OFF (see Intermecc Fingerprint, v7.xx, Reference Manual.)


## Digital Opto In

The status of the digital IN ports 101-108 can be read by means of PORTIN functions. If a current is led through the opto-coupler of the port, PORTIN returns the value -1(true), else the value 0 (false.)

| Signal     | Description        | Min. | Typical | Max. |
|------------|--------------------|------|---------|------|
| Vin [High] | Input Voltage High | 10V  | 24V     | 40V  |
| Vin [Low]  | Input Voltage Low  | -1V  | 0V      | 1V   |

### Connector Configuration

| Pin | Signal Name | Description                 | Fingerprint Ref. No. |
|-----|-------------|-----------------------------|----------------------|
| 10  | IN1A        | Anode Opto In Channel 1 +   | 101                  |
| 40  | IN1K        | Cathode Opto In Channel 1 - |                      |
| 26  | IN2A        | Anode Opto In Channel 2 +   | 102                  |
| 11  | IN2K        | Cathode Opto In Channel 2 - |                      |
| 41  | IN3A        | Anode Opto In Channel 3 +   | 103                  |
| 27  | IN3K        | Cathode Opto In Channel 3 - |                      |
| 12  | IN4A        | Anode Opto In Channel 4 +   | 104                  |
| 42  | IN4K        | Cathode Opto In Channel 4 - |                      |
| 28  | IN5A        | Anode Opto In Channel 5 +   | 105                  |
| 13  | IN5K        | Cathode Opto In Channel 5 - |                      |
| 43  | IN6A        | Anode Opto In Channel 6 +   | 106                  |
| 29  | IN6K        | Cathode Opto In Channel 6 - |                      |
| 14  | IN7A        | Anode Opto In Channel 7 +   | 107                  |
| 44  | IN7K        | Cathode Opto In Channel 7 - |                      |
| 30  | IN8A        | Anode Opto In Channel 8 +   | 108                  |
| 15  | IN8K        | Cathode Opto In Channel 8 - |                      |



*Simplified schematics of a digital IN port.*

## Digital Opto Out


The current to each optocoupler of the digital OUT ports 221-228 can be turned on and off by means of PORTOUT ON/OFF statements.

The status of the ports can be read by means of PORTIN functions. If a current is led through the opto-coupler of the port, PORTIN returns the value -1(true), else the value 0 (false.)

| Signal | Description                         | Max.  |
|--------|-------------------------------------|-------|
| Vceo   | Collector-Emitter breakdown voltage | 35V   |
| Veco   | Emitter-Collector breakdown voltage | 7V    |
|        | Collector Current                   | 15 mA |
| Vog    | Output to ground (optocoupler)      | 100V  |

### Connector Configuration

| Pin | Signal Name | Description                  | Fingerprint Ref. No. |
|-----|-------------|------------------------------|----------------------|
| 20  | Out1c       | Collector Opto Out Channel 1 | 221                  |
| 5   | Out1e       | Emitter Opto Out Channel 1   |                      |
| 35  | Out2c       | Collector Opto Out Channel 2 | 222                  |
| 21  | Out2e       | Emitter Opto Out Channel 2   |                      |
| 6   | Out3c       | Collector Opto Out Channel 3 | 223                  |
| 36  | Out3e       | Emitter Opto Out Channel 3   |                      |
| 22  | Out4c       | Collector Opto Out Channel 4 | 224                  |
| 7   | Out4e       | Emitter Opto Out Channel 4   |                      |
| 37  | Out5c       | Collector Opto Out Channel 5 | 225                  |
| 23  | Out5e       | Emitter Opto Out Channel 5   |                      |
| 8   | Out6c       | Collector Opto Out Channel 6 | 226                  |
| 38  | Out6e       | Emitter Opto Out Channel 6   |                      |
| 24  | Out7c       | Collector Opto Out Channel 7 | 227                  |
| 9   | Out7e       | Emitter Opto Out Channel 7   |                      |
| 39  | Out8c       | Collector Opto Out Channel 8 | 228                  |
| 25  | Out8e       | Emitter Opto Out Channel 8   |                      |



*Simplified schematics of a digital OUT port.*

## Relay Out


The relays of the OUT ports 201-204 can be individually activated by means of PORTOUT ON/OFF statements.

The status of the ports can be read by means of PORTIN functions. If a relay is activated, PORTIN returns the value -1(true), else the value 0 (false.)

### Max AC Load Breaking Capacity


| Signal | Description       | Max.     |
|--------|-------------------|----------|
| I      | Current           | 1A       |
| Psw AC | Switching power   | 100VA AC |
| Usw AC | Switching voltage | 100V AC  |

### Max DC Load Breaking Capacity



### Connector Configuration

| Pin | Signal Name | Description             | Fingerprint Ref. No. |
|-----|-------------|-------------------------|----------------------|
| 16  | REL1nc      | Relay 1 Normally Closed | 201                  |
| 1   | REL1no      | Relay 1 Normally Open   |                      |
| 31  | REL1com     | Relay 1 Common          |                      |
| 17  | REL2nc      | Relay 2 Normally Closed | 202                  |
| 2   | REL2no      | Relay 2 Normally Open   |                      |
| 32  | REL2com     | Relay 2 Common          |                      |
| 18  | REL3nc      | Relay 3 Normally Closed | 203                  |
| 3   | REL3no      | Relay 3 Normally Open   |                      |
| 33  | REL3com     | Relay 3 Common          |                      |
| 19  | REL4nc      | Relay 4 Normally Closed | 204                  |
| 4   | REL4no      | Relay 4 Normally Open   |                      |
| 34  | REL4com     | Relay 4 Common          |                      |



*Simplified schematics of a relay OUT port.*

