



*6980/6985 Network Manager*

# ***PROGRAMMER'S GUIDE***



**P/N 977-055-002**  
*Revision B*  
*May 2000*

► NOTICE

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and service Intermec manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Disclaimer of Warranties. The sample source code included in this document is presented for reference only. The code does not necessarily represent complete, tested programs. The code is provided **“AS IS WITH ALL FAULTS.” ALL WARRANTIES ARE EXPRESSLY DISCLAIMED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

We welcome your comments concerning this publication. Although every effort has been made to keep it free of errors, some may occur. When reporting a specific problem, please describe it briefly and include the book title and part number, as well as the paragraph or figure number and the page number.

Send your comments to:  
Intermec Technologies Corporation  
Publications Department  
550 Second Street SE  
Cedar Rapids, IA 52401

ANTARES, INTERMEC, NORAND, NOR\*WARE, PEN\*KEY, ROUTEPOWER, TRAKKER, and TRAKKER ANTARES are registered trademarks and ENTERPRISE WIRELESS LAN, INCA, TE 2000, UAP, and UNIVERSAL ACCESS POINT are trademarks of Intermec Technologies Corporation.

© 2000 Intermec Technologies Corporation. All rights reserved.



This publication printed on recycled paper.

### Acknowledgments

*Hayes* is a registered trademark of Hayes Microcomputer Products Inc.

*Microsoft*, *MS*, and *MS-DOS*, and *Windows*, are registered trademarks and *Visual Basic for Windows*, and *Windows for Pen* are trademarks of Microsoft Corporation.

### FCC Computer Compliance

► NOTICE

This equipment meets Class A digital device limits per Part 15 of FCC Rules. These limits protect against interference in a commercial area. It emits, uses, and can radiate radio frequency energy. If you do not install and use the equipment according to its instructions, it may interfere with radio signals. Using it in a residential area is likely to cause interference. If this occurs, you must correct the interference at your expense.

### Canadian Computer Compliance

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada

# CONTENTS



## SECTION 1

### Introduction

About this Guide .....	1-2
Related Publications .....	1-2
Customer Support .....	1-2
Customer Response Center .....	1-2
Factory Service .....	1-2
Web Site .....	1-3
Bulletin Board Service .....	1-3

## SECTION 2

### Getting Started

Modem Support .....	2-1
Error Codes .....	2-1
Enhancements .....	2-1
Communication Session .....	2-2
Network Configurations .....	2-3
Physical Ports .....	2-3
Logical Channels .....	2-4
Compact Flash .....	2-4
Device Channel Option .....	2-5

## SECTION 3

### Host-to-Network Manager Records

EM311 Protocol Interface .....	3-1
Record Types .....	3-2
Download Data Record (Type 0) .....	3-3
End-of-Data Record (Type 1) .....	3-4
Initialization Record (Type 2) .....	3-5
System Mode Parameters .....	3-6
Host Parameters .....	3-7
Activate Autoanswer (Type 3) .....	3-8
Activate Autodial (Type 4) .....	3-9
Deactivate for One Minute (Type 5) .....	3-10
Host Directive (Type 6) .....	3-11
File Upload Directive "1" .....	3-12
File Create or Load Directive "2" .....	3-13
File Delete Directive "3" .....	3-14
File Download Directive "4" .....	3-15
File Processing Abort "6" .....	3-16
Special Commands .....	3-17
Type ? — Host Ready Command .....	3-17
Type * — Reinitialization Command .....	3-17

**SECTION 4**

**Network Manager-to-Host Records**

Record Formats with 2-byte Channel ID .....	4-1
Record Types .....	4-2
Upload Data (Type 0) .....	4-3
End of Session Status (Type 1) .....	4-4
Data Request (Type 2) .....	4-5
Inactive Status (Type 3) .....	4-5
Active Status (Type 4) .....	4-6
Activation Request (Type 5) .....	4-6
Special Request (Type 6) .....	4-8
Directive Status (Type 7) .....	4-9
Begin of Call (Type C) .....	4-10
Network Manager-Based File Processing .....	4-11

**SECTION 5**

**EM611 IP Header Information**

Local 6980 Network Manager (NPCMux Functionality) .....	5-2
Host Interface to “6980 NPCMux” .....	5-3

**APPENDIX A**

**4980-to-6980 Conversion**

Communication and Application Diagram .....	A-2
AS/400 or 4980 Conversion to 6980 .....	A-2
4980 Interface on an AS/400 .....	A-2
6980 Interface on an AS/400 .....	A-3

**APPENDIX B**

**Adapting Programs Used with the 4980 Protocol Converter**

Record Types .....	B-1
4980 Record Types .....	B-1
Communications Controller-to-Host .....	B-1
Host-to-Communications Controller .....	B-1
6980/6985 Record Types .....	B-2
Network Manager-to-Host .....	B-2
Host-to-Network Manager Records .....	B-3
Special Commands .....	B-4

**APPENDIX C**

<b>Asynchronous Hosts</b> .....	<b>C-1</b>
---------------------------------	------------

**APPENDIX D**

<b>Pseudo Host Communications Program</b> .....	<b>D-1</b>
---	------------

**FIGURES**

Figure 5-1 EM611 Structure and Definition .....	5-1
Figure A-1 Architecture between 6980 Socket Manager and AS/400 .....	A-2
Figure A-2 AS/400 Programming Architecture .....	A-3

**TABLES**

Table 2-1 Network Manager Environments .....	2-2
Table 2-2 Physical Ports for Client Connections .....	2-3
Table 3-1 Host-to-Network Manager Records .....	3-2
Table 3-2 Type 0 — Download Data Record .....	3-3
Table 3-3 Type 1 — End-of-Data Record .....	3-4
Table 3-4 Type 2 — Initialization Record .....	3-5
Table 3-5 System Mode Parameters .....	3-6
Table 3-6 Host Parameters .....	3-7
Table 3-7 Type 3 — Activate (Auto-Answer) Record .....	3-8
Table 3-8 Type 4 — Activate (Auto-Dial) Record .....	3-9
Table 3-9 Type 5 — Deactivate for One Minute Record .....	3-10
Table 3-10 Type 6 — Host Directive Record .....	3-11
Table 3-11 File Upload Directive “1” .....	3-12
Table 3-12 File Create or Load Directive “2” .....	3-13
Table 3-13 File Delete Directive “3” .....	3-14
Table 3-14 File Download Directive “4” .....	3-15
Table 3-15 File Processing Abort “6” .....	3-16
Table 3-16 Type ? — Host Ready Command .....	3-17
Table 3-17 Type * — Reinitialization Command .....	3-17
Table 4-1 2-Byte Channel ID .....	4-1
Table 4-2 Network Manager-to-Host Record Types .....	4-2
Table 4-3 Type 0 — Upload Data Record .....	4-3
Table 4-4 Type 1 — End of Session Status Record .....	4-4
Table 4-5 End of Session Status Codes .....	4-4
Table 4-6 Type 2 — Data Request Record .....	4-5
Table 4-7 Type 3 — Inactive Status Record .....	4-5
Table 4-8 Type 4 — Active Status Record .....	4-6
Table 4-9 Type 5 — Activation Request Record .....	4-6
Table 4-10 Activation Request Status Codes .....	4-7
Table 4-11 Type 6 — Special Request Record .....	4-8
Table 4-12 Special Request Subtypes .....	4-8
Table 4-13 Type 7 — Directive Status Record .....	4-9
Table 4-14 Host File Directive Status Codes .....	4-10
Table 4-15 Type C — Begin of Call Record .....	4-10
Table 4-16 NETRPL.LST File .....	4-11
Table 5-1 EM611 Packet and Header .....	5-1
Table 5-2 6980 NPCMux Commands .....	5-3

**GLOSSARY****INDEX**



# Section 1

## Introduction



► **NOTE:**

*This publication supersedes the 4980 Network Controller Programmer's Guide (P/N: 977-028-001) and the 4985 Network Controller Programmer's Guide (P/N: 977-028-006).*

The 6980/6985 Network Manager provides a data communications interface between the host computer and INTERMEC<sup>®</sup> devices. The network manager is programmable and can be configured many ways. The two functions in this release of the 6980/6985 Network Manager are:

- ▶ An asynchronous (async) or IP-based communications gateway to a host computer
- ▶ A hand-held computer network manager.

In the first function, the network manager is directly connected to a customer's host computer and provides a gateway through which data and data requests pass from hand-held computers to the host on logical channels.

In the second function, the network manager is usually located at a remote site and provides an interface between hand-held computers and a host. Section 2 provides illustrations of several possible system configurations.

A host telecommunication program and associated support programs are required to interface to a 6980/6985 Network Manager. This function can be provided by the Norand<sup>®</sup> 6920 Communications Server or some other host application.

The RS-232 host link can be configured for speeds up to 115,200 bps async or a 10 Mbps TCP/IP interface. See Section 4 for more on developing your host interface.

The network manager initiates the session placing the host in a loop reading data and request records from network managers.

---

## About this Guide

These paragraphs detail topics discussed in each section:

### **Section 1 — Introduction**

Introduces the manual and provides customer support information.

### **Section 2 — Getting Started**

Covers the hardware configuration of the network, the physical port assignments on the network manager, and the logical port assignments.

### **Section 3 — Host-to-Network Manager Records**

Lists host-to-network manager records and other processing information from the host.

### **Section 4 — Network Manager-to-Host Records**

Contains network-to-manager records and other processing information, and status and error codes returned from the network manager.

### **Section 5 — EM611 Header Information**

Defines the EM611 IP framing structure.

The appendixes have several program examples and 4980-to-6980 conversion information.

---

## Related Publications

The following publications have information related to the 6980/6985 Network Manager.

*6980/6985 Network Manager User's Guide*

P/N: 961-055-003

*Norand<sup>®</sup> 6920 Communications Server Installation Guide*

P/N: 962-055-005

*Norand<sup>®</sup> 6920 Communications Server User's Guide*

P/N: 961-021-014

*Norand<sup>®</sup> 6920 Communications Server Reference Manual*

P/N: 977-021-001

---

## Customer Support

### **Customer Response Center**

The Customer Response Center (technical support) telephone number is 800-755-5505 (U.S.A. or Canada) or 425-356-1799. The facsimile number is 425-356-1688. Email is [support@intermec.com](mailto:support@intermec.com).

If you email or fax a problem or question include the following information in your message: your name, the company name and address, phone number and email to respond to, and problem description or question (the more specific, the better). If the equipment was purchased through a Value-Added Reseller (VAR), please include that information.

### **Factory Service**

If your unit is faulty, you can ship it to the nearest authorized Service Center for factory-quality service. The addresses and telephone numbers are included in the Warranty Card shipped with your product.



## Web Site

The Customer Support File Libraries, including Hot Tips and Product Awareness Bulletins, are available on the Internet. New users start at the Intermec web site: <http://corp.intermec.com>. Choose “Support,” then “Product Support,” then “Conference Area.” Look on the main page for a link to register new customers.

A PDF version of this manual is available at:

<http://corp.intermec.com/manuals/english.htm> or choose “products,” “manuals,” “english” via the home page.

## Bulletin Board Service

The Customer Support Bulletin Board (BBS), maintained by the Intermec Technologies Corporation, provides software and documentation:

**Phone number:**

319-369-3515 (14.4 Kbps modem)

319-369-3516 (28.8 Kbps modem)

**Protocol:**

Full duplex, ANSI or ANSI-BBS; 300 to 28,800 bps; v.32bis; 8 bits, no parity, 1 stop bit. *For high-speed modems, disable XON/XOFF and enable RTS/CTS.*

This is the same location available via the internet site. If you have high-speed access, the web interface provides a faster response.



# Getting Started

---

## Modem Support

The 6980/6985 Network Manager supports a number of Hayes-compatible configuration and autodial modem types. Support provided is subject to changes made in the modem interface by the modem vendor.

---

## Error Codes

Error codes via the LED display and Power-Up Self-Test errors are located in the *6980/6985 Network Manager User's Guide* (P/N: 961-055-003).

---

## Enhancements

The network manager provides a number of new features:

### **File support**

The network manager allows the host computer to download a limited number of files that can be stored on the network manager compact flash. These files can include customer data files, which can be forwarded to a hand-held computer at the direction of the host computer; or boot files, which can boot a hand-held computer independently of the host computer. The host may upload or delete data or boot file from the network manager.

### **Line disciplines**

The network manager supports a variety of line disciplines, including Norand TTY, Async, and Norand<sup>®</sup> Portable Communications Protocol (NPCP).

### **Autodial/Autoanswer** (*Future release*)

Ports on the network manager can be toggled as either autodial or autoanswer. A timeout can be specified for autoanswer ports.

### **Data Record Length**

The network manager data record length is 256 bytes for Async or 256 or 1024 for IP, not including channel and record type bytes. The 4980 data record length is 256 bytes.

### **Booting Hand-Held Computers**

Boot files can be downloaded from the host into a "DATA" directory in the 6980 Network Manager CompactFlash flash.

### **Modifying System and Port Configurations**

The network manager system and port configurations can be modified using the 6980 Web Interface. See the *6980/6985 Network Manager User's Guide* for details.

## Communication Session

The 6980/6985 Network Manager uses the host-to-hand-held computer communications sessions. The network manager provides the physical connection for the communications session and maintains the session on a logical channel.

A logical channel between a hand-held computer and the host computer will always pass through a network manager. All data sent to the host from a network manager is prefixed by a device ID and logical channel identifier.

Table 2-1 summarizes the communication abilities of each of the hand-held computer types in specific environments. Other environments may be possible with special adapters.

Table 2-1  
**Network Manager Environments**

Hand-Held Computer Type	Protocol Option	Environment
4000/6000 Series	TTY	Modem (single dock)
	NPCP	Single or multidock directly-connected to a network manager
601 and 602 (DOS only)	TTY	Modem (single dock)
	NPCP	Single or multidock directly-connected to a network manager

► **NOTE:**

*The network manager supports only full-duplex modems.*

As an example, Table 2-1 indicates that a 4000 or 6000 Series hand-held computer can communicate using TTY or NPCP. If NPCP is used, the hand-held computer must be in a dock which is directly cabled to a network manager.

The network manager minimizes the differences between Norand hand-held computers. After the physical connection is established, the communications sessions for all of the hand-held computer types are identical.

The communication session for a hand-held computer, currently, consists of:

- An “upload” file transfer from hand-held computer to host computer.
- A “download” file transfer from host computer to hand-held computer.
- An “end-of-session” from the hand-held computer.

Typically, the hand-held computer sends identification information in the first upload record, which can be used by the host to tie a specific set of download data files to the unique route or driver assigned to that particular hand-held computer. This download part is optional.

**EXAMPLE:**

The host receives upload records from a hand-held computer, on a device ID and logical channel, until the upload is complete. After the upload is complete, the host receives download data requests, on the same device ID and logical channel, for the hand-held computer. The host responds with download data until finished, then an end-of-data record is sent. The host then receives an end-of-session record with the hand-held computer session status.

The user must be aware of hand-held computer differences in the INTERMEC Wide Area Network (WAN) to make the correct physical connection to a given remote site.

See the *6980/6985 Network Manager User’s Guide* for a table that specifies the possible configurations for network manager ports and the environments to which the ports can connect.

## Network Configurations

Each 6980/6985 Network Manager is treated as a unique connection to the host application allowing a single host application to simultaneously communicate with several network managers. The 6980/6985 Network Manager, using NPCP as its main connection protocol, allows the host to make a high speed connection to each network manager.

This type of configuration allows for a simple migration from a 4980 Communications Controller to a 6980 Network Manager. See Section 5 to learn about the 6980 NPCMux application.

See the *6980/6985 Network Manager User's Guide* for sample configurations. Contact your account representative for more detailed information.

## Physical Ports

The 6980 Network Manager has five possible physical ports for client connections. The 6985 Network Manager has one physical port.

Table 2-2  
**Physical Ports for Client Connections**

Physical Port	Hardware Type	Supported Client Protocol	Logical Channels
<b>6980 Network Manager</b>			
Port A1	RS-485 Connections	NPCP	1-5
Port A2	RS-485 Connections	NPCP	1-5
Port B1	RS-232 Connections	TTY	1
Port B1	RS-232 Connections	TTY	1
Port C1	PC Card Modem	TTY	1
<b>6985 Network Manager</b>			
Port A1	RS-485 Connection	NPCP	1-5

The 6980 Network Manager configuration connects with a maximum of 13 handheld computer (client) channels simultaneously. The 6985 Network Manager connects with a maximum of 5 channels. Thus, when a network manager is communicating to a host computer, clients will send their upload and receive their download on 1 of 5 or 13 possible logical channels. There is no correlation between what logical channel is assigned to a client and the physical port the client communicates on.

The network manager, pending its configuration, has a "pool" of channels individually assigned to client connections. The client uses its assigned channel to communicate its upload and receive its download. When the client ends its session, the channel is returned to the pool for reuse.

---

## Logical Channels

Records from the network manager specific to a port (such as Activate Requests) always use the logical channel which equates to the logical port ID. After the physical connection on a port is established, data to or from a client is sequential on a logical channel, and the location of the logical channel should not concern the host programmer.

---

## Compact Flash

The 6980 Network Manager stores Windows CE, Web Server, FTP Server, 6980 protocols, and hand-held computer applications on the compact flash within. The compact flash can be viewed using FTP (either command line or through a browser) and has a “cfata” folder.

Removing or editing files on the compact flash can cause the network manager to fail. Under some extreme circumstances, the network manager may not be recoverable. In these extreme cases, the CompactFlash Card must be reimaged.

The compact flash has the following folder structure:

<u>Folder Name</u>	<u>Description</u>
\cfata\Websrv	Contains all the Web Server pages and the location of the configuration file for the network manager (6980CE.INI).
\cfata\6980	Location of the 6980 application that provides host and client communication protocols.
\cfata\6980\data	Location for all locally stored client boot applications and download request data files.
\cfata\UpdFiles	Overrides any Kernel resident files. At cold boot, any file in this directory is copied to the “\Windows” folder and the system is warm-booted. Only Kernel-level files reside in this directory.
\cfata\AppFiles	Location to store any new applications that may run in the “\Windows” folder (known as the “object store” in Windows CE) once the network manager is started.

Some of the important files which reside on the network manager:

<u>File Location\Name</u>	<u>Description</u>
\cfata\boot.ini	A file containing a list of applications to start when the network manager is started.
cfata\Websrv\6980ce.ini	Configuration file for the network manager (normally modified using Web Pages (see the <i>6980/6985 Network Manager User’s Guide</i> for details).
cfata\Websrv\6980ini.def	Default configuration file for the network manager (this file returns the network manager to its factory default).

## Device Channel Option

Each record from the network manager is preceded by a device ID, a logical channel identifier, and a record type field.

There are eight host-to-network manager record types. Some are request records which require a response from the host computer. Each record from the host computer is preceded by a record type field. There are six host-to-network manager record types.

► **NOTE:**

*IP-based communications require a 6-byte header prefixed to each record. See Section 5 for EM611 IP Header information.*

The first data the host will receive on the new device channel is an identification record. That record contains a user-defined ID and configuration information about the remote network manager. Device channels require the host to index state variables and file variables by device and hand-held computer channel number.

All records from the 6980 Network Manager are preceded with a device number and channel number.

The partial record layouts illustrate the differences in the logical channel options:

EM311 for 4980 Series Communications Controller:

Position 1	Device channel disabled ( <i>optional</i> )
Position 2	Hand-held computer channel
Position 3	Record type
Position 4+	Type-dependent

EM311 for 6980/6985 Network Manager:

Device channel enabled:

Position 1	Device channel
Position 2	Hand-held computer channel
Position 3	Record type
Position 4+	Type-dependent





# Host-to-Network Manager Records



The file transfer protocol between the network manager and host is implemented with six host-to-network manager record types.

This section explains the function of each host-to-network manager record type.

---

## **EM311 Protocol Interface**

Each record sent from your host must have a record type field. There may be eight record types sent from your host to the network manager.

This explains the function of each record type. Actual record layouts appear after the record description starting on page 3-2.

Each record from an async host must begin with a one-byte beginning-of-record delimiter (a slash “/”) and a one-byte command code (ASCII) “0” through “7”.

The host sends records in response to requests from the network manager, except for the initialization record. The initialization record is sent to activate an inactive network manager.

The host may also send two special commands to the network manager, a question mark “?” and an asterisk “\*”. A question mark indicates the host is ready to receive data and serves as an acknowledgement record. The asterisk resets the network manager, although the network manager will reset itself if the host issues an invalid record or fails to respond within the host timeout period.

The record includes an end-of-record delimiter, by default <CR> , which is configured in the initialization record.

Data records from the host (not including special commands) must be of the same fixed-length, and may include end-of-line pad bytes. The network manager uses the initialization record sent from the host to determine record size and end-of-line pad lengths. IP-based communications have a 6-byte header prefixed to each record. See Section 5 for EM611 header information.

## Record Types

This section specifies the record types for the Async host interface. For IP-based interfaces, an EM611 header *must* prefix all records sent to a 6980 Network Manager.

Table 3-1  
*Host-to-Network Manager Records*

Record ID	Type	Description
0	Download Data	The host sends download data records in response to a download request. Information obtained from upload data links download data with a specific hand-held computer on a logical channel.
1	End-of-data	The host sends end-of-data records in response to a download request from the network manager. This indicates that no more download data exists for this session. End-of-data records are also sent in response to a file request to terminate file processing.
2	Initialization	An initialization record is sent at the beginning of a host/network manager session to set the system mode parameters and default port activation parameters.
3	Activate autoanswer	The host sends an activate record in response to a request record. If the record contains a phone number parameter, an autodial is attempted, else the port is configured for autoanswer. Nonswitched (direct) connections are considered to be autoanswer.
4	Activate autodial	The host sends an activate record in response to a request record. If the record contains a phone number parameter, an autodial is attempted, else the port is set to autoanswer. Nonswitched (direct) connections are considered to be autoanswer. The network manager processes autoanswer and autodial activate records identically. A hand-held computer port can be defined as TTY. The activate record specifies the protocol type (TTY) to use for the next connection.
5	Deactivate for one minute	Deactivate records can postpone activating a port for one minute. Causes a delay between phone number dials or implements an activation window for a port.
6	Host Directive	The host sends a directive in response to a special or download data request from the network manager. Six subtypes of host directives are available: <ul style="list-style-type: none"> <li>▶ Types 1–3 manage user data files.</li> <li>▶ Type 4 sends download data to a hand-held computer.</li> <li>▶ Type 5 deactivates a request, and</li> <li>▶ Type 6 cancels file processing.</li> </ul>







## System Mode Parameters

The network manager configuration can be customized using system parameters. `-S[system mode]`

The system mode is a 1- to 5-digit numeric (base 10) field adjusting the operational mode for the network manager. Mode parameters have a value and are turned on by *adding in* the values for each specific mode.

These parameters are supported in the initialization record:

```
/* defined bits in "S" record mode */
/* system mode parameters */
/* LABEL          DECIMAL    BINARY    */
MODE_OFF          0          /* 0000 0000 0000 0000 */
RMT_ID_ON         64          /* 0000 0000 0100 0000 */
FILES_ON          128         /* 0000 0000 1000 0000 */
```

Table 3-5  
System Mode Parameters

Value	Meaning	Description
8	Boot 4000 Series in a LAN connected to network manager.	Enabled when a LAN port is installed and a list of boot files exists on the network manager's system disk.
32	2-byte channel option.	All records to host are preceded by a 2-byte channel identifier. <i>(Required)</i>
64	Remote ID on.	Forward ID from remote controller to host. <i>(Required)</i>
128	Network manager file processing.	When added in, the host is prompted with file requests at the beginning of a host-network manager communications session.
512	Local ID on.	Forward ID from remote controller to host. <i>(Required)</i>

## Host Parameters

The network manager's host parameters can be customized in the initialization record.

Table 3-6  
Host Parameters

Parameter	Default	Description
-C[parity]	0	1 digit numeric field setting parity and number of data bits. Valid values are: "0" = No parity/8 data bits (-C0) "1" = Odd parity/7 data bits (-C1) "2" = Even parity/7 data bits (-C2)
-D[stopbits]	1	1 digit numeric field setting stop bits. Valid values are: "1" = One stop bit (-D1) "2" = Two stop bits (-D2) "3" = Three stop bits (-D3)
-E[delimiter]	13	1- to 2-digit numeric field specifying collating sequence number of character marking end of all records sent from network manager to host. A delimiter of "0" specifies no end-of-record delimiter.
-B[block size]	0	Numeric field ranging from 256 to 4906 (multiples of 256 — 256, 512, 1024, 2048, or 4096); specifies the minimum network manager-to-host record block size. Does not include the end-of-record delimiter character. Records shorter than the block size are padded to the block size and the delimiter character is appended. Forces network manager to send fixed-length blocks to the host.
-G[pad char]	32	1- to 3-digit numeric field specifying the characters that pad short blocks when a minimum block size is specified.
-H[ready char]	63	1- to 3-digit field specifying the host "ready" directive.
-I[read timeout]	30	2- or 3-digit numeric field specifying the maximum seconds the network manager waits for a response from host. If no response received within set time, the network manager will reset and await an initialization record from the host. Valid values are 10 to 120.
-J[host-delay]	0	1- or 2-digit numeric field specifying delay in hundredth of seconds before network manager sends next message to host after receiving a ready character from host. Valid values are 0 to 50.
-K[char-gap]	10	1- or 2-digit numeric field specifying maximum intercharacter gap time in whole seconds allowed in a block of data sent from host. Valid values are 9 to 40.
-L[cts-gap]	5	1- to 3-digit numeric field specifying maximum time in tenths of seconds the network manager waits for CTS after RTS. Valid values are 0 to 100.

**EXAMPLE:** /2-E0-I60-K30/









## Host Directive (Type 6)

The host sends a directive in response to a special download data request from the network manager. Five subtypes of host directives are available. Types “1”, “2”, and “3” manage user data files. Type “4” sends download data to a hand-held computer and type “6” cancels file processing.

Table 3-10  
Type 6 — Host Directive Record

Position	Bytes	Description
1	1	Beginning delimiter: “/”
2	1	Command code: “6”
3	1	Directive type: “1” - “4,” and “6”: “1” = File upload directive “2” = File create or load directive “3” = File delete directive “4” = File download directive “6” = File processing abort
4	256	Directive information. The information required for this field depends on the directive type used.
259+		Optional pad up to 5 bytes

If file processing is enabled using the system mode parameter in the initialization record, the host will receive file requests from the network manager at the beginning of a host-to-network manager session and after the host acknowledges a network manager Directive Status Record. These requests can have one of several host directives.

► **NOTE:** *The network manager sends a directive status to the host immediately after completing a host directive.*

The host sends a directive record only during the file processing phase of a communication session. This record requests information from the network manager or file uploads with the network manager.

A host directive may be sent by the host in response to a special request from the network manager. Types “1” to “3” manage user data files (or hand-held computer boot files) stored on the network manager. (If file processing, a system mode parameter is enabled and the host is prompted with file requests at the beginning of a host-to-network manager session.) Type “4” sends a file stored on the network manager to a hand-held computer requiring download data.

► **NOTE:** *For all of the following examples, asterisks indicate spaces in commands. Complete commands may not be shown. “6980” is short for “6980 Network Manager.”*

### File Upload Directive “1”

The host sends an upload directive, in response to a file processing special request, to upload a file stored on the 6980/6985 Network Manager (usually the directory file).

Table 3-11  
File Upload Directive “1”

Position	Bytes	Description
1	1	Beginning delimiter: “/”
2	1	Command code: “6”
3	1	Directive Type: “1”
4	8	DOS compatible filename, left-justified
12	3	DOS compatible filename extension, left-justified
15	245	Filler bytes (ASCII space)

**EXAMPLE:** /61FILENAMEEXT. .xxxxppppp<CR>

Host Computer		6980	Description
	<————	0161	File Processing Request
/61FILENAMEEXT. .xxxxppppp<CR>	————>		Upload Directive
	<————	010xxx...	File Header Information
?	————>		Host Ready
	<————	010xxx...	Upload Data
?	————>		Host Ready
	<————	010xxx...	Upload Data
?	————>		Host Ready
	<————	011	End Upload Data
?	————>		Host Ready
	<————	01710	Status Record
?	————>		Host Ready
	<————	0161	Next File Processing Request

► **NOTE:** *IP-based structures have length information prefixed to each record between the network manager and the host computer.*  
For example: IP/61FILENAMEEXT. . .xxxxppppp<CR>

### File Create or Load Directive “2”

This directive is sent, in response to a file processing special request, to create a data file on the network manager. This must contain a user data file directory entry with filename and user-defined information. The file is saved on the CompactFlash storage card. After the network manager receives a create directive, it sends the host data request records. The host then sends data records until all the data is sent. An end-of-data record from the host marks the end of data for the file.

Table 3-12  
File Create or Load Directive “2”

Position	Bytes	Description
1	1	Beginning delimiter: “/”
2	1	Command code: “6”
3	1	Directive type: “2”
4	8	DOS compatible filename ( <i>required</i> )
12	3	DOS compatible file extension ( <i>required</i> )
15	6	Date field (YYMMDD)
21	4	24-hour time (HHMM)
25	2	User-defined filler
27	1	User-defined file type “0” or blank indicates a hand-held computer boot file.
28	1	Filler ( <i>should be zero-filled 0x30</i> )
29	1	File status: “0” = Good “1” = Undefined “2” = Deleted “3” = System
30	6	File size (in ASCII digits) <i>required</i>
36		Filler bytes

**EXAMPLE:** /62FILENAMEEXTdddddtttff000123456ppppp<CR>

Host Computer		6980	Description
	<————	0161	File Processing Request
/62FILENAMEEXTdddddtttff000123456ppppp<CR>	————>		Create/Load Directive
/0<data>	<————	012	Download Request
	————>		Data Block
/0<data>	<————	012	Download Request
	————>		Data Block
/1	<————	012	Download Request
	————>		End of Data Record
?	<————	01720	Status Record
	————>		Host Ready
/1	<————	0161	Next File Processing Request
	————>		End of Data Record
			(no more files — end file processing)

### File Delete Directive “3”

A file delete directive may be sent in response to a file request to delete a user data file from the network manager user file directory.

► **NOTE:** A directive status record (type 7) goes to the host immediately after a host directive is completed.

Table 3-13  
File Delete Directive “3”

Position	Bytes	Description
1	1	Beginning delimiter: “/”
2	1	Command code: “6”
3	1	Directive type: “3”
4	8	DOS compatible filename ( <i>required</i> )
12	3	DOS compatible file extension ( <i>required</i> )
15	245	Filler bytes

**EXAMPLE:** /63FILENAMEEXT. .xxxxppppp<CR>

Host Computer		6980	Description
	←	0161	File Processing Request
/63FILENAMEEXT. .xxxxppppp<CR>	→		Delete Directive
	←	01730	Status Record
?	→		Host Ready
	←	0161	Next File Processing Request

### File Download Directive “4”

The host sends this record type in response to a request for download data from a computer. After receiving a download directive, the network manager opens the file specified and downloads it to the computer. The network manager must contain this file (created with File Create).

Table 3-14  
File Download Directive “4”

Position	Bytes	Description
1	1	Beginning delimiter: “/”
2	1	Command code: “6”
3	1	Directive type: “4”
4	8	DOS compatible filename ( <i>required</i> )
12	3	DOS compatible file extension ( <i>required</i> )
15	245	Filler bytes

**EXAMPLE:** /64FILENAMEEXT. .xxxxppppp<CR>

<u>Host Computer</u>		<u>6980</u>	<u>Description</u>
	<————	0161	File Processing Request
/64FILENAMEEXT. .xxxxppppp<CR>	————>		Download Directive
/0<data>	<————	012	Download Request
	————>		Data Block
/0<data>	<————	012	Download Request
	————>		Data Block
/1	<————	012	Download Request
	————>		End of Data Record
?	<————	01720	Status Record
	————>		Host Ready
/1	<————	0161	Next File Processing Request
	————>		End of Data Record

(no more files — end file processing)

### File Processing Abort "6"

The host sends this directive to inform the network manager that a file error occurred on the host. If currently downloading or creating a file on the network manager, the network manager responds by deleting the current file being created or downloaded. Telecommunications then begins with the hand-held computers. *Hand-held computer cold-starts are not possible in a locked file system.* Files unlock after a successful file processing session.

Table 3-15  
File Processing Abort "6"

Position	Bytes	Description
1	1	Beginning delimiter: "/"
2	1	Command code: "6"
3	1	Directive type: "6"
4	256	Filler bytes

**EXAMPLE:** /66. . .xxxxppppp<CR>

<u>Host Computer</u>		<u>6980</u>	<u>Description</u>
	<—	0161	File Processing Request
/62FILENAMEEXTddddddttttff000123456ppppp<CR>	—>		Create/Load Directive
	<—	012	Download Request
/0<data>	—>		Data Block
	<—	012	Download Request
/66. . .xxxxppppp<CR>	—>		Processing/Abort Directive
	<—	01760	Status Record
?	—>		Host Ready
	<—	0161	Next File Processing Request



## Special Commands

The host may send two special commands to the network manager. Records from the host, except for the special commands, must all be of the same fixed-length, and may include end-of-line pad bytes.

IP-based commands must also have a prefixed record length field attached.

### Type ? — Host Ready Command

The host sends this record to the network manager when ready to receive data. This command can be changed to a different value using the `-H` parameter in the initialization command.

Table 3-16  
Type ? — Host Ready Command

Position	Bytes	Description
1	1	Question mark “?”

**EXAMPLE:** (CR = end of record marker)  
?<CR>

### Type \* — Reinitialization Command

The host sends this record to reset the network manager when the network manager is expecting a ready command.

Table 3-17  
Type \* — Reinitialization Command

Position	Bytes	Description
1	1	Asterisk “*”

**EXAMPLE:** (CR = end of record marker)  
\*<CR>

**EXAMPLE 1:** This is a sample of file processing when the files on the target 6980 Network Manager are up to date with the 6920 Communications Server files.

<u>6920</u>	<u>6980</u>	<u>Description</u>
	←	Connection Request
	→	Reply to Socket
	←	018CE6980... Controller ID Record
/2*-D1*-S744..	→	Initialization Record
?	→	Host Ready
	←	0161 File Processing Request
/61NCDIR***NCC	→	Upload Directive: NCDIR.NCC
?	→	Host Ready
	←	010NETRPL**LST000124 . Uploads NCDIR.NCC
?	→	Host Ready
	←	01710 Host Directive Status Record
?	→	Host Ready
	←	0161 File Processing Request
/63NETRPL**LST	→	Delete Directive: NETRPL.LST
?	→	Host Ready
	←	01730 Host Directive Status Record
?	→	Host Ready
	←	0161 File Processing Request

With no files to download, 6920 sends down a directive to create the NETRPL.LST file.

/62NETRPL**LST0..	→	Create Directive: NETRPL.LST
?	→	Host Ready
	←	012 Download Request
/0APP*****EXE	→	Data block for NETRPL.LST
?	→	Host Ready
	←	012 Download Request
/1	→	End of Data Record
?	→	Host Ready
	←	01720 File Directive Status
?	→	Host Ready
	←	0161 File Processing Request
/1	→	End of Data Record
?	→	Host Ready
	←	014 Tcom may begin with clients
?	→	Host Ready

**EXAMPLE 2:** In this sample, the 6980 Network Manager does not have any files in the Data directory; the 6920 Communications Server must create the necessary files. Note that the NETRPL.LST file has to be created for 4000 boot files, not for 6xxx files.

<u>6920</u>		<u>6980</u>	<u>Description</u>
	<—	018CE6980**000124105 .	Controller ID Record
/2*-D1*-S744*-. . .	—>		Initialization Record
?	—>		Host Ready
	<—	0161	File Processing Request
/61NCDIR***NCC	—>		Upload Directive: NCDIR.NCC
?	—>		Host Ready
	<—	010NETRPL**LST000124 .	Uploads NCDIR.NCC
?	—>		Host Ready
	<—	01710	File Directive Status
?	—>		Host Ready
	<—	0161	File Processing Request
/62NETRPL**LST0 . .	—>		Create Directive: NETRPL.LST
?	—>		Host Ready
	<—	012	Download Data Request
/0APP*****EXE	—>		Data Block for NETRPL.LST
?	—>		Host Ready
	<—	012	Download Data Request
/1	—>		End of Data Record
?	—>		Host Ready
	<—	01720	File Directive Status
?	—>		Host Ready
	<—	0161	File Processing Request
/62APP*****EXE99 . .	—>		Create Directive: APP.EXE
?	—>		Host Ready
	<—	012	Download Data Request
/0[INI]..Version=1..—>	—>		Data Block for APP.EXE
?	—>		Host Ready
	<—	012	Download Data Request
/1	—>		End of Data Record
?	—>		Host Ready
	<—	01720	File Directive Status
?	—>		Host Ready
	<—	0161	File Processing Request
/1	—>		End of Data Record
?	—>		Host Ready
	<—	03C	Begin of Call (tcom starts)



# Network Manager-to-Host Records



The file transfer protocol between the network manager and host is implemented with eight network manager-to-host record types.

---

## Record Formats with 2-byte Channel ID

Network manager-to-host record types implement the file transfer protocol and status information between the network manager and the host. A 2-byte channel ID is always activated.

There may be nine status and request record types sent from the network manager to your host that require a response from your host.

Records from network manager-to-host use a 2-type channel ID that consists of a 1-byte “device channel” field and a 1-byte “Hand-held computer channel” field. Hand-held computer channels belong to the active device on the corresponding device channel.

Device channel “0” is reserved for the network manager direct-connected to the host.

The record formats with the 2-byte channel option are the same as 1-byte channels. The difference is that the device channel ID is attached to the beginning of each record.

Device channels are for remote network managers. The record formats for the 2-byte channel option are the same as the 1-byte channel option except that the device channel ID is prepended to each record from the network manager.

The 2-byte channel ID format, required for the 6980/6985 Network Manager, is shown in Table 4-1.

*Table 4-1*  
**2-Byte Channel ID**

<b>Position</b>	<b>Bytes</b>	<b>Description</b>
1	1	Device ID (Hex): “0x31”
2	1	Hand-held computer Channel ID (Hex): 0x30–0x3E
3+		Records defined below starting at position 2.

## Record Types

This section specifies the record types for Async host interfaces. An EM611 header is prefixed on all records sent from a 6980 Network Manager for IP-based communications. See Section 5 for EM611 header information.

*Table 4-2*  
**Network Manager-to-Host Record Types**

<b>Record ID</b>	<b>Type</b>	<b>Description</b>
0	Upload Data	The hand-held computer sends contiguous upload data records to the host on a logical channel.
1	End of Session Status	Indicates the status of a single hand-held computer session. Each hand-held computer sends an end-of-session record as its session ends. See page 4-4.
2	Data Request	The hand-held computer sends a download data request to the host. The host sends back a download data record, an end-of-data or a download file directive.
3	Inactive Status	This record indicates the status of a logical port. The host port uses inactive status records as time-fill records whenever it is idle. The host program discards or ignores these records.
4	Active Status	Active status records indicate a logical port status. The host port uses active status records as time-fill records whenever it is idle. The host program discards or ignores these records.
5	Activation Request	The host activates a port using the activation request records. Requests are sent for an enabled port whenever the port disconnects. The prior connection status for the port is also in the request record. The host responds with an autodial record, autoanswer activate record, or a deactivate-for-one-minute record.
6	Special Request	Special request records group a variety of special records into one record type. A subtype field determines the actual request type. There are two subtypes specified, see Table 4-12 on page 4-8.
7	Directive Status	The network manager sends directive status records to the host after completing a host directive (with or without error). See page 4-9.
8	Identification	The network manager sends an ID record to the host at the beginning of each session with a remote network manager. The ID record serves two purposes. It identifies the just connected remote network manager, and it opens a new device channel. See page 4-1.
C	Begin of Call	Sent by the 6980 Network Manager to the host computer when a hand-held computer is about to begin a session.







## Data Request (Type 2)

Table 4-6  
Type 2 — Data Request Record

Position	Bytes	Description
1	1	Device channel ID: "1"
2	1	Hand-held computer channel ID (Hex): 0x30–0x3E
3	1	Record type = "2"

**EXAMPLE:** (CR = end of record marker)  
012<CR>

Device channel ID = 0  
Hand-held computer channel ID = 0x30h  
Record type = data request

## Inactive Status (Type 3)

Table 4-7  
Type 3 — Inactive Status Record

Position	Bytes	Description
1	1	Device channel ID: "1"
2	1	Hand-held computer channel ID (Hex): 0x30–0x3E
3	1	Record type = "3"

**EXAMPLE:** (CR = end of record marker)  
013<CR>

Device channel ID = 0  
Hand-held computer channel ID = 1  
Record type = Inactive Status

## Active Status (Type 4)

Active status records indicate a logical port status. The host port uses active status records as time-fill records whenever it is idle. The host program may discard or use these records to maintain real-time status information.

Table 4-8  
Type 4 — Active Status Record

Position	Bytes	Description
1	1	Device channel ID: "1"
2	1	Hand-held computer channel ID (Hex): 0x30–0x3E
3	1	Record type = "4"

**EXAMPLE:** (CR = end of record marker)  
014<CR>

Device channel ID = 0  
Hand-held computer channel ID = 0x30h  
Record type = Activate Status "4"

## Activation Request (Type 5)

Host activates the LAN port in response to activate request records. Network manager sends request to host to activate enabled port after start of session and after each port disconnect. Port's prior connection status is also in request record. Host should respond with record types "3" or "4."

Table 4-9  
Type 5 — Activation Request Record

Position	Bytes	Description
1	1	Device channel: "0"
2	1	Hand-held computer channel ID (Hex): 0x30–0x3E
3	1	Record type: "5"
4	1	For previous port activation status code and meaning, see Table 4-10 on the next page.
5	4	Reserved for diagnostic information
9	252	Required padding

**EXAMPLE:** (CR = end of record marker)  
015xyyy<CR>  
Device channel = 0  
Hand-held computer channel ID = 0x30h  
Record type = Activation Request "5"  
"x" = Previous activation status code  
"y" = Diagnostic information

An activation request record is sent to the host whenever a port is inactive. The request contains a status code indicating the state of the previous activation attempt or connection. The status codes are ASCII numeric characters and are listed in Table 4-10.

*Table 4-10*  
**Activation Request Status Codes**

<b>Code</b>	<b>Description</b>
0	Good
1	Abort. Port disconnect due to protocol error. Physical connection was lost.
2	No answer.
3	Modem configuration error or bad modem status.
4	Disconnect, line protocol error.
5	Bad activation parameter error.
6	Error activating port.
7	Autoanswer port timeout. If a timeout is defined for a hand-held computer port, and the timeout period expires with no activity, the port deactivates with a timeout status code.
8	Hand-held computer error.
9	Line busy.
: (colon)	Modem reported no dial tone.
; (semicolon)	Modem reported no carrier.
< (less than)	Call collision, modem reported ring

## Special Request (Type 6)

Special request records group a variety of special records into one record type. A subtype field determines the actual request type. Currently there is only one subtype defined.

Table 4-11  
Type 6 — Special Request Record

Position	Bytes	Description
1	1	Device channel ID: "0"
2	1	Channel ID: "1"
3	1	Record type: "6"
4	1	Special request subtypes and meanings in Table 4-12.

**EXAMPLE:** (CR = end of record marker)  
0161<CR>

Device channel = 0  
Channel ID = 1  
Record type = Special request  
Special request subtype = File processing request

Table 4-12  
Special Request Subtypes

Record ID	Type	Description
1	File request	File requests obtain file processing information from the host. The host responds with a file directive or an end-of-data record.
2	Deactivate Request (Async interface only; <i>not implemented</i> )	Deactivate requests are enabled using the network manager initialization record. When enabled, the network manager periodically sends a deactivate request to the host for each autoanswer port. The host then responds with a deactivate directive (yes or no).

## Directive Status (Type 7)

Network manager sends directive status records to the host after completing a host directive (with or without error).

Table 4-13  
Type 7 — Directive Status Record

Position	Bytes	Description
1	1	Device channel ID: "0"
2	1	Channel ID: "1"
3	1	Record type: "7"
4	1	Status type: "1" - "6": "1" = File upload "2" = File create or load "3" = File delete "4" = File download "5" = Reserved "6" = File processing abort
5	1	Directive status codes and meanings are in Table 4-14 on the next page.
6	3	Reserved for diagnostic information

**EXAMPLE:** (CR = end of record marker)  
 01710xxx<CR>

Device channel ID = 0  
 Channel ID = 1  
 Record type = Directive Status  
 Status type = File upload  
 Status = Good  
 "xxx" is reserved for diagnostic information

Currently, four types of file directives are implemented on the network manager. After a directive is completed, successfully or unsuccessfully, the network manager sends a directive status record to the host containing the directive type and a 1-byte status code. The status codes for the file processing directives are ASCII 1-byte characters (in hex) and are listed in Table 4-14.

Table 4-14  
Host File Directive Status Codes

Code (Hex)	Description
0x30	Good status
0x31	File open error.
0x32	File read error.
0x33	File write error.
0x34	The maximum number of files exceeded on a create operation.
0x35	The maximum number of open files exceeded on a file open operation.
0x36	File not found error.
0x37	Bad file handle (internal only).
0x38	File in use error. A file cannot be overwritten with a create operation or deleted while it is in use. This situation could occur if a file was used to boot a hand-held computer when the host attempted to recreate the file.
0x39	File not open error (internal only).
0x3A	File allocation error.
0x3B	End of file (internal only).
0x3C	File directory error.
0x3D	Request aborted.
0x3E	File system locked.

## Begin of Call (Type C)

This record is sent by the network manager to the host computer when a hand-held computer is about to begin a session.

Table 4-15  
Type C — Begin of Call Record

Position	Bytes	Description
1	1	Device channel ID: "0"
2	1	Channel ID (Hex): 0x30–0x3E
3	1	Record type: "C"

**EXAMPLE:** (CR = end of record marker)  
01C<CR>

Device channel ID = 0  
Channel ID = 0x30h  
Record type = Begin of Call

## Network Manager-Based File Processing

“File Processing” refers to a method of transferring from the host computer updated application and data files to a local or remote 6980/6985 Network Manager. These files are stored in the network manager’s CompactFlash storage card. The new files will overwrite or replace the existing files on the network manager. The total file size area is limited to 4 MB. The data files may contain files to boot hand-held computers, download data, or warm-boot files for hand-held computers using the File Server method.

To successfully implement file processing, you must:

- ▶ Understand the network manager disk directory structure and format of the NETRPL.LST control file, which can boot 4000 Series Computer in the LAN environment.

“Boot” is the industry jargon for bringing a computer to normal operating condition when it has been without power.

NETRPL.LST resides on the network manager and contains filenames needed for *booting* the hand-held computer. It is composed of 11-byte records with each containing two fields: an 8-byte filename and 3-byte extension. A blank record terminates the list of files.

When the *boot option* is in effect, the network manager attempts to send all files specified in NETRPL.LST to any hand-held computer trying to boot on the attached LAN.

Table 4-16

### NETRPL.LST File

Position	Bytes	Description
1	8	DOS-compatible filename (right-aligned, padded with spaces)
9	3	DOS-compatible filename extension

#### EXAMPLE:

There are three files contained in NETRPL.LST. Asterisks indicate spaces:

```
UPLOAD**DATRECORD**IDXCUSTDATAINF
```

- ▶ Implement host directive, special request, and directive status records on your host computer.
- ▶ Perform version checking of hand-held computer application software program changes done on the host computer against each hand-held computer for proper version numbers.
- ▶ Know how to download to hand-held computers, without a proper version, a “download request” file. The “download request” file must have the proper filenames located on the network manager.





## Section 5

# EM611 IP Header Information



The 6980 Network Manager communicates over IP to a host 6980 Network Manager or host communications program using a framing called EM611. This is an extension of an older Norand<sup>®</sup> framing structure called EM311. The new framing structure encapsulates the EM311 packet with a 6-byte header. EM611 is very similar to EM311 allowing 4980 users to modify their host application with minimal effort. EM611 also has an added feature that it can contain up to 8192 bytes of data, whereas the older EM311 record contained a maximum data block of 256 characters.

An EM611 packet has the following structure and definition:




Figure 5-1  
EM611 Structure and Definition

Table 5-1  
EM611 Packet and Header

Position	Abbreviation	Description
1, 2	LEN1, LEN2	Length of rest of EM611 frame. Length=(LEN1 * 256) + LEN2
3	CID	Controller ID (Virtual Controller channel for multiple 6980 support)
4	EM611	Version of EM611 packet frame. Current version is 0x01.
5, 6	RES1, RES2	Reserved for future use.

EM311 Records:

As defined in Sections 3 and 4.

EM611 Socket Number:

EM611 attempts to contact a host computer or host 6980 Network Manager using Socket Number **6980**.

► **NOTE:**

The above information was provided for customers building their own interface directly to the 6980 Network Manager. This information is hidden from customer's implementing the Inter-mec applications.

---

## Local 6980 Network Manager (NPCMux Functionality)

By putting a local 6980 Network Manager running 6980 Norand Portable Communications Multiplexer program (*NPCMux* for short), the host can interface to a single 6980 for a tiered architecture.

“6980 NPCMux” provides a common interface to communicate to local and remote 6980 Network Managers using NPCP. “6980 NPCMux” will allow customers and distributors to make minimal host application changes to implement the 6980 Network Manager in a LAN or WAN, obtaining the faster communication speeds without major impact to their current host communication program.

“6980 NPCMux” has three main functions:

- ▶ Provides a single interface to multiple 6980 Network Managers, allowing the host application to manage a single connection.
- ▶ Manages 6980 socket connections, limiting the quantity of connections for performance.
- ▶ Handling EM311 to EM611 packet conversion. This is needed at some level as every packet to multiple 6980s has the same structure, “Socket Manager” handles the mapping of connections to virtual devices for the host program.

To communicate directly to each 6980 Network Manager over IP, develop a host application that would:

- ▶ Use the EM611 packet structure.
- ▶ Provide multi-6980 functionality.
- ▶ Look for 6980 connections on Socket Port Number 6980.

Intermec Technologies Corporation provides a “6980 NPCMux” interface functionality which interfaces to one 6980 device. The *host 6980 Network Manager running “6980 NPCMux”* manages the multiple 6980 connections and provides a single interface to the host system.

In addition, “6980 NPCMux:”

- ▶ Provides the host system with EM611 frames with different EM611 Controller IDs and different EM311 Device IDs. Controller and Device IDs assist the host communication system in associating users with devices.
- ▶ Handles sending up End-of-Session records for any device that disconnects during active sessions.

## Host Interface to “6980 NPCMux”

The host-to-6980 NPCMux interface is done using the EM611 framing. However, the host system now has unique Controller and Device IDs for each connected 6980 device. The host application communicates to “6980 NPCMux” using the EM611 protocol (very similar to EM311 method).

There are a few new initialization commands important to “6980 NPCMux.”

Table 5-2  
6980 NPCMux Commands

Command	Bytes	Description
-D	nn	Number of remote concurrent 6980 sessions: 1–9
-F	n	File processing pass through enabled: “0” = Disabled (6980 System IDs are not passed to the host. All 6980 Network Managers have the same ID. This is for file processing.) “1” = Enabled (6980 System IDs are passed to the host.)
-B	nnnn	Data Block Size (default 256-data character) Version 1.0 allows 256, 512, 1024, 2048, or 4096 as the block size.

The EM311 records of the EM611 packet uses a 2-byte channel ID containing the device and channel.

- ▶ Device 0 is always the local 6980 NPCMux.
- ▶ Device 1 through *nn* are the remote 6980 IP connected controllers. Device ID distinguishes each 6980 device connected. Maximum devices are determined by Host Initialization Record. (–Dnn)

EM311 protocol records are outlined in Sections 3 and 4.

### EXAMPLE:

The initial handshaking between a host application and “6980 NPCMux” shows the EM311 portion of the EM611 packet generated by the NPCMux application to the host application.

Host Computer		NPCMux	6980	Description
/2 -D2 -F0 -B256	—>			Init Record
?	—>			Host Ready
.				Repeats 20-second cycles until first response.
.				Listens on configured socket for 6980 connections (default is port 6980).
			<—	Connect Request
	—>			Accept
			<— 018	Controller ID
1/2	<—	1018		Answer or Dial Record
	—>	/2		Init Record
			<— 016	Special Request
1/1	<—	1016		Answer or Dial Record
	—>	/1		Init Record
			<— 015	Inactive Record
1/3	<—	1015		Answer or Dial Record
	—>	/3		Init Record
		.		
		.		
		.		



## Appendix A

# 4980-to-6980 Conversion



The 6980 System Architecture is unique to the 6980 Network Manager, and an extension of the 4980 System. The architecture differences require that the host interface change to support the deployment of 6980 Network Managers into an existing 4980 System.

Some differences and their rationale are:

- ▶ 4980 Communications Controllers have a single host interface to remote controllers. 6980 Network Managers require an EM611 interface for each 6980 Network Manager. This change allows the AS/400 to communicate with multiple network managers concurrently.
- ▶ 4980 Communications Controllers supported Async and Bisync host connections. 6980 Network Managers support Async or TCP/IP connections. This change supports more popular Ethernet interfaces.
- ▶ Remote 498x Communications Controllers support required using multiple ADCCP channels through a locally connected 4980 Controller. Remote 6980 Network Managers support requires an IP connection back to a host application (or Host 6980 Network Manager) for each 6980 session. This allows the use of the PPP protocol made popular by remote Internet access users.

One of the major differences in the remote 6980-to-host system implementation is that 6980 Network Managers do not have to use a single host interface to communicate to remote 6980 Network Managers. Each network manager may have a unique host connection. This methodology provides increased flexibility in the 6980 Network Manager system architecture design and improves the efficiency in communicating with the hand-held computers.

However, it is a change that will affect host applications. Intermec Technologies Corporation has designed some interface applications for a local 6980 Network Manager and an AS/400 to assist in migration to the 6980 Network Manager.

This appendix is intended for two different purposes:

- ▶ Migration of existing 4980 Host Interface Architecture (primarily AS/400 accounts) to 6980 Architecture using an Intermec Technologies Corporation interface.
- ▶ Customization of interface.

Intermec Technologies Corporation has provided a program for all customers to use. This program can reside on a local 6980 Network Manager and is referred to as a “6980 NPCMux” application. This program has functionality which will have to be created in host applications.

## Communication and Application Diagram

Figure A-1 on the next page shows the architecture between a 6980 Network Manager and an AS/400. This figure describes each of the components, their functions, and areas addressed to simplify a 4980-to-6980 conversion.

A breakdown of the architecture into each of the areas, starting from the furthest component, is provided.




Figure A-1  
Architecture between 6980 Socket Manager and AS/400

## AS/400 or 4980 Conversion to 6980

The conversion sequence discussed below is done using all the areas discussed above, 6980 Network Manager, NPCMux application on a local 6980 Network Manager, the customer's host application, plus an additional piece of software provided by Intermec Technologies Corporation to take an additional step out of the host conversion.

### 4980 Interface on an AS/400

The 4980 Communications Controller was used on a Bisync interface on the AS/400. The 4980-to-AS/400 connection used a protocol or framing structure called EM315.

Most AS/400 users also used a single channel for each 4980 record sent to the host. This was referred to as a single channel ID record. This was the easiest and most common installation at AS/400 Systems.

## 6980 Interface on an AS/400

EM315 is very similar to the 4980 protocol or framing structure called EM311. When moving from the AS/400 Bisync interface (EM315) to a 6980 IP interface (EM611), the protocol or framing structure needs to be moved from EM315 to EM311.

► **NOTE:**

An additional AS/400 application referred to as Socket Interface provides the EM311-to-EM611 conversion and ASCII-to-EBCDIC conversion.

Figure A-2 shows the AS/400 programming architecture. Intermec Technologies Corporation provides “Socket Interface” to Local/Remote 6980 communications.




Figure A-2  
AS/400 Programming Architecture

The following changes were identified when moving from the 4980 Bisync interface to the 6980 interface using the “Socket Interface.”

- ▶ EM315-to-EM311 framing conversion. This means two primary changes:
  - A “/” precedes every command going to a 6980 Network Manager, except for the Host Ready character.
  - A “?” is sent by the host application after each record sent to the 6980 Network Manager. The “?” tells the network manager that the host is ready for the next read.
- ▶ An EM311 “Begin of Call” record type “C” is sent by the network manager to the host computer when a hand-held computer is about to begin a session.
- ▶ No double read needed to turn the line around. This was a Bisync protocol specific need.
- ▶ Need to move from a single channel ID to a 2-byte channel ID, on reads only. This means each block of data coming from the 6980 Network Manager has two bytes showing the device and channel. (Device 0 is always the local 6980 NPCMux Interface)
  - The host application now tracks current active routes by device and channel instead of by channel.

**EXAMPLE:**

When route 1234 starts uploading, you need to know what Device and Channel route 1234 started uploading on, so when Download Requests for the same Device and Channel begin, the correct route is located.

- ▶ New Initialization record parameters. These are shown earlier in this section. The Intermec socket currently supports the 256-, 512-, 1024-, 2048-, 4096-, and 8192-character block size.
- ▶ The “Socket Interface” example written by Intermec Technologies handles EBCDIC-to-ASCII translations.
- ▶ Instead of connecting to a Bisync port on the AS/400 for reads and writes, the host application reads and writes to two Dataques: one for input to the host application from the socket interface and the other for output to the socket interface.
- ▶ Host Application startup. When the host application starts up, the dataques should be cleared and initialized. The Intermec socket interface will put a “G” in the **DataqueIn** to inform the host application that it is ready to begin.
- ▶ Host application ending. If the host application wants to end, it should send an “E” to the **DataqueOut**.



# Adapting Programs Used with the 4980 Protocol Converter



A wide-area communications network based on the INTERMEC<sup>®</sup> 6980/6985 Network Manager can be configured to be functionally compatible with a network based on a Norand<sup>®</sup> 4980 protocol converter. Host programs designed to run with a 4980 Converter will require minimum changes, as specified below, to communicate with network managers running in a “compatibility mode.”

The required changes generally fall into the following categories:

### **Record types**

The network manager adds a number of new record types and the function of some of the old 4980 record types has changed.

### **Special commands**

### **Logical channels**

The network manager may have up to three logical channels per physical port.

### **New enhancements**

The network manager provides a number of new enhancements which may be enabled when the host is ready to support them.

The other major area of change is in the data record. The length of the data block has increased from 128 bytes to 256 bytes.

---

## **Record Types**

Record types for both the 4980 Controller and 6980/6985 Network Managers are listed in the following paragraphs. Differences (if any) in the way the records are used are noted.

### **4980 Record Types**

#### **Communications Controller-to-Host**

- |     |                    |     |                      |
|-----|--------------------|-----|----------------------|
| ▶ 0 | Upload Data        | ▶ 2 | Data Request         |
| ▶ 1 | End-of-call Status | ▶ 5 | Phone Number Request |

#### **Host-to-Communications Controller**

- |     |                |     |                                    |
|-----|----------------|-----|------------------------------------|
| ▶ 0 | Download Data  | ▶ 3 | Cancel Autodial                    |
| ▶ 1 | End-of-data    | ▶ 4 | Phone Number                       |
| ▶ 2 | Initialization | ▶ 5 | Deactivate autodial for one minute |

## 6980/6985 Record Types

### Network Manager-to-Host

#### 0 Upload Data

#### 1 End-of-session Status

End-of-session records are sent after each hand-held computer communications session completes to indicate the status of a single hand-held computer session. This differs from the 4980 end-of-call record which is sent after a port connection is lost to provide the status of the connection.

#### 2 Data Request

#### 3 Inactive Status

Inactive status records are sent to the host whenever a period of time expires without any activity on the host port. The status records indicate the status of the associated port.

#### 4 Active Status

See preceding Inactive Status record.

#### 5 Activation Request

Activation request records obtain the information from the host which is necessary to activate a port. Activation requests are sent for a physical port whenever the port is disconnected and include the status of the previous activate request for the port. The host may respond with an autodial activate record, an autoanswer activate record, or with a deactivate-for-one-minute record.

For compatibility, the activation request record can be processed exactly like a 4980 phone request record, with the following restrictions:

- ▶ No additional parameters are required if the correct default parameters are stored on the network manager system diskette.
- ▶ A 1-byte status field follows the record type in the activation request; this field indicates the status of the previous activation request. This status corresponds to the 4980 end-of-call status.
- ▶ Responding to an activation request with an autoanswer activate record corresponds to responding to a 4980 phone number request with a cancel-autodial record. However, the network manager continues to prompt the host with activate requests each time a port disconnects.
- ▶ Phone numbers must be formatted.

The following record types are not 4980-compatible, and are not sent to the host unless the associated options are enabled.

#### 6 Special Request

Currently, one subtype is specified:

##### 1 File Requests

#### 7 Directive Status

#### 8 Network manager Identification

#### C Begin of Call

## **Host-to-Network Manager Records**

### **0 Download Data**

### **1 End-of-data**

### **2 Initialization**

The initialization record supplies system configuration parameters.

► **NOTE:**

*To avoid host program changes, store initialization information in an easily-modified file.*

The initialization record determines the host computer's block size which includes a beginning-of-record delimiter, record types, data, and an optional "end-of-line" pad characters, such as a carriage return.

All records sent to the network manager must have the same size, with the exception of special commands. Any end-of-line pad, appended to records, and special commands sent to the network manager must be consistent.

### **3 Autoanswer Activate**

Autoanswer activate records are sent in response to an activate request and may include optional modem and port configuration parameters. The autoanswer activate record replaces the 4980 cancel-autodial record.

### **4 Autodial Activate**

Autodial activate records are sent in response to an activate request, and may include optional modem and port configuration parameters (for example, a phone number). The autodial activate record replaces the 4980 phone number record.

► **NOTE:**

*Autoanswer and Autodial Activate records are processed identically. The autoanswer type is provided for backward compatibility.*

### **5 Deactivate for One Minute**

The following record types are not 4980-compatible, and cannot be sent to the network manager unless the associated options are enabled.

### **6 Host Directive**

A host directive may be sent by the host in response to a special request or data request from the network manager. Currently, four subtypes of host directives

are specified:

- 1 File Upload
- 2 File Create/Load
- 3 File Delete
- 4 File Download

---

## Special Commands

The host may send two other commands with the preceding records to the network manager.

- ▶ The host must send a question mark (“?”) to the network manager to indicate that it is ready to receive data. The question mark can be changed to any other character (such as an XON character) with an initialization record parameter. Optional pad characters following the question mark must be consistent.
- ▶ The host may reinitialize the network manager by sending an asterisk (\*). This parallels sending a slash and an asterisk (/\*) to the 4980 Controller. The host must wait at least 30 seconds before sending another initialization record after sending the asterisk.

▶ **NOTE:** *The asterisk can be sent only when the network manager is expecting a question mark or before sending the initialization record.*

## Asynchronous Hosts



The 6980/6985 Network Manager offers several methods to provide flexible options for reading records from the network manager.

- ▶ An end-of-record delimiter can be added to the end of each record. The default delimiter is a carriage return (CR).
- ▶ The network manager can be configured to pad all records to a fixed block size. The pad character can be set by the host. The default is a blank.
- ▶ The host-ready character, a question mark by default, can be changed to any other character, such as an XON character.
- ▶ The data portion of an upload data record may contain transparent data if the port is configured for transparent mode. All other data sent to the host is guaranteed to be character data.
- ▶ The network manager reads the initialization record as 8-bit data, so that the host can set the parity for the host-network manager connection in the initialization record.


If the host is reading transparent data from the network manager, then the host cannot read to an end-of-record delimiter. This problem can be solved by padding all records to a fixed length. However, this is inefficient because of the extra length added to download requests.

As an alternative the channel ID and record type portion of each record can be read before the rest of the record is read. The host can then use a table, indexed by record type, to determine the number of bytes which remain to be read for the record.

Alternatively, the host can read a fixed number of remaining bytes for upload data records and read to an end-of-record delimiter for other record types.

▶ **NOTE:** *Some host communications drivers delete the entire contents of the communications buffer attached to a port when a read is issued on the port. A nondestructive read must be available to read a partial record from the network manager.*

**EXAMPLE:** Asynchronous Host to 6980/6985 Network Manager:



"?"	————>	
	<————	Channel 1 Inactive Status
"?"	————>	
	<————	Channel 1 Begin of Call
"?"	————>	
	<————	Channel 1 Upload Data
"?"	————>	
	<————	Channel 4 Begin of Call
"?"	————>	
	<————	Channel 4 Upload Data
"?"	————>	
	<————	Channel 4 Upload Data
"?"	————>	
	<————	Channel 2 Begin of Call
"?"	————>	
	<————	Channel 2 Upload Data
"?"	————>	
	<————	Channel 2 Active Status
"?"	————>	
	<————	Channel 3 Begin of Call
"?"	————>	
	<————	Channel 3 Upload Data
"?"	————>	
	<————	Channel 2 Upload Data
"?"	————>	
	<————	Channel 1 Download Request
Download Data	————>	
"?"	————>	
	<————	Channel 1 Download Request
Download Data	————>	
"?"	————>	
	<————	Channel 3 Upload Data
"?"	————>	
	<————	Channel 1 Download Request
End of Data	————>	
"?"	————>	
	<————	Channel 2 Upload Data
"?"	————>	
	<————	Channel 1 End Status
"?"	————>	
	<————	Channel 3 Download Request
End of Data	————>	
"?"	————>	
	<————	Channel 2 Download Request
Download Data	————>	
"?"	————>	
	<————	Channel 3 End Status
"?"	————>	
	<————	Channel 3 Activation Request
Activate Delay	————>	
"?"	————>	
	<————	Channel 2 Download Request
End of Data	————>	
"?"	————>	
	<————	Channel 2 End Status
"?"	————>	
	<————	Channel 2 Activation Request

# Pseudo Host Communications Program



You configure the 6980/6985 Network Manager by using one of the following methods:

- ▶ Initialization record parameters. The host sends this record at the beginning of a session.
- ▶ Activation record parameters. The host sends this record to activate a port.
- ▶ Control parameters stored in the 6980CE.INI configuration file accessible via a web server.

Configuring the network manager consists of:

### **Main Routine:**

Open Files

Initialize counters to 0 and port/channel states to inactive. (Note counters, state variables, etc. are indexed by channel)

Send Initialization Record to 6980/6985

While Not Finished

  If Async\_host

    Send ready character (e.g. "?") to the 6980/6985.

  Perform 4980\_Read.

  Determine device ID, logical channel, record type.

  If type equal Upload\_Data

    Perform Received\_Upload\_Data\_Routine.

  Else if type equal End\_Tcom\_Status

    Perform End\_Status\_Routine.

  Else if type equal Download\_Data\_Request

    Perform Download\_Data\_Routine.

  Else if type equal Inactive\_Status

    Display "port inactive" (or ignore)

  Else if type equal Active\_Status

    Display "port active" (or ignore)

  Else if type equal Activate\_Request

    Perform Activation\_Routine.

  Else if type equal Special\_Request

    Perform Special\_Request\_Routine.

  Else if type equal Network Manager ID

    Perform Remote\_6980/6985\_Logon.

  Else

    Perform Invalid\_Record\_Routine.

  Endif

End While Not Finished.

Close Files.

End of Program.

**End Main Routine**

***Upload\_Data\_Routine:***

If channel inactive

Save HHC ID from first upload record in save area for channel.

Reset upload sequence counter for channel.

Change channel state to "uploading."

Write upload record with channel/hand-held computer ID/sequence counter key.

Else

Increment upload sequence counter.

Write upload record with channel/hand-held computer ID/sequence counter key.

Endif.

Return.

**End Upload\_Data Routine.*****End\_Status\_Routine:***

Log final status of hand-held computer telecom session.

Reset channel status to inactive.

Return.

**End End\_Status Routine.*****Download\_Data\_Routine:***

If channel state is uploading

Log good status for upload.

Reset download sequence counters for channel.

Change channel state to downloading.

Endif.

If more download data for the hand-held computer

Send download data record.

Else

Send an end-of-data record.

Endif.

(Note: One way to associate download data with a hand-held computer is to maintain a "download request" file that contains a list of "download" files for each scheduled hand-held computer. The list of files may actually be a list of keys for indexed file systems.)

Return.

**End Download\_Data Routine*****Activation\_Routine:***

(Note that the hand-held computer channel number is the port number for activation requests.)

If a phone number is active on the port

Log the status of the phone number.

Store the phone number for possible retry later.

Endif.

Get the next phone number for the port type.

If a phone number is available for the port type

Send the phone number in the activation record.

Else if too soon to retry phone numbers

Send an activation\_delay record.

Else if no more phone numbers

Send the default (possibly blank) activation record for the port type.

Endif.

Return.

**End Activation\_Routine.**



***Special Request Routine:***

Display "No special requests are supported."

Send an end-of-data record.

**End Special\_Request\_Routine*****Remote\_6980/6985\_Logon:***

Send an initialization record for the remote 6980/6985

**End Remote\_6980/6985\_Logon**





**HHC (Hand-Held Computer)**

A generic acronym for a Norand Hand-Held Computer, including the 4000 Series (43XX, 44XX, 4500) and the PEN\*KEY or 6000 Series (61XX, 62XX, 63XX, 6400, 65XX, 66XX).

Also the trademark of another company.

**Host**

A customer's host computer.

A computer that provides services directly to users, such as the user's computer. In TCP/IP, an IP addressed device.

A large computer that serves many users, such as a minicomputer or mainframe.

**Host Computer**

A large computer that serves many users, such as a PC, minicomputer, or mainframe.

**Host Network Manager**

A 6980/6985 Network Manager that is functioning as a host to a secondary network manager.

**LAN (Local Area Network)**

A group of network devices in which each device can communicate through a wired or wireless link. The wired link may have several segments joined by repeaters and bridges. The LAN is characterized by the relatively short distance it is designed to cover, a high speed of operation, and relatively low error rates. The geographic scope of LANs is limited to thousands of feet or closely-spaced building complexes.

**Local Network Manager**

A network manager which is directly connected to a host computer. A local network manager uses either secondary ADCCP or ASYNC on its host port.

**Logical Port**

The host port on the controller is logically numbered 0. Port 0 is always the host port.

**NPCP (Norand Portable Communications Protocol)**

A Norand proprietary protocol that provides session, network, and datalink services for Norand hand-held computers in the Norand LAN environment used with printers and data communications.

**Physical Port**

Equates to port connector. The 4980 Controller has four internal physical ports ("A", "B", "C", and "D"). It also has six connectors ("A", "B", "C", "D", "LAN1", and "LAN2"). Ports "B", "C", and "D" are permanently attached to the 15-pin connectors labeled "B", "C", and "D" respectively on the back of the controller. Port "A" is attached to either the 15-pin RS-232 connector labeled "A" or to both of the two 9-pin RS-485 connectors labeled "LAN1" and "LAN2". Port "A" is attached to the RS-485 connectors when it is configured as a LAN port, otherwise it is attached to the RS-232 connector labeled "A."

**Port**

The physical hardware communication port.

(SNMP) Physically, an access point to a computer, multiplexer device, or network. Logically, a pointer to a TCP/IP application.

**Remote Network Manager**

The network manager which is logically farthest away from the host computer when two network managers are connected.

**Remote Port**

A TTY or NPCP port that can connect to hand-held computers or remote network managers. Data channels on remote ports are multiplexed onto the host port.

**Remote Subnet**

An Ethernet segment other than the distribution LAN. For Enterprise OWL, the remote subnet is the Ethernet link of the access point that attaches to the super root through an IP tunnel.

**TCOM or Telecom**

Telecommunications.

**Terminal**

Circuit terminating device such as a hand-held computer.

(ADK) Portable elements in the radio data network. Provide a wireless portability with two-way interactive data communication capabilities.

**TTY**

Norand two-way TTY asynchronous data link protocol.



# General Index

## NOTE:

This index covers all topics. Those in italics are figures, those in bold are tables.

## NUMBERS

2-byte channel ID, network manager-to-host record formats, 4-1  
4980 Series Communications Controller, EM311, 2-5  
6980 Network Manager, physical ports, **2-3**  
6980/6985 Network Manager, EM311, 2-5  
6980CE.INI, 2-4, D-1  
6980INI.DEF, 2-4

## A

Abort  
  activation request status code, **4-7**  
  status code, **4-4**  
Activate Autoanswer, host-to-network manager record, description of, **3-2**  
Activate Autodial, host-to-network manager record, description of, **3-2**  
Activation Request  
  4980 protocol converter, B-2  
  network manager-to-host record  
  4980 protocol converter, B-2  
  description of, **4-2**  
Activation Request Status codes, **4-7**  
  abort code, **4-7**  
  autoanswer timeout code, **4-7**  
  disconnect code, **4-7**  
  good, no status, **4-7**  
  hand-held computer error, **4-7**  
  line busy code, **4-7**  
  modem error code, **4-7**  
  modems reported  
  no carrier, **4-7**  
  no dial tone, **4-7**  
  ring, call collision, **4-7**  
  no answer code, **4-7**  
  parameter error code, **4-7**  
  port activation error code, **4-7**  
Active Status  
  4980 protocol converter, B-2  
  network manager-to-host record  
  4980 protocol converter, B-2  
  description of, **4-2**  
Active Status Record layout, network manager-to-host, using 1-byte ID, **4-2**  
Architectures  
  AS/400 programming, A-3  
  between 6980 Socket Manager and AS/400, A-2  
AS/400  
  4980 interface, A-2  
  6980 interface, A-3  
  converting to 6980, A-2  
  programming architecture, A-3  
Async  
  channel ID, C-1

  end-of-record delimiter, C-1  
  fixed block size, C-1  
  host-ready character, C-1  
  initialization record, C-1  
  transparent data, C-1  
Autoanswer, 4980 protocol converter, 2-1  
Autoanswer Activate  
  4980 protocol converter, B-3  
  host-to-network manager record, 4980 protocol converter, B-3  
Autoanswer timeout, activation request status code, **4-7**  
Autodial, 4980 protocol converter, 2-1  
Autodial Activate  
  4980 protocol converter, B-3  
  host-to-network manager record, 4980 protocol converter, B-3

## B

Begin of Call  
  4980 protocol converter, B-2  
  network manager-to-host record  
  4980 protocol converter, B-2  
  description of, **4-2**  
BOOT.INI, 2-4  
Booting from network manager, 4-11

## C

Channel ID  
  asynchronous host, C-1  
  logical, 2-2  
Channels, maximum, 2-3  
Client connections, 2-3  
  6980 physical ports, **2-3**  
Common file structures, 3-1, 4-1  
Communication session, parts of, 2-2  
Compact flash, 2-4  
  files, 2-4  
  folder structure, 2-4  
CompactFlash Card  
  network manager file processing, 4-11  
  reimaging, 2-4  
Converting 4980 to 6980, A-2

## D

Data record length, 4980 protocol converter, B-1  
Data Request  
  4980 protocol converter, B-2  
  network manager-to-host record  
  4980 protocol converter, B-2  
  description of, **4-2**  
Deactivate for One Minute  
  4980 protocol converter, B-3  
  host-to-network manager record  
  4980 protocol converter, B-3  
  description of, **3-2**  
Deactivate Request, network manager-to-host record, description of, **4-8**  
Device channel, definition of, 2-5

Differences between 4980 and 6980, A-1

Directive Status

- 4980 protocol converter, B-2
- network manager-to-host record
  - 4980 protocol converter, B-2
  - description of, **4-2**

Disconnect

- activation request status code, **4-7**
- status code, **4-4**

Download Data

- 4980 protocol converter, B-3
- host-to-network manager record
  - 4980 protocol converter, B-3
  - description of, **3-2**

## **E**

EM311

- 4980 Series Communications Controller, 2-5
- 6980/6985 Network Manager, 2-5
- comparison with EM611, 5-1
- frame of EM611 packet, 5-3
- moving from EM315, A-3
- portion of EM611 packet, 5-3

EM315, A-2

- moving to EM311, A-3

EM611

- definition, 5-1
- EM311 portion of packet, 5-3
- host-to-NPCMux application, 5-3
- packet and header, **5-1**
- structure and definition, 5-1

End-of-data

- 4980 protocol converter, B-3
- host-to-network manager record
  - 4980 protocol converter, B-3
  - description of, **3-2**

End of Session Status, network manager-to-host record, description of, **4-2**

End of Session Status codes, **4-4**

- Abort code, **4-4**
- Disconnect code, **4-4**
- Good status code, **4-4**
- Logic error code, **4-4**

End-of-record delimiter, C-1

End-of-session Status

- 4980 protocol converter, B-2
- network manager-to-host record, 4980 protocol converter, B-2

## **F**

File allocation error, host file directive status code, **4-10**

File create error, host file directive status code, **4-10**

File directive status codes

- file allocation error, **4-10**
- file create error, **4-10**
- file directory error, **4-10**
- file end error, **4-10**
- file handle bad, **4-10**
- file in use error, **4-10**
- file max error, **4-10**

file not found error, **4-10**

file not open error, **4-10**

file open error, **4-10**

file read error, **4-10**

file system locked, **4-10**

file write error, **4-10**

good status, **4-10**

request aborted, **4-10**

File directory error, host file directive status code, **4-10**

File end error, host file directive status code, **4-10**

File handle bad, host file directive status code, **4-10**

File in use error, host file directive status code, **4-10**

File max error, host file directive status code, **4-10**

File not found error, host file directive status code, **4-10**

File not open error, host file directive status code, **4-10**

File open error, host file directive status code, **4-10**

File read error, host file directive status code, **4-10**

File request, network manager-to-host record, description of, **4-8**

File Requests subtype

- 4980 protocol converter, B-2
- network manager-to-host record, 4980 protocol converter, B-2

File support, 4980 protocol converter, 2-1

File system locked, host file directive status code, **4-10**

File write error, host file directive status code, **4-10**

Files, NETRPL.LST, **4-11**

Fixed block size, asynchronous host, C-1

FTP server, 2-4

## **G**

Good status

- host file directive status code, **4-10**
- status code, **4-4**

Good, no status, activation request status code, **4-7**

## **H**

Hand-held computer error, activation request status code, **4-7**

Hand-held computers, 4980 protocol converter, 2-1

Hayes-compatible modems, 2-1

Host application, communication with network manager, 5-2

Host communications program, 1-1

- Activation Routine, D-2
- Download Data Routine, D-2
- End Status Routine, D-2
- Main Routine, D-1
- Remote 6980/6985 Logon, D-3
- Special Request Routine, D-3
- Upload Data Routine, D-2

Host Directive

- 4980 protocol converter, B-3
- host-to-network manager record
  - 4980 protocol converter, B-3
  - description of, **3-2**

Host file directive status codes, **4-10**

Host specific program, 1-1

Host-ready character, asynchronous hosts, C-1



## Host-to-network manager records

- 4980 protocol converter
  - Autoanswer Activate, B-3
  - Autodial Activate, B-3
  - Deactivate for One Minute, B-3
  - Download Data, B-3
  - End-of-data, B-3
  - Host Directive, B-3
  - Initialization, B-3
- Autoanswer Activate, 4980 protocol converter, B-3
- Autodial Activate, 4980 protocol converter, B-3
- Deactivate for One Minute, 4980 protocol converter, B-3
- description of
  - Activate Autoanswer, **3-2**
  - Activate Autodial, **3-2**
  - Deactivate for One Minute, **3-2**
  - Download Data, **3-2**
  - End-of-data, **3-2**
  - Host Directive, **3-2**
  - Initialization, **3-2, 3-5**
- directives
  - 1 - file upload, 3-12
  - 2 - file create or load, 3-13
  - 3 - file delete, 3-14
  - 4 - file download, 3-15
  - 6 - file processing abort, 3-16
- Download Data
  - 4980 protocol converter, B-3
  - description, **3-2**
- End-of-data, 4980 protocol converter, B-3
- Host Directive, 4980 protocol converter, B-3
- Initialization
  - 4980 protocol converter, B-3
  - description, **3-2, 3-5**
- record layouts type
  - 0 - download data, 3-3
  - 1 - end-of-data, 3-4
  - 2 - initialization, 3-5
  - 3 - activate (auto-answer), 3-8
  - 4 - activate (auto-dial), 3-9
  - 5 - deactivate for one minute, 3-10
  - 6 - host directive, 3-11
- special command types
  - ?, 3-17
  - \*, 3-17

## I

- Identification
  - 4980 protocol converter, B-2
  - logical channel, 2-2
  - network manager-to-host record
    - 4980 protocol converter, B-2
    - description of, **4-2**
- Inactive Status
  - 4980 protocol converter, B-2
  - network manager-to-host record
    - 4980 protocol converter, B-2
    - description of, **4-2**
- Initialization
  - 4980 protocol converter, B-3
  - host-to-network manager record
    - 4980 protocol converter, B-3
    - description of, **3-2, 3-5**
- Initialization record, asynchronous host, C-1
- Initialization records, parameters
  - host, 3-7
  - system mode, 3-6
- Interfaces, asynchronous, 1-1

## L

- Layouts, host-to-network manager, 3-1
- Line busy, activation request status code, **4-7**
- Line disciplines, 4980 protocol converter, 2-1
- Local 6980, NPCMux functionality, 5-2
- Logic error, status code, **4-4**
- Logical channels
  - client connections, 2-3
  - description, 2-2

## M

- Modem error, activation request status code, **4-7**
- Modems
  - activation request status code
    - reported no carrier, **4-7**
    - reported no dial tone, **4-7**
    - reported ring, call collision, **4-7**
  - supported, 2-1

## N

- NETRPL.LST, 4-11
  - file, **4-11**
- Network manager configuration
  - 6980CE.INI control parameters, D-1
  - activation record parameters, D-1
  - consists of, D-1
  - initialization record parameters, D-1
- Network manager-based file processing, 4-11
- Network manager-to-host record formats, 2-byte channel ID, **4-1**
- Network manager-to-host records, 1-1
  - 4980 protocol converter
    - Activation Request, B-2
    - Active Status, B-2
    - Begin of Call, B-2
    - Data Request, B-2
    - Directive Status, B-2
    - End-of-session Status, B-2
    - File Requests subtype, B-2
    - Identification, B-2
    - Inactive Status, B-2
    - Special Request, B-2
    - Upload Data, B-2
  - Activation Request, 4980 protocol converter, B-2
  - Active Status, 4980 protocol converter, B-2
  - Begin of Call, 4980 protocol converter, B-2
  - Data Request, 4980 protocol converter, B-2
  - data request, 1-1
  - description of
    - Activation Request, **4-2**
    - Active Status, **4-2**
    - Begin of Call, **4-2**
    - Data Request, **4-2**
    - Deactivate Request subtype, **4-8**
    - Directive Status, **4-2**
    - End of Session Status, **4-2**
    - File request subtype, **4-8**
    - Identification, **4-2**
    - Inactive Status, **4-2**
    - Special Request, **4-2**
    - Upload Data, **4-2**
  - Directive Status, 4980 protocol converter, B-2
  - End-of-Session, 4980 protocol converter, B-2
  - File Request subtype, 4980 protocol converter, B-2
  - Identification, 4980 protocol converter, B-2
  - Inactive Status, 4980 protocol converter, B-2

- record layout types
    - 0 - upload data, 4-3
    - 1 - end of session status, 4-4
    - 2 - data request, 4-5
    - 3 - inactive status, 4-5
    - 4 - active status, 4-6
    - 5 - activation request, 4-6
    - 6 - special request, 4-8
    - 7 - directive status, 4-9
    - C - begin of call, 4-10
  - Special Request, 4980 protocol converter, B-2
  - Upload Data, 4980 protocol converter, B-2
  - No answer, activation request status code, 4-7
  - NPCMux application
    - EM611 framing, 5-3
    - functionality, 5-2
    - handshake, from host, 5-3
  - NPCP
    - 6980 physical ports, 2-3
    - logical port assignment, 2-2
    - NPCMux application, 5-2
- P**
- Parameter error, activation request status code, 4-7
  - Parameters
    - host, 3-7
    - system mode, 3-6
  - Physical ports, 6980, 2-3
  - Port activation error, activation request status code, 4-7
- R**
- Related publications, 1-2
  - Request aborted, host file directive status code, 4-10
- S**
- Socket Interface, A-3
  - Socket Manager, architectural differences, A-2
  - Special commands, host-to-network manager, 4980 protocol converter, B-4
  - Special Request
    - 4980 protocol converter, B-2
    - network manager-to-host record
      - 4980 protocol converter, B-2
      - description of, 4-2
  - Status codes
    - abort, 4-4, 4-7
    - activation request, 4-7
    - autoanswer timeout, 4-7
    - disconnect, 4-4, 4-7
    - end of session, 4-4
    - file allocation error, 4-10
    - file create error, 4-10
    - file directory error, 4-10
    - file end error, 4-10
    - file handle bad, 4-10
    - file in use error, 4-10
    - file max error, 4-10
    - file not found error, 4-10
    - file not open error, 4-10
    - file open error, 4-10
    - file read error, 4-10
    - file system locked, 4-10
    - file write error, 4-10
    - good status, 4-4, 4-10
    - good, no status, 4-7
    - hand-held computer error, 4-7
    - host file directives, 4-10
    - line busy, 4-7
    - logic error, 4-4
    - modem error, 4-7
    - modems reported
      - call collision, ring, 4-7
      - no carrier, 4-7
      - no dial tone, 4-7
    - no answer, 4-7
    - parameter error, 4-7
    - port activation error, 4-7
    - request aborted, 4-10
- T**
- Transparent
    - data - asynchronous host, C-1
    - mode - asynchronous host, C-1
  - TTY, 6980 physical ports, 2-3
- U**
- Upload Data
    - 4980 protocol converter, B-2
    - network manager-to-host record
      - 4980 protocol converter, B-2
      - description of, 4-2
- W**
- Web Server, 2-4
  - Windows CE, 2-4