Initial 1551E Set up for WinLEBCI and SIMM Users ONLY

Note: **If you are *NOT* a WinLEBCI or SIMM user, please disregard this set-up sheet, and please refer to the Getting Started Guide for installation instructions.**

STEP 1: Remove 1551E from box, attach cable to scanner and plug scanner into terminal.
STEP 2: Power up the computer terminal.
STEP 3: Scan the TWO barcodes associated with the task you are to perform; WinLEBCI requires first two barcodes, SIMM requires last two barcodes.

Reset factory defaults
Predefined terminal selections - RS-232 - standard RS-232 C (9600, 7, E, 2)
RS-232 - postamble - Carriage Return

\46\42\41\4A\01\24\45\54\3E\0D\60

Disable all symbologies
Code 11 - active
Code 11 - check digit – 1 digit (*)
Code 11 - check digit - checked and transmitted (*)
Code 39 - active (*)
Code 39 - format - full ASCII
Code 128 / EAN 128 - active

41\4B\42\44\45\43\45\45\41\4C\42\4B\41\5A\60

WinLEBCI Users: Both barcodes must be scanned in the order presented before installing the scanner for the first time.

Reset factory defaults
Predefined terminal selections - Keyboard wedge - standard PC - QWERTY English
Keyboard wedge - postamble - Tab

46\42\41\4A\03\08\45\54\04\02\08\60

Disable all symbologies
Code 11 - active
Code 11 - check digit – 1 digit (*)
Code 11 - check digit - checked and transmitted (*)
Code 39 - active (*)
Code 39 - format - full ASCII
Code 128 / EAN 128 - active

41\4B\42\44\45\43\45\45\41\4C\42\4B\41\5A\60

SIMM Users: Both barcodes must be scanned in the order presented before installing the scanner for the first time.

Note: **Scanner configuration needs only to be performed once prior to initial use. The 1551E scanner will retain configuration settings even if power is disconnected. Technicians – please retain for your records.**

Part No. 071632-001

071632-001

Intermec
Technologies Corporation

6001 36th Avenue West
P.O. Box 4280
Everett, WA 98203-9280

© 2001 Intermec
All Rights Reserved