

SOFTWARE RELEASE NOTES

Intermec Launcher™ Version 2.00

For CV41 CE6.0 Computers

1. Version Information	1
2. Installation Notes	1
<i>To Install Intermec Launcher</i>	<i>1</i>
<i>Licensing</i>	<i>1</i>
3. New Functionality Available in Version 2.00	2
4. Issues Fixed In This Version	2
5. Known Issues	2

1. Version Information

This release of Intermec Launcher operates on CV41 mobile computers running CE6.0. Please reference the Intermec Launcher User’s Manual for additional information on features and use of Intermec Launcher.

2. Installation Notes

To Install Intermec Launcher

The download posted on the website is a SmartSystems Bundle. The installation will install into a SmartSystems Console to allow for easy “drag-and-drop” installation onto your discovered devices. You may also install Intermec Launcher via other methods such as SD card or ActiveSync.

A free version of SmartSystems Foundation is available for download at:

<http://www.intermec.com/products/smrtsysfoundation/index.aspx>.

Licensing

Intermec Launcher V2.00 may require an activation or maintenance license to operate in full featured mode.

- If maintenance has not been purchased, a new license may be required to run this version of Intermec Launcher.

Intermec Launcher will run in a Demo mode for 60 days if your device does not contain a proper factory license or activation license or maintenance license. Demo mode allows you to operate the device for 60 days in “full feature”. After 60 days, the device will move to nag mode.

Licenses are available for purchase through your Intermec representative or online at:

<http://order.intermec.com>.

3. New Functionality Available in Version 2.00

- Updated the base code to support Intermec CV41 computer.

4. Issues Fixed In This Version

- None.

5. Known Issues

- None.