


4420/4440 Parallel Port Cover Instruction Sheet

Install the parallel port cover on any 4420 or 4440 printer that has an internal Ethernet adapter installed. The parallel interface is unavailable with the Ethernet adapter installed.

To install the parallel port cover

- Orient the parallel port cover over the parallel port and insert over the parallel port.

The parallel port cover is square on one end to allow for easy removal. The parallel port cover should only be removed if the Ethernet adapter has been disconnected.



Intermec
Technologies Corporation

6001 36th Avenue West
P.O. Box 4280
Everett, WA 98203-9280

© 1999 Intermec
All Rights Reserved
Part No. 069565-001