

Dust Cover Instructions



Use the dust cover to protect your Intermec mobile computer keypad from dust, dirt, and rain. The clear material of the dust cover allows you to use the touch screen and the keypad with the dust cover installed. You cannot install a dust cover if you are using a snap-on adapter, CAC reader, or holster accessory.



Note: Remove the dust cover before inserting your computer into a charging or communications dock.


To install the dust cover

1 If you have a CK31G, CN2G, or 751G, remove the I/O connector.






Note: The CN3NI has an optional dust clip that functions as the serial port cover. You do not need to remove the dust clip to install the dust cover. Refer to P/N 943-167-001 for usage instructions.

- A** Insert the top of the mobile computer into the dust cover.
- B** Pull the dust cover over the bottom of the mobile computer.



Installing the Dust Cover: Each Intermec mobile computer has a unique dust cover made specifically for it. This illustration shows the CK31G with a 52-key keypad dust cover for reference.


- 2 If non-incendive sealing is required, install the I/O cover on your mobile computer.



Installing the I/O Cover



Note: On the CK61G to maintain non-incendive certification, you may also need to insert the headphone plug into the jack.



Installing the Headphone Plug

Dust Cover Instructions



P/N 074130-005



Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2009 Intermec Technologies
Corporation. All rights reserved.