

Printer Shoulder Strap Instructions




The printer shoulder strap (P/N 074788-xxx) provides you with a convenient way to carry your PB21, PB22, PB31, PB32, PB42, PB50, PB51, or PW50 printer. The wide padded strap makes it comfortable to wear the printer for long periods of time.

The shoulder strap kit contains these parts:

- Shoulder strap accessory
- These instructions

To attach the shoulder strap to the mobile printer (PB2X, PB3X, PB4X, PB5X)

- 1 Install the handstrap on the printer.
- 2 Orient the shoulder strap so that the textured side of the strap padding is facing toward the printer. You want the textured side of the padding to sit on your shoulder when the strap is installed.
- 3 Attach the snap hooks on the ends of the shoulder strap to the D-rings on the handstrap.



You are now ready to use the printer with the shoulder strap accessory.


To attach the shoulder strap to the PW50

- 1 Orient the shoulder strap so that the textured side of the strap padding is facing toward the printer. You want the textured side of the padding to sit on your shoulder when the strap is installed.

2 Open one of the the snap hooks and insert it parallel to the bar on one side of the PW50. Then, rotate the snap hook until it catches the bar and release the latch.



Note: If you have a handstrap installed, attach one of the snap hooks to the D-ring on the handstrap.



3 Repeat Step 2 with the other snap hook.

You are now ready to use the PW50 with the shoulder strap accessory.

Printer Shoulder Strap Instructions



P/N 943-160-004

Intermec

Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2010 Intermec Technologies Corporation. All rights reserved.

