



AB17 | AB18

CK3 Series Battery Information

Charge the Battery Pack

You need to fully charge the battery before you use it in your CK3 Series (CK3a, CK3a1, CK3n, CK3n1, CK3c, CK3c1, 1007CP01, 1007CP02, 1007CP02L, and 1007CP02-N1) mobile computer. You can charge batteries after a partial discharge without affecting the original battery capacity. A fully discharged battery charges in approximately four (AB17) to six (AB18) hours.

You can charge the AB17 or AB18 battery with these accessories:

- Desktop Base (Model 1002UU01) (with 1002UC02)
- Dual Base (Model 1002UU02, 1002UU03) (with 1002UC02)
- Quad Base (Model 1002UU04, 1002UU05) (with 1002UC02)
- CK3 Series Quad Charger (Model AC20)
- CK3 Series Single Dock (Model AD20)

You can also charge an AB17 or AB18 battery installed in a CK3 Series mobile computer. For more information about charging accessories, see your computer user manual or the instructions that shipped with the accessory.

Important Recommendations

- Do not store the battery at temperatures above 60 °C (140 °F), such as inside a car on a hot day or in direct sunlight as this may damage the battery.
- Use battery pack AB17 or AB18 only with a CK3 series mobile computer. Use of this battery pack in other devices could result in damage to the device or battery.
- Only charge your battery pack with a Honeywell-approved charger.
- Replace the battery only with another AB17 or AB18 battery. These batteries have been tested in accordance with applicable safety standards. Contact your local sales representative or distributor if this battery is no longer available.
- Promptly dispose of used batteries in accordance with local regulations. This battery pack contains Lithium-ion chemistry. Do not allow metallic conductive objects to contact battery terminals. Do not short-circuit a battery or throw it into a fire; it can explode and cause severe personal injury.
- Improper battery use may result in a fire, explosion, or other hazard.
- For maximum battery life, charge the battery at 20 °C (68 °F) to 25 °C (77 °F) and store at 23 °C (73 °F) with a 50% charge.

Specifications

Design and specifications are subject to change without notice.

Product:	Rechargeable Li-ion battery (Model AB17 or AB18)
Dimensions:	(AB17) 9.1 x 4.2 x 2.2 cm (AB18) 9.1 x 4.2 x 2.5 cm (3.6 x 1.7 x 0.9 in)
Weight:	(AB17) 67.7 g (2.4 oz) (AB18) 123.4 g (4.3 oz) (3.6 x 1.7 x 1.0 in)
Maximum output:	≈ 4.2 V
Nominal output:	≈ 3.7 V
Capacity:	(AB17) 2000 mAh (AB18) 5100 mAh
Operating temperature:	-20 °C to 60 °C (-4 °F to 140 °F)
Charging temperature:	0 °C to 45 °C (32 °F to 113 °F)
Storage temperature:	-20 °C to 60 °C (-4 °F to 140 °F)
Relative humidity:	5% to 95% non-condensing



16201 25th Avenue West
Lynnwood, Washington 98087
U.S.A.

www.honeywellaidc.com

Copyright © 2015
Honeywell International Inc.
All rights reserved.



CK3 Series Battery (Model AB17/AB18) Information



P/N 943-175-006



Caution: This battery pack may ignite, create a chemical burn hazard, explode, or release toxic materials if mistreated. Do not incinerate, disassemble, or heat above 100 °C (212 °F). Do not short circuit; may cause burns. Keep away from children.



Dikkat: Bu ürüne kullanılan pil paketleri tutuşabilir, kimyasal yanık tehlikesi oluşturabilir, patlayabilir ya da yanlış kullanıldığında toksik maddeler salgılayabilir. Yakmayın, parçalarına ayırmayın ya da 100 °C'nin üzerinde ısıtmayın. Kısa devre yaptırmayın, yanmalara sebep olabilir. Çocuklardan uzak tutun.



Vorsicht: Dieser Akkusatz kann sich bei Missbrauch entzünden, chemische Verätzungen verursachen, explodieren oder toxische Substanzen freisetzen. Nicht verbrennen, zerlegen oder über 100 °C erwärmen. Keinen Kurzschluss verursachen; Verbrennungsgefahr. Von Kindern fern halten.



警告: 電池包可能着火、造成化學燃燒危險、爆炸，而且如果處理不當會釋放有毒物質。請勿燒毀、分解電池，或其溫度超過 100 °C。請勿使電池短路，以免引起火災。請不要讓兒童接觸到電池。



Precaución: Esta batería puede encenderse, crear un peligro de quemadura química, explotar o expedir materiales tóxicos si se trata indebidamente. No la incinere, desarme ni caliente sobre 100 °C. No haga cortocircuitos porque pueden causar quemaduras. Manténgala alejada de los niños.

适用于中国用户

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr ⁶⁺)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电池	X	0	0	0	0	0

0: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572-2011标准规定的限量要求以下。

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T26572-2011 标准规定的限量要求。

警告:

- 電池浸水後禁止使用!
- 禁止拆解、撞擊、擠壓、或投入火中。
- 若出現嚴重鼓脹，請勿繼續使用。
- 請勿置於高溫環境中。



Mise en garde : Ce bloc-piles peut prendre feu, constituer un risque de brûlure chimique, exploser ou dégager des substances toxiques s'il est manipulé de façon inappropriée. Ne pas jeter au feu, démonter ou chauffer à plus de 100 °C. Ne pas court-circuiter; cela pourrait causer des brûlures. Garder hors de la portée des enfants.



주의: 이 배터리 팩은 잘못 다룰 경우 불이 붙거나 화학 반응을 일으키거나 폭발하거나 또는 유독 물질이 흘러나올 수 있습니다. 배터리를 불에 태우거나 분해하거나 100 °C 이상의 열을 가하지 마십시오. 배터리를 단락시키지 마십시오. 화재가 발생할 수 있습니다.



Cuidado: A bateria pode pegar fogo, criar risco de queimadura química, explodir ou exalar materiais tóxicos se abusada. Não incinerar, desmontar nem aquecer a bateria a mais de 100 °C. Não provocar curto-circuito, pois pode causar queimaduras. Manter afastada de crianças.



注意: 此電池必須小心處理，否則可能會燃燒、造成化學灼傷、爆炸或釋放出有毒物質。請勿焚燒、拆卸或使其溫度超過 100 °C。請勿短路，否則可能會導致灼傷。請放在兒童拿不到的地方。



Осторожно: При неправильном обращении этот батарейный источник питания может воспламениться, создать опасность химического ожога, взорваться или выделять ядовитые материалы. Не сжигайте, не разбирайте, не допускайте нагрева выше 100 °C. Не замыкайте контакты накоротко – это может причинить ожог. Прячьте от детей.

廢電池請回收