

CS40

Tethered Stylus Replacement Instructions

指示笔更换说明

指示筆更換說明

Upute za zamjenu povezanog Stylusa

Instructions pour le remplacement du stylet filaire

Anweisungen zum Ersatz des Stifts mit Schnur


테더 스타일러스 교체 지침

Instruções de substituição da caneta stylus fixa

Инструкции по замене привязного пишущего элемента

Instrucciones para cambiar el puntero con cordón

คำแนะนำ การเปลี่ยนปากกาโลหะที่จำกัดขอบเขต





Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2010 Intermec Technologies
Corporation. All rights reserved.



CS40 Tethered Stylus Replacement Instructions



P/N 943-280-001