

IF61



Ferrite Bead Installation Instructions

磁珠安装说明

Instructions d'installation de la perle en ferrite

Anweisung zur Anbringung der Ferritperle

Instrucciones de instalación del núcleo de ferrita



To ensure compliance, attach the ferrite bead to the Ethernet cable.

为确保合规性，请在以太网电缆上安装磁珠。

Pour garantir la conformité, attachez la perle en ferrite au câble Ethernet.

Zur Einhaltung der Konformitätsbestimmungen Ferritperle an das Ethernetkabel anbringen.

Para asegurar el cumplimiento, conecte el núcleo de ferrita al cable Ethernet.



Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2011 Intermec Technologies
Corporation. All rights reserved.



IF61 Ferrite Bead Installation Instructions



P/N 943-316-001