

PR₂ | PR₃

Metal Belt Clip Installation Instructions

金属皮带夹安装说明

金屬皮帶夾安裝說明

Instructions d'installation du clip de ceinture en métal

Installationsanleitung zum Metallgürtelclip

Istruzioni per l'installazione delle clip da cintura in metallo


금속 벨트 클립 설치 지침



Instruções de instalação do Clipe de cinto de metal

Инструкции по установке металлических зажимов для крепления к ремню

Instrucciones de instalación de la pinza metálica para cinturón

Metal Kemer Mandali Kurulum Talimatları





Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2012 Intermec Technologies Corporation. All rights reserved.



PR2 and PR3 Metal Belt Clip Installation Instructions



P/N 943-356-001