

**Quad Battery Charger Instructions**

Use these instructions to install and use the 700 Series Color Mobile Computer Quad Battery Charger, Model AC16. The quad battery charger can charge up to four battery packs at the same time. The shipping box for the charger contains the charger, these instructions, and the compliance insert.

Items not provided:

- An Intermec-approved power supply
- A country-specific power cord



**Caution:** The Model 700C battery charger is suitable for use only with Intermec battery pack Model 318-013-004. Use of any other battery pack may present risk of fire or explosion hazard.


**Attention:** Le modèle de chargeur de batterie 700C peut être utilisé avec les numéros de référence de bloc de batterie Intermec suivants 318-013-004. L'utilisation de tout autre bloc de batterie présente un risque d'incendie ou d'explosion.

**Vorsicht:** Das Batterieladegerät Modell 700C ist nur zum Laden der Intermec Batteriesätze mit den Teilenummern 318-013-004 geeignet. Bei Verwendung eines anderen Batteriesatzes besteht Brand- oder Explosionsgefahr.


**Precaución:** El Cargador de batería Modelo 700C debe ser utilizado solo con los paquetes de batería Intermec N/P 318-013-004. El uso de cualquier otro paquete de batería puede ocasionar riesgos de incendio o explosión.

**To install and use the charger**

- 1 Tilt the battery pack at a slight angle and insert it into the charger with the battery pack sliding under the lip the charger.



- 2 Push down on the battery pack until you hear a click.
- 3 Connect the power supply to the charger and the power supply to a power source.



- 4 Charge the battery pack until the LED turns green.

Each battery compartment on the charger has its own status LED. Use this chart to understand the status of the LED.

#### ***Understanding the Charging Status LED***

LED Color	Description
Off	No power to charger.
Red	The battery pack is charging.
Green	The battery pack is completely charged.
Yellow	No battery pack is installed in the charger. If the LED goes from red to yellow during charging, the battery pack is defective. Replace the battery pack.



Worldwide Headquarters  
6001 36th Avenue West  
Everett, Washington 98203  
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2010 Intermec Technologies Corporation. All rights reserved.



700 Series Color Mobile Computer Quad Battery Charger Instructions



P/N 962-000-036D