

## Specifications

### Environmental

Operating Temperature: -20°C to +50°C (-4°F to +122°F)  
Storage Temperature: -30°C to 70°C (-22°F to +158°F)  
Relative Humidity: 5% to 95%

### DEX Connector Pinouts

Pin Number	I/O to Computer	Description
Ring	O	RS-232 Transmit data
Tip	I	RS-232 Receive data
Sleeve	PWR	Signal Ground

CK60 DEX Snap-On Adapter (AA4) Instructions



P/N 962-032-011C



Worldwide Headquarters  
6001 36th Avenue West  
Everett, Washington 98203  
U.S.A.

tel 425.348.2600


fax 425.355.9551

[www.intermec.com](http://www.intermec.com)

© 2010 Intermec Technologies Corporation. All rights reserved.



## Instructions



### CK60 DEX Snap-On Adapter (AA4)

## Out of the Box

After you remove the CK60 Handheld Computer DEX Adapter (Model AA4) from the shipping box, save the box and packing material in case you need to ship or store the device. The CK60 DEX adapter shipping box should contain these items:

- CK60 DEX adapter
- CK60 DEX adapter instructions
- Compliance insert

## What is the CK60 DEX Adapter?

DEX/UCS is an industry standard for electronic transfer of invoice information between the supplier's mobile computer and the retailer's in-store receiving system. The transfer takes place through a DEX adapter cable.

The DEX Snap-On Adapter allows quick and easy attachment of the DEX cable to the CK60 Handheld Computer. Two metal guides ensure proper alignment of the adapter to the handheld computer; spring clips hold the adapter securely in place while the handheld computer is carried around the store.

A power connector on the DEX adapter allows connection of an external power supply to the CK60 without removing the adapter.

**You must remove the DEX adapter from the CK60 if you want to place the handheld computer in a dock.**

### To attach the DEX adapter:

- Align metal clips with guides on either side of the CK60 handheld computer and press firmly. The adapter latches into place.

### To remove the DEX adapter:

- Squeeze the finger grips on both sides of the DEX adapter to disengage clips and pull the DEX adapter away from the handheld computer.

## CK60 DEX Adapter Features

