

Important Setup Information!

Please Read This Before Turning On Your CT60

Place the CT60 on charge (with an AC adapter or dock) before turning it on for the first time.

Using the AC Adapter or Dock

To charge the battery using the AC adapter, plug the circular connector of the AC adapter into the AC connector in the CT60 or in the power supply port on the replicator. Battery charging begins automatically as the unit is docked when using a vehicle-docking mount, desktop docking station or a wall mount docking station.

The first time you boot your new computer, you will be asked some basic setup questions. The entire process will take less than five minutes.

Before turning on the computer, you must be prepared to run through this setup in its entirety.



Do not turn OFF the computer before completing this setup process or you will corrupt your hard drive image!



Do not use any external power source other than the AC adapters provided with the CT60; permanent damage to the battery or computer may result.



Do not connect more than one power source at a time, such as an AC power supply and a docking station, when charging the CT60 or permanent damage to the battery or computer may occur.

Contact support personnel at 1-800-755-5505 (US and Canada).

Intermec

Corporate Headquarters
6001 36th Avenue West
Everett, Washington 98203
tel 425.348.2600
fax 425.355.9551
www.intermec.com

CT60 Setup Guide June 2003



962054067A REV A

Important Setup Information!

Please Read This Before Turning On Your CT60

Place the CT60 on charge (with an AC adapter or dock) before turning it on for the first time.

Using the AC Adapter or Dock

To charge the battery using the AC adapter, plug the circular connector of the AC adapter into the AC connector in the CT60 or in the power supply port on the replicator. Battery charging begins automatically as the unit is docked when using a vehicle-docking mount, desktop docking station or a wall mount docking station.

The first time you boot your new computer, you will be asked some basic setup questions. The entire process will take less than five minutes.

Before turning on the computer, you must be prepared to run through this setup in its entirety.



Do not turn OFF the computer before completing this setup process or you will corrupt your hard drive image!



Do not use any external power source other than the AC adapters provided with the CT60; permanent damage to the battery or computer may result.



Do not connect more than one power source at a time, such as an AC power supply and a docking station, when charging the CT60 or permanent damage to the battery or computer may occur.

Contact support personnel at 1-800-755-5505 (US and Canada).

Intermec

Corporate Headquarters
6001 36th Avenue West
Everett, Washington 98203
tel 425.348.2600
fax 425.355.9551
www.intermec.com

CT60 Setup Guide June 2003



962054067A REV A