



Intermec




Operator's Guide




**ScanPlus 1802
Battery Charger**

Installation




Operation




1 Power on



2 Insert battery or scanner




3 Initial battery state (during 10 seconds)



The initial state of the battery is displayed for 10 seconds before charging starts.


This indication is only valid if the battery is left idle (not charged or discharged) before you place it in the battery charger.

4 Charging




Full charging takes up to 3 hours.

5 Battery fully charged



Troubleshooting



- The battery is not correctly connected to the charger. → Remove and reinsert the battery.
- The operating temperature is too high or too low. → Remove the battery and leave at room temperature.
- The battery is not in working order. → Change the battery.

Recommendations

For longer battery life, only recharge the battery when you see the low battery signal (scanner flashes rapidly when you pull the trigger and continues to flash for a few seconds after releasing the trigger).

You can store a battery/scanner in the charger to maintain it at full charge but do not repeatedly insert and remove a battery/scanner as this reduces battery life.

Do not store a battery/scanner for an extended period of time in a charger which is not powered up, because the battery will discharge faster.

Only use the charger for Intermec Ni-Mh Hybride Battery packs rated 3.6V, 600mA, 0.6 Ah (P/N 3-360029-13).

Do not throw away batteries.



WARNING: Fire, explosion and severe burn hazard. Do not crush, disassemble, heat above 100° C (212° F) or incinerate Battery Pack (P/N 3-360029-13).

Regulatory statements

CE Intermec hereby declares that the ScanPlus 1802 Battery Charger has been tested and found compliant with the below listed standards as required by the EMC Directive 89/336/EEC as amended by 92/31/EEC and by the Low Voltage Directive 73/23/EEC as amended by 93/68/EEC: EN55022 (1992) and EN50082-1 (1998). This device is TÜV GS licensed (EN 60950 and EN 60825-1) for safety only when powered by an external Intermec power supply, Intermec P/N 3-301029-03 ~ 230V 50/60 Hz, Intermec P/N 3-303029-03 ~ 240V 50 Hz.

USA: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide a reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, increase the separation between the equipment and the receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected or consult the dealer or an experienced radio/TV technician for help.


In order to maintain compliance with the FCC Rules, the I/O cables that interconnect between the device and any peripheral must be as specified by Intermec.

Caution: Changes or modifications not expressly approved by Intermec could void the user's authority to operate this equipment.

This device is UL and cUL listed (UL1950 / C22.2 n°950). For safety, this unit must be powered by a UL listed LPS power supply, Intermec P/N 3-302029-03 ~120V 60 Hz, output rated 5V DC, 600 mA.

Canada: This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada. Cet équipement est listé UL et cUL (UL1950 / C22.2 n°950). Pour la sécurité, cet équipement doit être connecté à une alimentation listée UL / cUL, Intermec P/N 3-302029-03 ~120V 60 Hz, 5V DC, 600 mA.

Australia-New Zealand: This equipment has been tested and found to conform to the Australian EMC framework concerning Class B digital devices, prescribed by the Australian and New-Zealand standard AS/NZS 3548.  N309

The information contained in this document is for informational purposes only and is subject to change without notice. No part of this document may be copied or reproduced in any manner without the prior written permission of Intermec Technologies Corporation.

ScanPlus products are covered by patents issued or pending in the USA and other countries.

The words Intermec, ScanPlus and the Intermec logo are either trademarks or registered trademarks of Intermec Technologies Corporation.

Throughout this document, trademarked names may be used. Rather than put a trademark (™ or ®) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

EasySet® is a registered trademark of Intermec Technologies Corporation.

© 2007 Intermec Technologies Corporation

All rights reserved



North America / Asia Pacific / Latin America • 6001 36th Avenue West, PO Box 4280, Everett, WA 98203-9280, USA
Tel: +1 425 348 2600 • Fax: +1 425 348 2833
U.S. service and technical support, tel: 1 800 755 5505 • Canadian service and technical support, tel: 1 800 688 7043

Europe / Middle East / Africa • Sovereign House, Vastern Road, Reading RG1 8BT, England
Tel: +44 118 987 9400 • Fax: +44 118 987 9401

Internet: www.intermec.com

E-mail: info@intermec.com

